

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE*
(Other instructions
reverse side)

Reed Sanderson
Lease Bureau No. 1004-11-5
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

891008822 *60 05/622-13*

6. IF INDIAN, ALLETTREE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1.

OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Conoco Inc.

3. ADDRESS OF OPERATOR

P.O. Box 460 - Hobbs, NM 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below)
At surface

1980' FNL & 660' FEL

14. PERMIT NO.

30-025-04188

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3636' DF

7. UNIT AGREEMENT NAME

Reed Sanderson Unit

8. FARM OR LEASE NAME

Reed Sanderson

9. WELL NO.

#7

10. FIELD AND POOL, OR WILDCAT

Eumont Yates 7 Rivers Queen

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 4, T20S, R36E

12. COUNTY OR PARISH

Lea

13. STATE

NM

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETION

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

XX

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT*

(Other)

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. MIRU. TOOH and LD 2-3/8" tubing. PU and TIH w/4-3/4" bit, 5-1/2" csg scraper, and 2-7/8" workstring to 3886'. POOH.

2. Set CIBP @ 3855'. Spot 25 sx cement on CIBP.

*Spot $\pm 50'$ cmt @ $\pm 1500'$ *(SJS)*

3. Spot 10-1/2 sx cement from 394' to 293'. WOC.

4. Circ. cement up surface casing and set surface plug. Perf 5-1/2" prod. Casing at 275'. Pump 95 sx cement to fill up 8-5/8" x 5-1/2" annulus and set plug.

6. Erect abandonment marker

For further technical information call Tom Boelens at 397-5870.

18. I hereby certify that the foregoing is true and correct

SIGNED

W.W. Baker

W.W. Baker

TITLE

Administrative Supervisor

DATE

July 10, 1989

(This space for Federal or State office use)

APPROVED BY

Shannon Shaw

For:
TITLE

CHIEF, MINERAL RECORDS

DATE

7-31-89

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side