## State of New Mexico

Submit 3 Copies Form C-103 Empy, Minerals and Natural Resources Department to Appropriate Revised 1-1-59 District Office OIL CONSERVATION DIVISION WELL API NO. P.O. Box 1980, Hobbs, NM 88240 P.O. Box 2088 3002505655 Santa Fe, New Mexico 87504-2088 P.O. Drawer DD, Artesia, NM 88210 5. Indicate Type of Lease STATE FEE 1000 Rio Brazos Rd., Azlec, NM 87410 6. State Oil & Gas Lease No. B-1589-1SUNDRY NOTICES AND REPORTS ON WELLS ( DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A 7. Lease Name or Unit Agreement Name DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) 1. Type of Well: NORTH MONUMENT G/SA UNIT WELL WELL T BLK. 6 2. Name of Operator & Well No. AMERADA HESS CORPORATION 3. Address of Operator 9. Pool name or Wildcat POST OFFICE DRAWER D, MONUMENT, NEW MEXICO 88265 **EUNICE MONUMENT G/SA** Well Location Unit Letter \_\_ F : \_\_ 1980 Feet From The \_\_ NORTH 1980 Feet From The WEST Line and Line 20 19S 37 E LEA Range **NMPM** County 10. Elevation (Show whether DF, RKB, RT, GR, etc.) Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data 11. NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK ALTERING CASING TEMPORARILY ABANDON **CHANGE PLANS** COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT **PULL OR ALTER CASING** CASING TEST AND CEMENT JOB OTHER: OTHER:\_ 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. NMGSAU #606 Move in and rig up pulling unit, reverse unit and air unit. TOH with rods and pump. Nipple down wellhead. Nipple up BOP. Shut-in well overnight. TIH w/Amerada Bomb and obtain static bottomhole pressure. TOH w/tubing. TIH w/4-3/4" bit on drill collars and 2-7/8" tubing. Clean out openhole to TD (3,995' MD). Drill out an additional 10'. TOH w/bit and tubing. Rig up Schlumberger. TIH and log openhole with GR/LDT log. TOH w/tools. Rig down Schlumberger. Rig up acid company. TIH w/tubing open ended and spot acid on bottom of openhole. TOH w/tubing. TIH w/packer and tubing to 3,850'. Acidize well with 5,000 gals. 15% NEFE DI HCL. Swab/flow back load. Swab/flow test well. Obtain oil water and gas samples for analysis. TOH w/tubing and packer. TIH w/tubing. Nipple down BOP. Nipple up wellhead. TIH w/rods and pump. Rig down and move out pulling unit. Pump test well.

Sr. Staff Assistant DATE 02-01-94	
TELEPHONE NO. 393-214	4
FE2 Ve	199
	TELEPHONE NO. 393-214

CONDITIONS OF APPROVAL, IF ANY:

APPROVED BY