

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUMMIT IN TRIPLICATE
(Other instructions on the
reverse side)Form approved
Budget Project No. 42-R1421
6. LEASE IDENTIFICATION AND SERIAL NO.

LC 021621 (a)

8. IS INDIAN, ALLEGED OR OTHER NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. ☐ OIL WELL ☒ GAS WELL ☐ OTHER		7. UNIT AGREEMENT NAME	
2. NAME OF OPERATOR UNION TEXAS PETROLEUM CORPORATION		8. FARM OR LEASE NAME Britt "A"	
3. ADDRESS OF OPERATOR 1300 Wilco Building, Midland, Texas 79701		9. WELL NO. 3	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface Unit Letter "K", 1830' FWL & 2130' FSL		10. FIELD AND POOL, OR WILDCAT Monument	
14. PERMIT NO.		11. SEC., T., R., M., OR BLM. AND SURVEY OR AREA Sec. 6, T-20-S, R-37-E	
15. ELEVATIONS (Show whether DF, RT, CR, etc.) 3575' DF		12. COUNTY OR PARISH Lea	13. STATE New Mexico

18. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF	☐	PULL OR ALTER CASING	☐
FRACTURE TREAT	☐	MULTIPLE COMPLETE	☐
SHOOT OR ACIDIZE	☐	ABANDON*	☐
REPAIR WELL	☐	CHANGE PLANS	☐
(Other) Plug Back & Re-complete			☒

SUBSEQUENT REPORT OF:

WATER SHUT-OFF	☐	REPAIRING WELL	☐
FRACTURE TREATMENT	☐	ALTERING CASING	☐
SHOOTING OR ACIDIZING	☐	ABANDONMENT*	☐
(Other)			☐

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. MIRUPU - Install BOP.
2. Pull out of hole w/tubing and production equipment.
3. Run 5 1/2" retainer on tubing and set @ 5100'. Squeeze perforations 5184 to 5202 w/150 sx. Class "C" cement. Spot 20' on top of retainer.
4. Perforate two holes @ 3665' and establish circ. to surface. RIH w/retainer on 2 3/8" tubing & set at 3650'. Cement 5 1/2" casing with 200 sx. Class "C" cement.
5. Perforate Grayburg zone with 1 JSPF 3378, 96, 3403, 12, 44, 57, 73, 85, 90; 3504, 37 43, 54, 58 & 68'.
6. RIH w/Baker Model "R" pkr. With Pkr. @ 3350', acidize perfs. w/4000 gallons 15% NE acid.
7. Swab back spent acid water and place well on production.

19. I hereby certify that the foregoing is true and correct

SIGNED [Signature]TITLE Sr. Prod. AnalystDATE 2-1-77

(This space for Federal or State office use)

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____

DATE _____

APPROVED
[Signature]
D. J. ANDERSON
DISTRICT ENGINEER