

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240DISTRICT II
P.O. Drawer DD, Artesia, NM 88210DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 3002506030
5. Indicate Type of Lease STATE ☐ FEE ☒
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name T. Anderson
8. Well No. 1
9. Pool name or Wildcat Eunice Monument G.S.A.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL ☒ GAS WELL ☐ OTHER	2. Name of Operator <i>Producing Inc.</i> Texaco Exploration and Production Inc.
3. Address of Operator P.O. Box 730 Hobbs, N.M. 88240	4. Well Location Unit Letter <u>J</u> : 1980 Feet From The <u>South</u> Line and 1980 Feet From The <u>East</u> Line Section <u>8</u> Township <u>20S</u> Range <u>37E</u> NMPM Lea County 10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3564 D. F.

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1.) Notify OCD 24 hours prior to commencement of plugging operations.
- 2.) MIRUPU. Set CIBP @ 3630'. Cap w/ 35' of cement. (Class "H" w/ 2½ CaCl₂, 5.2 gal/sack, 15.6 ppg, 1.18 cu. ft/sack).
- 3.) Run freepoint on 7" casing. Cut and pull casing. Load hole with 9.5 ppg mud.
- 4.) Set 100' cement plug (28 sxs Class "H" 1.18 cu ft/sack w/ 2½ CaCl₂) across 7" casing stub.
- 5.) Pull up hole and set 100' (37 sxs Class "H" 1.18 cu ft/sack w/ 2½ CaCl₂) cement plug across 9 5/8" casing shoe.
- 6.) Pull up hole and set 100' (37 sxs Class "H" 1.18 cu ft/sack w/ 2½ CaCl₂) cement plug across 13" casing shoe.
- 7.) Set 27' (10 sxs Class "H" 1.18 cu ft/sack w/ 2½ CaCl₂) cement at surface.
- 8.) Cut off wellhead. Install hole marker. Clean location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE *M.C. Duncan*TITLE Engineer's AssistantDATE 1/30/91TYPE OR PRINT NAME M.C. DuncanTELEPHONE NO. 393-7191

(This space for State Use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: