

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
E-1587

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Gulf Oil Corporation	8. Farm or Lease Name Lea "11" State
3. Address of Operator Box 670, Hobbs, New Mexico 88240	9. Well No. 1
4. Location of Well UNIT LETTER <u>K</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>30</u> TOWNSHIP <u>19-S</u> RANGE <u>35-E</u> NMPM.	10. Field and Pool, or Wildcat Pearl Queen
15. Elevation (Show whether DF, RT, GR, etc.) 3752' GL	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	
OTHER <input type="checkbox"/>			

Plug and Abandon

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

5116' PB.

Load hole with brine water. Pull tubing and packer. Set CI BP at 4700' and cap with 5 sacks (35') of cement. Cut and recover 5-1/2" casing at approximately 3200'. Spot abandonment mud from cement plug at approximately 4665' to 3200'. Spot 20 sack (100') cement plug across 5-1/2" casing stub at 3200'. Cut and recover 8-5/8" casing at approximately 3100'. Load hole with mud. Spot 40 sack (100') cement plug across 8-5/8" casing stub. Spot 70 sack (100') cement plug across 13-3/8" shoe at 354'. Spot 70 sack cement plug from 100' to surface. Install dry hole marker and clean location.

100' plug @ top 521'

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED C. J. Kallinger TITLE Area Engineer DATE May 12, 1972

APPROVED BY Joe D. Roney TITLE Dist. I, Supv. DATE MAY 15 1972

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

MAY 12 1972

OIL CONSERVATION COMM.
HOODS 11-1