

Form 3160-5  
(June 1990)

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

5. Lease Designation and Serial No.  
NM, 4046 40406

6. If Indian, Allottee or Tribe Name

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Collins & Ware, Inc.

3. Address and Telephone No.

303 W. Wall, Ste. 2200, Midland, TX 79701

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

K, 1980' FSL & 1980' FWL, Sec. 6, T20S, R34E

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Quietman Fed. #1

9. API Well No.

30-025-31714

10. Field and Pool, or Exploratory Area

Quail Ridge Morrow

11. County or Parish, State

Lea NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

☐ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☒ Other P&A  
☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

CIBP(s) at the following locations w/35' cement plugs on top of BP: 13010', 10950', 7980'.

Perfs now open: 6350-6366' (2JSPF)

Proposed plugging procedure:

1. Set CIBP @ approx. 6320' w/ 35' cement plug on top of BP.
2. Spot 35 sx plug 5250-4940 across shoe 9 5/8.
3. Spot 35 sx plug 3244-2934 across shoe 13 3/8.
4. To recover 1500' / 5 1/2" csg., spot additional 50 sx plug @ 1650-1369'.
5. Spot 35 sx plug 547-237 across 20" shoe.
6. Spot 20 sx plug @ surf. 0-175'.
7. Install dry hole marker.

14. I hereby certify that the foregoing is true and correct

Signed Max Guerrey

Title Regulatory Mgr.

Date 9-29-93

(This space for Federal or State office use)

(ORIG. SGD.) JOE G. LARA

Approved by  
Conditions of approval, if any:

Title PETROLEUM ENGINEER

Date 10/20/93

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

\*See Instruction on Reverse Side