

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-06132
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. 77043
7. Lease Name or Unit Agreement Name State I
8. Well No. 1
9. Pool name or Wildcat Monument Paddock

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
2. Name of Operator Texaco E & P Inc.	
3. Address of Operator P.O. Box 3109, Midland, Texas 79702	
4. Well Location Unit Letter <u>N</u> : <u>330</u> Feet From The <u>South</u> Line and <u>1650</u> Feet From The <u>West</u> Line Section <u>16</u> Township <u>T 20 S</u> Range <u>R 37 E</u> NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Notify OCD of intent to plug
- 2) MIRU, NU BOPE
- 3) RIH w/tbg & tag CIBP @5090
- 4) CIRC hole w/9.5# mud
- 5) Pull to 3581 and spot 15 sx to 3481', WOC & tag
- 6) Pull to 2546 and spot 25 sx to 2446
- 7) Pull to 1260 and spot 40 sx to 1050, WOC & tag
- 8) Pull to 281 and spot 25 sx to 181, WOC & tag
- 9) Set surface plug 0 - 50 w/10 sx
- 10) RDMO - cut off well head, install dryhole marker & clean location

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Dave W. Deax TITLE Reservoir Engineer DATE 3/17/98

TYPE OR PRINT NAME Dave Deax

TELEPHONE NO 915-688-4492

(This space for State Use)

ORIGINAL SIGNED BY CHRIS WILLIAMS
DISTRICT SUPERVISOR

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

mp