

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Benito Rd., Aztec, NM 87410

**OIL CONSERVATION DIVISION**  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-07807
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER TA	7. Lease Name or Unit Agreement Name WARREN MCKEE UNIT
2. Name of Operator AMERADA HESS CORPORATION	8. Well No. 402
3. Address of Operator DRAWER D, MONUMENT, NM 88265	9. Pool name or Wildcat WARREN MCKEE
4. Well Location Unit Letter C : 2324 Feet From The WEST Line and 330 Feet From The NORTH Line Section 17 Township 20S Range 38E NMPM LEA County	

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
<b>NOTICE OF INTENTION TO:</b>	<b>SUBSEQUENT REPORT OF:</b>
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

PLAN TO MIRU PU AND INSTALL BOP. TIH WITH 4-3/4" OVERSHOT, 2-3/8" GRAPPLE, BUMPER SUB, JARS, 6 -3-1/2" DC'S ON 2-7/8" WORK STRING TO 6285'. ATTEMPT TO JAR PKR. LOOSE. IF SUCCESSFUL IN RETRIEVING FISH TOH WITH FISH, TIH WITH 5-1/2" CIBP AND SET ±9000'. TIH WITH 5-1/2" MODEL R PKR. & TEST CIBP TO 2000#. LOCATE CASING LEAK AND ESTABLISH RATE AND PRESSURE INTO LEAK. SQUEEZE LEAK AS CONDITIONS WARRANT. WOC. LOAD & TEST CSG. TO 500 PSI FOR 30 MIN., OBTAIN CHART FOR OCD. CIRCULATE WITH TREATED FLUID AND TEMPORARILY ABANDON WELL. IF UNSUCCESSFUL IN RETRIEVING FISH NOTIFY NMOCD. PREPARE PLAN TO LEAVE PKR. AND MINIMAL AMOUNT OF TUBING IN HOLE AND ABANDON MCKEE ZONE. LOCATE CASING LEAK. SQUEEZE LEAK AS CONDITIONS WARRANT. WOC. LOAD & TEST CASING TO 500 PSI FOR 30 MIN., OBTAIN CHART FOR NMOCD. CIRCULATE HOLE WITH TREATED FLUID AND TEMPORARILY ABANDON WELL.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Cindy Robertson TITLE ADMIN. STAFF ASSIST. DATE 5/6/92  
TYPE OR PRINT NAME \_\_\_\_\_ TELEPHONE NO. \_\_\_\_\_

(This space for State Use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY:

This Approval of Temporary  
Abandonment Expires

MAY 11 '92