

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.
300250781800

5. Indicate Type of Lease
Federal ☐ STATE ☐ FEE ☐

6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL ☐ GAS WELL ☐ OTHER Water Injection

2. Name of Operator
Conoco Inc.

3. Address of Operator
10 Desta Drive West, Midland, TX 79705

4. Well Location

Unit Letter G : 1980 Feet From The North Line and 1980 Feet From The East Line

Section 19 Township T-20S Range R-38E NMPM Lea County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
GR 3540'

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☒ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well is shutin pending a field-wide study, that is in progress, to determine its use in future waterflood operations. It is proposed to temporarily abandon this well by the following procedure.

Refer to the wellbore schematics copied on the back of this form.

1. Clean out wellbore to PBTD at 3899'.
2. RIH w/4-1/2" packer and RBP. Set RBP at 3625' inside liner.
NOTIFY NMCD 24 HOURS BEFORE PRESSURE TESTING RBP.
3. Pressure test RBP to 500 psi for 30 min.
4. Circulate hole with Conoco packer fluid.
5. RIH and set RBP in 7" casing at 2115', above casing leak at 2130'.
6. Pressure test RBP to 500 psi for 30 min.
7. Load hole with Conoco packer fluid and shutin.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Jerry W. Hoover TITLE Regulatory Coordinator DATE 11-1-90
TYPE OR PRINT NAME Jerry W. Hoover TELEPHONE NO. (915) 686-6548

(This space for State Use)

Orig. Signed by
Paul Kautz
Geologist

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

NOV 05 1990