

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-229	

SUNDRY NOTICES AND REPORTS ON WELLS <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small>		
1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator		Jalmat Field Yates Sand Unit
3. Address of Operator		8. Farm or Lease Name
Box 670, Hobbs, New Mexico 88240		9. Well No.
4. Location of Well		137
UNIT LETTER <u>F</u> , <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>2310</u> FEET FROM		10. Field and Pool, or Wildcat
THE <u>West</u> LINE, SECTION <u>14</u> TOWNSHIP <u>22-S</u> RANGE <u>35-E</u> NMPM.		Jalmat
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
3581' GL		Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <u>Plug and Abandon</u> <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

4050' TD, 4046' PB.

Pull producing equipment. Set CI BP at 3800' and cap with 35' Class H cement plug to 3765', abandoning perforations 3840' to 4008'. Set cement retainer at 3500' and squeeze below retainer with 100 sacks of Class H cement. Spot 35' Class H cement plug on top of retainer. Load hole with abandonment mud. Spot 100' Class H cement plug from 2050' to 1950', across salt section. Spot 50' cement plug from 50' to surface. Install dry hole marker and clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>[Signature]</u>	TITLE <u>Area Engineer</u>	DATE <u>June 27, 1975</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>[Signature]</u>	DATE <u>JUN 30 1975</u>
CONDITIONS OF APPROVAL, IF ANY:		