

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Imperial-American Management Company	8. Farm or Lease Name Merry Christmas
3. Address of Operator 507 Midland Savings Bldg.- Midland, Texas 79701	9. Well No. 1
4. Location of Well UNIT LETTER L 660 FEET FROM THE West LINE AND 1980 FEET FROM THE South LINE, SECTION 30 TOWNSHIP 21-S RANGE 33-E N.M.P.M.	10. Field and Pool, or Wildcat Undesignated
15. Elevation (Show whether DF, RT, GR, etc.) 3414 GR	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is proposed to P.&A. this well as follows:

1. Squeeze perfs 7168- 7513' w/ 200 sx class C
2. Squeeze perfs 6661-6806' w/ 100 sx class C
3. Load hole with mud.
4. Shoot off 7" casing at free point- Est. to be above 3500' .
5. Set 100' cement plug at base of salt section from 2670 to 2770
6. Set 100' cement plug at top of salt section from 1520 to 1620
7. Set 45 sx plug 860- 960'- half in , half out of surface casing shoe
8. Set 10 sx plug Surface to 23'.
9. Set Surface marker and clean up location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u><i>[Signature]</i></u>	TITLE <u>Area Manager</u>	DATE <u>1-19-70</u>
APPROVED BY <u><i>[Signature]</i></u>	TITLE _____	DATE _____
COPIES OF APPROVAL, IF ANY:		