

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

EXPIRES IN 1985
(Other instructions on reverse side)

Expires August 31, 1985
5. LEASE DESIGNATION AND SERIAL NO.

LC 045708-B

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT" for such proposals.)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Owens Federal

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

Wantz ABO

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 19, T21S, R38E

12. COUNTY OR PARISH

Lea

13. STATE

New Mexico

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

American Exploration Company

3. ADDRESS OF OPERATOR

21-0 NCNB Center, Houston, Texas 77002

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)

At surface
1980' FSL & 660' FWL of Sec. 19, T21S, R38E, Lea Co., New Mexico

14. PERMIT NO.

15. ELEVATIONS (Show whether OF, RT, GR, etc.)

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREAT

MULTIPLE COMPLETION

FRACTURE TREATMENT

ALTERING CASING

SHOOT OR ACIDIZE

ABANDON*

SHOOTING OR ACIDIZING

ABANDONMENT*

REPAIR PLUG

CHANGE PLUG

(CHECK)

NOTE

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATION: (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to the work.)

*NOTIFY BLM AT (505)393-3612 PRIOR TO COMMENCING PLUGGING OPERATION.
MIRU WOR. Set CIBP @ $\pm 6600'$. Freepoint 7" csg. Cut & POH w/7". Set 100' cmt. plug (50' in 7"/50' above 7" in openhole). Set 100' cmt. plug across base of salt section @ $\pm 2500'$. Set 100' cmt. plug @ 810-910' across surface csg. shoe. Set 50' cmt. plug @ surface. Cut off csg. 4' below ground. Cap well. Set metal plate on surface.

*USE 9.0 PPG MUD BETWEEN PLUGS.

*USE CLASS 'C' CEMENT MIXED WITH FRESH WATER WITH SLURRY WEIGHT OF 14.8 PPG.

✓ TAG THE CASING STUB PLUG.

✓ TAG THE SURFACE CASING SHOE PLUG.

RECEIVED

JUN 11 8 01 AM '90

DATE

18. I hereby certify that the foregoing is true and correct

SIGNED

Marty B. McClanahan

TITLE

Sr. Production Analyst

DATE

6/04/90

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

8 20 90

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side