

NO. OF COPIES RECEIVED	
DISTRIBUTION	
AMT A FE	
ILC	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-101
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO REOPEN OR REEQUIP A WELL IN A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT TO DRILL OR REEQUIP FOR SUCH PROPOSALS.)

1. ☒ OIL WELL ☐ GAS WELL ☐ OTHER

2. Name of Operator
Amoco Production Company

3. Address of Operator
P. O. Drawer "A", Levelland, Texas 79336

4. Location of Well
UNIT LETTER L 1980 FEET FROM THE South LINE AND 660 FEET FROM
THE West LINE, SECTION 28 TOWNSHIP 22-S RANGE 35-E NMPM.

5a. Indicate Type of Lease
State ☒ Fee ☐

5. State Oil & Gas Lease No.
L-1926

7. Unit Agreement Name
Rock Lake Unit

8. Farm or Lease Name
Rock Lake Unit

9. Well No.
1

10. Field and Pool, or Wildcat
Rock Lake Bone Springs

12. County
Lea

15. Elevation (Show whether DF, KT, GR, etc.)
3581 RDB

6. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☒	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPNS. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOBS ☐	

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to PXA well by loading hole with mud laden fluid and spotting 100 foot (25 sacks) Class H cement plug at top of Bone Springs interval 8,650'-8,750' (Perfs at 8720'-8804'). Raise tbq to 6500' and spot 100 foot (25 sacks) Class H cement plug at top of Delaware sand interval 6,400' to 6,500'. (Perfs at 6470' to 6530'). Run free point to 4550', cut and recover 7-5/8" casing. Run tbq. and set 10-3/4" CIBP 20 feet below 7-5/8" casing stub and cap w/50 foot (25 sacks) Class H cement plug. Run free point to 2993', cut and recover 10-3/4" casing. Run tbq. and spot 100 foot (90 sacks) Class H cement plug from 50 feet below to 50 feet above 10-3/4" casing stub. Spot 20 foot (25 sacks) Class H cement plug in top of 16" casing and erect PXA marker. Clean location and restore surface to contour.

100' plug at top of salt, if not behind Pipe

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

2. NAME
R.W. Cox
R.W. Cox
TITLE Administrative Assistant DATE 10-27-76

3. DIV
1-RC
MOVED BY
TITLE
DATE

4. CONDITIONS OF APPROVAL, IF ANY
note above

RECEIVED

JUL 26 1973

CLERK OF THE COURT
U.S. DISTRICT COURT
SOUTHERN DISTRICT OF NEW YORK