

C.L. CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State ☐	For ☒
5. State Oil & Gas Lease No.	

7. Unit Agreement Name	

8. Farm or Lease Name	
C.H. Weir 'A'	
9. Well No.	
12	
10. Field and Pool, or Wildcat	
Skaggs Drinkard	
12. County	
Lea	

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE APPLICATION FOR PERMIT - 1 (FORM C-101) FOR SUCH PROPOSALS.

OIL WELL ☒ GAS WELL ☐ OTHER ☐

Name of Operator

Texaco Inc.

Address of Operator

P.O. Box 728, Hobbs, New Mexico 88240

4. Location of Well

UNIT LETTER G 2307 FEET FROM THE North LINE AND 2307 FEET FROM

THE East LINE, SECTION 12 TOWNSHIP 20-S RANGE 37-E NEPA.

15. Elevation (Show whether DF, RT, GR, etc.)

3559' (GR)

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☐	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPNS. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOB ☐	
		OTHER <u>Perforate Treat & Complete</u> ☒	
		<u>Drinkard Zone</u>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Total Depth 7700' Plug Back Total Depth 7320'

13 3/8" OD 54.50# K-55 Csg set @ 1452'

9 5/8" OD 40# S-80 & 36# K-55 Csg. set @ 4000'

7" OD 23# K-55 Csg set @ 7700'

1. Perforate 7" Csg w/2-JSPF @ 7363', 95', 7444', 7501', 24', 52', 71', 7602', & 7610'.

2. Set pkr @ 7250'. Acidize perfs 7363'-7610' w/3000 gals. 20% NE-FE Acid containing clay stabilizer & 36 Ball sealers. Swab well.

3. Set cement retainer @ 7330'. Squeeze perfs. 7363'-7610' w/450 sx class H cement.

4. Perforate 7" csg w/2-JSPF @ 7049', 59', 68', 76', 90', 7114', 19', 22', 29', 44', 51', 55', 66', 78', 84', 90', 99', 7203', 09', 14', 32', 37', 41', 44', 59', 62', & 7286.

5. Set pkr. @ 6978'. Acidize perfs. 7049'-7286' w/8600 gals 20% NEFE Acid using clay stabilizer & 75 Ball sealers.

6. Test well.

7. Set RBP @ 6937' & spot 2 sx sand on plug.

8. Perforate 7" Csg w/2-JSPF @ 6634', 42', 50', 56', 63', 68', 74', 78', 82', 97', 6702', 06', 13', 18', 26', 31', 36', 38', 41', 42', 48', 49', 55', 56', 61', 62', 68', 73', 76', 81, 91, 96, 6801, 06, 10, 16, 26, 31, 36, 41, 49, 56, 61, 69, 76, 83, 89, 6894.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Asst. Dist. Mgr. DATE 12-21-81

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY: