

COPIES RECEIVED	
TRIBUTION	
FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Atlantic Richfield Company	8. Farm or Lease Name E. C. Adkins
3. Address of Operator P. O. Box 1710, Hobbs, New Mexico 88240	9. Well No. 8
4. Location of Well UNIT LETTER <u>A</u> <u>330</u> FEET FROM THE <u>North</u> LINE AND <u>330</u> FEET FROM THE <u>East</u> LINE, SECTION <u>9</u> TOWNSHIP <u>21S</u> RANGE <u>36E</u> NMPM.	10. Field and Pool, or Wildcat Eunice-Monument/ Grayburg-San Andres
15. Elevation (Show whether DF, RT, GR, etc.) 3603' GR	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well has been shut in since 1970 when production declined to 4-5 BOPD & 75 BWPD. We propose to P&A this well as shown below:

Set 7" 24# CIBP @ 3760' & cap w/35' of cement.
Load hole w/gel mud containing 25 sx gel per 100 BW.
Shoot off & recover 7" from free point.
Spot 40 sx (100') cement @ 7" stub.
If 7" stub is below top of salt, spot 40 sx cement (100') from 2420'-2320'.
Spot 40 sx cement (100') across 9-5/8" shoe @ 1392'.
Shoot off & recover 9-5/8" from free point.
Spot 40 sx cement @ 9-5/8" stub.
Spot 40 sx cement across 15 1/2" shoe @ 254'.
Set 10 sk cement plug in top of well - erect dry hole marker, clear & level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED A. D. Bretches TITLE Dist. Drlg. Supv. DATE 12/12/73

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY: