

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department
OIL CONSERVATION DIVISION
P.O. Box 2088

Form C-103
Revised 1-1-89

DISTRICT I

P.O. Box 1980, Hobbs, NM 88240

DISTRICT II

P.O. Drawer Dd, Artesia, NM 88210

DISTRICT III

1000 Rio Brazos Rd., Aztec, Nm 87410

Santa Fe, New Mexico 87504-2088

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		API NO. (assigned by OCD on New Wells)
1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER		5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
2. Name of Operator CHEVRON U.S.A. INC.		6. State Oil & Gas Lease No. N/A
3. Address of Operator P.O. BOX 1150 MIDLAND, TX 79702 ATTN: P.R. MATTHEWS		7. Lease Name or Unit Agreement Name W.A. RAMSAY (NCT-B)
4. Well Location Unit Letter <u>F</u> : <u>1980</u> Feet From The <u>NORTH</u> Line and Section <u>25</u> Township <u>21S</u> Range <u>36E</u> <u>1980</u> Feet From The <u>WEST</u> Line NMPM <u>LEA</u> County		8. Well No. 1
10. Elevation(Show whether DF, RKB, RT, GR, etc.)		9. Pool name or Wildcat EUMONT

11 Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTER CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABAN. ☐
CASING TEST AND CMT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operation:(Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

CHEVRON PROPOSES TO P & A WELLBORE.
SET CIBP AT 3375', SPOT 35' OF CMT. ON TOP.
SPOT 35 SX. BALANCED PLUG @ 3045'-2720', PLUG WILL COVER YATES & 7 RIVERS.
PERF AT 1455' WITH SQUEEZE HOLES.
SET CIGR AT 1300', SQZ WITH 40 SXs. CMT. LEAVE 35' CMT ON TOP OF CIGR.
ABOVE PLUG WILL COVER TOP OF SALT.
SET 10 SX. BALANCED CMT. PLUG F/360-250.
SET 10 SX. SURFACE PLUG F/100'-SURFACE.
CUT OFF WELLHEAD AND INSTALL P & A MARKER.
P & A MUD WILL BE SPOTTED BETWEEN ALL CMT. PLUGS.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE P.R. Matthews TITLE TECH. ASSISTANT DATE: 8-5-92

TYPE OR PRINT NAME P.R. MATTHEWS TELEPHONE NO. (915)687-7812

ORIGINAL SIGNED BY JERRY SEXTON

APPROVED BY DISTRICT I SUPERVISOR TITLE DATE AUG 07 '92

CONDITIONS OF APPROVAL, IF ANY: