

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-75

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☐ Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. GIL WELL ☒ GAS WELL ☐ OTHER ☐	7. Unit Agreement Name
2. Name of Operator SHELL WESTERN E&P INC.	8. Form or Lease Name PLUMLEE
3. Address of Operator P.O. BOX 576, HOUSTON, TX 77001 (WCK 4435)	9. Well No. 1
4. Location of Well UNIT LETTER <u>N</u> <u>660</u> FEET FROM THE <u>SOUTH</u> LINE AND <u>1980</u> FEET FROM THE <u>WEST</u> LINE, SECTION <u>12</u> TOWNSHIP <u>21-S</u> RANGE <u>37-E</u> NMPM.	10. Field and Pool, or Wildcat DRINKARD
11. Elevation (Show whether DF, RT, GR, etc.) 3454' DF	12. County LEA

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data.

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☐	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPER. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐		CASING TEST AND CEMENT JOBS ☐	
OTHER <u>SQZ DRINKARD, RCP TO WANTZ ABO & ACID TREAT</u> ☒		OTHER ☐	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

1. Pull production equipment.
2. Set cmt ret @ $\pm$ 6500'.
3. Sqz Drinkard perfs 6575' - 6837' w/100 sx Cls "C" cmt + .2% Halad-9 followed by 100 sx Cls "C" cmt + 2% CaCl₂. WOC 24 hrs.
4. DO cmt & cmt ret @ $\pm$ 6500'. Tag PBTB. Pres tst sqz to 500#.
5. DO CIBP @ 6875' & push to btm.
6. Tag btm. Set a balance plug of 75 sx Cls "H" cmt. WOC 24 - 48 hrs. Tag TOC. Cap cmt plug w/sand to 7250'.
7. Run base GR/temp survey from PBTB to 6900'.
8. Acid treat Wantz Abo OH 6950' - 7250' w/6000 gals 20% HCl + 1000# rock salt.
9. Run post treatment GR/temp survey from PBTB to 6900'.
10. Install production equipment and return well to production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED A. J. FORE TITLE SUPERVISOR REG. & PERMITTING DATE NOVEMBER 19, 1986
APPROVED BY Paul Rautz Geologist TITLE _____ DATE _____