

Submit 3 Copies
to Appropriate
District Office

2

State of New Mexico
Energy, Minerals and Natural Resources Department
OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

Form C-103
Revised 1-1-89

DISTRICT I

P.O. Box 1980, Hobbs, NM 88240

DISTRICT II

P.O. Drawer Dd, Artesia, NM 88210

DISTRICT III

1000 Rio Brazos Rd., Aztec, Nm 87410

| | |
|--|---|
| API NO. (assigned by OCD on New Wells) | 30-025-06731 ✓ |
| 6. Indicate Type of Lease | STATE <input checked="" type="checkbox"/> FEE <input checked="" type="checkbox"/> |
| 6. State Oil & Gas Lease No. | N/A |
| 7. Lease Name or Unit Agreement Name | EUBANK |
| 8. Well No. | 5 |
| 9. Pool name or Wildcat | BLINEBRY |

| | |
|--|--|
| SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) | |
| 1. Type of Well: | |
| OIL WELL <input checked="" type="checkbox"/> | GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/> |
| 2. Name of Operator | CHEVRON U.S.A. INC. |
| 3. Address of Operator | P.O. BOX 1150 MIDLAND, TX 79702 ATTN: NITA RICE |
| 4. Well Location | |
| Unit Letter | B - e |
| Section | 22 |
| Feet From The | 330 |
| Township | 21S |
| Line and Range | NORTH 2310 37E |
| Feet From The | EAST |
| NMPM | LEA |
| County | |
| 10. Elevation(Show whether DF, RKB, RT, GR, etc.) | 3424' GR |

11

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTER CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABAN. ☐
CASING TEST AND CMT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations(Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

WE PROPOSE TO PLUG AND ABANDON THIS WELLBORE AS FOLLOWS:
(TD @ 7756', OPEN HOLE 7644-7756', 7" CASING @ 7644, 9-5/8" CASING @ 2800')
ND WH, NU BOP, CUT 9-5/8" CASING @ 1100' & PULL. CUT 7" CASING @ 2700' & PULL.
PUT 20 SX CMT ON TOP OF CIBP @ 7400. TOP OF CMT @ 7280.
SET CIBP @ 5700', PUT 20 SX ON TOP, PLUG 5700-5580'. (COVERS BLINEBRY
PERFS 5739-5832.) SET 50 SX CEMENT PLUG 4860-5160, (ABOVE PADDOCK PERFS
THAT WERE SQZD). SET 65 SX CEMENT PLUG FROM 2450-2650'. SET 140 SX PLUG FROM 194-394'.
SET 100 SACK SURFACE PLUG (150-SURFACE). PULL DEAD MAN ANCHORS, FILL PITS, LEVEL LOCATION
PLACE P&A MARKER AND CHANGE STATUS OF WELL TO PLUGGED AND ABANDONED

*1 1/2" shoe plug 2700-2740
2" shoe plug 2740-2745
9 5/8" shoe plug 194-2450*

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Nita Rice TITLE TECHNICAL ASSISTANT DATE: 3/4/93

TYPE OR PRINT NAME NITA RICE TELEPHONE NO. (915)687-7436

APPROVED BY Paul Kautz TITLE Geologist DATE MAR 10 1993

CONDITIONS OF APPROVAL, IF ANY: