

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <u>DRY HOLE</u>		7. Unit Agreement Name
2. Name of Operator <u>PAN AMERICAN PETROLEUM CORPORATION</u>		8. Farm or Lease Name <u>BILBERRY</u>
3. Address of Operator <u>BOX 68, HOBBS, N. M. 88240</u>		9. Well No. <u>1</u>
4. Location of Well UNIT LETTER <u>E</u> <u>1980</u> FEET FROM THE <u>NORTH</u> LINE AND <u>660</u> FEET FROM THE <u>WEST</u> LINE, SECTION <u>6</u> TOWNSHIP <u>20-S</u> RANGE <u>39-E</u> NMPM.		10. Field and Pool, or Wildcat <u>HOUSE SAN ANDRES</u>
15. Elevation (Show whether DF, RT, GR, etc.) <u>3603' R.D. B.</u>		12. County <u>LEA</u>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT <input type="checkbox"/>	OTHER <u>San Andres Completion</u> <input checked="" type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TUBB: ABANDONED as follows: Set CI Ret. @ 6610'. Spot 45 sx plug across perfs 6615 - 6895'. Spot 5 sx cement on top of Retainer. Cemented behind 5 1/2" casing w/ 200 sx cement thru perfs @ 4645'. Set CI BP @ 4645'.

SAN ANDRES: Perforated interval 4536-86' w/ 25 SPF. Acidized w/ 4000 gal 28%. Evaluated. No Show of Oil or Gas.

PROPOSE TO PLUG & ABANDON AS FOLLOWS:

Cover San Andres perfs 4536-86' w/ 25 sx cement plug - 4645-4440'. Cut + pull 5 1/2" casing from full point. Est TCMT 3102'. Spot 10 sx @ surface & erect P & A marker. L & A procedure approved 3-13-68, John Ruman to DL Jones. Make final cleanup and restore ground to contour.

13 3/8" CSA 318. Ont Circ.  
8 7/8" CSA 3847. Ont 50' from surface.  
5 1/2" CSA 71 41' Ont Est Top 3102'.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED \_\_\_\_\_ TITLE AREA SUPERINTENDENT DATE 3-14-68

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

0-2- NMOCCH  
1- NSW  
1- SDS