

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 3002526802 ✓
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. B-1535
7. Lease Name or Unit Agreement Name State F-1
8. Well No. 9
9. Pool name or Wildcat Hardy Blinebry
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3520'

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator Conoco Inc.
3. Address of Operator 10 Desta Dr., Ste 100W, Midland, Tx 79705	4. Well Location Unit Letter U : 330 Feet From The south Line and 330 Feet From The west Line Section 1 Township 21S Range 36E NMPM Lea County
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3520'	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is proposed to shut off the water production and stimulate the State F-1 No. 9 well as follows:

1. POOH w/ production equipment.
2. Set RBP @ 5713'. Spot 5 sx sand on top of RBP.
3. Set packer @ 5585'.
4. Isolate top four (4) perms (5685, 5693, 5698, 5704'). Squeeze 45 sxs cement below packer.
5. DO cement & circ sand off off RBP.
6. POOH w/ws & RBP.
7. Acidize Blinebry w/3000 gals 15% HCL NEFE.
8. Place on production.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Jerry Sexton TITLE Sr. Conservation Coordinator DATE 1-20-93
TYPE OR PRINT NAME _____ TELEPHONE NO. _____

(This space for State Use)

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

JAN 22 1993

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY: