

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPI
(Other instructions
verse side)

Budget Bureau No. 1004-1
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL

NM-64602

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Lincoln Federal Unit

9. WELL NO.

1

10. FIELD AND POOL OR WILDCAT

Undes Bilbrey Morrow

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 26 T-21-S, R-32-E

12. COUNTY OR PARISH 13. STATE

Lea

NM

OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

Collins & Ware, Inc.

3. ADDRESS OF OPERATOR

600 W. Illinois, Ste 701 Midland, TX 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)

At surface

1980' FSL & 660 FWL of Sec. 26

14. PERMIT NO.

30-025-31193

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3709.9

16

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON*

CHANGE PLANE

X

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(Note: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Notify BLM @ (505) 393-3612 prior to commencing P & A - operations

1. Pump 175 BBLs of swabbed formation fluid into perforations.
2. Release packer & pull out hole with tbq.
3. Set CIBP @ 10,160' and place 50' cmt on plug, load hole w/ 9.5# mud.
4. Cut 7" csg @ 3300' and pull casing.
5. Place 130' cmt plug from 3365' to 3235' and tag plug.
6. Place 100' cmt plug from 900' to 800' and tag plug.
7. Place 50' cmt plug at surface - install dry hole marker.
8. Level pits and location - clean-up and re seed

18. I hereby certify that the foregoing is true and correct

SIGNED

J. E. Brusenhan

TITLE

Agent

DATE

9-20-91

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

10/17/91

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side