

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
A-2614	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Plug & Abandon		7. Unit Agreement Name	
2. Name of Operator Atlantic Richfield Company		8. Farm or Lease Name McDonald WN State	
3. Address of Operator P. O. Box 1710, Hobbs, New Mexico 88240		9. Well No. 10	
4. Location of Well UNIT LETTER <u>F</u> , <u>1650</u> FEET FROM THE <u>North</u> LINE AND <u>1650</u> FEET FROM THE <u>West</u> LINE, SECTION <u>25</u> TOWNSHIP <u>22S</u> RANGE <u>36E</u> NMPM.		10. Field and Pool, or Wildcat Jalmat	
15. Elevation (Show whether DF, RT, GR, etc.) 3456' GR		12. County Lea	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TD 3530'. Completed open hole section 2950-3530'.
12-3/4" OD csg set @ 25' & cmtd w/25 sx to surface.
8-5/8" OD csg set @ 1425' & cmtd w/500 sx to surface.
5-1/2" OD csg set @ 2950' & cmtd w/400 sx.

Propose to plug & abandon in the following manner:
Install BOP.
POH w/completion assy.
Run 5 1/2" cmt retr & set @ 2900' & cmt w/100 sx.
Spot heavy mud laden material between plugs.
Cut off & rec 5 1/2" csg from free point.
Spot 40 sx cmt across 5 1/2" csg stub.
Spot 40 sx cmt across 8-5/8" csg shoe.
Spot 10 sx cmt @ surface.
Erect regulation dry hole marker.
Clean & level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED H. J. Bernard TITLE Dist. Drlg. Supv. DATE 1/3/75

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: