

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Atlantic Richfield Company	8. Farm or Lease Name Ollie J. Boyd
3. Address of Operator P. O. Box 1978, Roswell, New Mexico 88201	9. Well No. 5
4. Location of Well UNIT LETTER <u>E</u> <u>2160</u> FEET FROM THE <u>North</u> LINE AND <u>330</u> FEET FROM THE <u>West</u> LINE, SECTION <u>23</u> TOWNSHIP <u>22-S</u> RANGE <u>37-E</u> NMPM.	10. Field and Pool, or Wildcat Paddock
15. Elevation (Show whether DF, RT, GR, etc.) 3336' GR	12. County Lea

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

A Paddock recompletion attempt, through perms 5058-5086, made in May, 1971, was unsuccessful. No remedial possibilities exist and we propose to P & A as follows:

Load hole w/9#/gal gel mud. 25 5x3/100 hbls.
Spot 25 sk cement plug from 5086' to 4900'.
Cut off and recover 5 1/2" casing from free point (TOC @ 3528')
Set 30 sx cement @ 5 1/2" stub
Set 30 sx cement from 2740' to 2850' (7-5/8" shoe @ 2801')
Set 10 sx cement in top of well and erect dry hole marker.

7-5/8" and 10-3/4" casing strings will remain intact. Location will be cleared and levelled.

100' plugs

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED P.D. Detches TITLE Dist. Dirg. Supervisor DATE 3/14/72

APPROVED BY Joe D. Ramey TITLE D. I. Supv. DATE MAR 16 1972
CONDITIONS OF APPROVAL, IF ANY: