

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	
-----	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name	
2. Name of Operator		8. Farm or Lease Name	
Morris R. Antweil		Shell "G"	
3. Address of Operator		9. Well No.	
Box 2010, Hobbs, New Mexico		1	
4. Location of Well		10. Field and Pool, or Wildcat	
UNIT LETTER <u>P</u> <u>330</u> FEET FROM THE <u>South</u> LINE AND <u>330</u> FEET FROM		Undesignated	
THE <u>East</u> LINE, SECTION <u>8</u> TOWNSHIP <u>22-S</u> RANGE <u>37-E</u> NMPM.			
15. Elevation (Show whether DF, RT, GR, etc.)		12. County	
3411' KB		Lea	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

### NOTICE OF INTENTION TO:

### SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUS AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Proposed to P. & A. as follows:

1. Spot 25 sx. cement plug across perfs 7319-1/2'--7327'.
2. Load hole with mud-laden fluid.
3. Cut & pull an estimated 6,000' 4-1/2" casing.
4. Spot 25 sx. cement plug across 4-1/2" casing stub.
5. Spot 25 sx. cement plug at top of Blinebry - 5350'.
6. Spot 25 sx. cement plug at top of Glorieta - 5030'.
7. Spot 25 sx. cement plug at top of San Andres-4000'.
8. Spot 25 sx. cement plug at base of salt. - 2400'.
9. Spot 25 sx. cement plug across 8-5/8" casing shoe @ 1200'.
10. Spot 10 sx. surface plug with marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>R.M. Williams</u>	TITLE <u>Agent</u>	DATE <u>11-25-69</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>SUPERVISOR DISTRICT</u>	DATE <u>NOV 26 1969</u>
CONDITIONS OF APPROVAL, IF ANY:		