

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR APPLICATIONS TO OIL OR GAS RIGHTS OR TO OIL OR GAS BACK TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT - (FORM C-101) FOR SUCH PROPOSALS.)

1. ☐ OIL WELL ☒ GAS WELL ☐ OTHER-

2. Name of Operator
GULF OIL CORPORATION

3. Address of Operator
P. O. Box 670, Hobbs, NM 88240

4. Location of Well
UNIT LETTER **L** **1980** FEET FROM THE **South** LINE AND **660** FEET FROM
THE **West** LINE, SECTION **16** TOWNSHIP **23-S** RANGE **33-E** N.M.P.M.

5a. Indicate Type of Lease
State ☒ Fee ☐

5. State Oil & Gas Lease No.
L-1927

7. Unit Agreement Name

8. Form of Lease Name
Lea "RL" State

9. Well No.
1

10. Field and Pool, or Wildcat
Brinninstool Morrow

12. County
Lea

15. Elevation (Show whether DF, RT, CR, etc.)
3695' GL

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☒	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPNS. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOBS ☐	OTHER ☐

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

15,950' TD.

Go in the hole and set a plug in on-off tool at 15,250'. Test plug to 1000#. Displace hole w/ 11# mud. Spot a 200' Class H cement plug on top of packer at 15,250'. Spot a 200' Class H cement plug from 13,600' to 13,400'. Spot a 200' Class H cement plug from 12,100' to 11,900'. Set at CIBP at 11,800' and cap with 100' Class H cement. Go in hole and cut 7 5/8" casing at 1000' and pull casing. Spot at 100' Class C cement plug from 1050' to 950'. Weld a 10 3/4" lift nipple and cut 10 3/4" casing at 900' and pull casing. Spot a Class C cement plug from 950' to 675'. Spot at 100' cement plug from 100' to surface. Install a dry hole marker. Clean and clear location.

I, Thereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED **H. B. Sikes, Jr.** TITLE **Area Engineer** DATE **5-2-78**

ORIG. SIGNED BY **John Runyan** TITLE Geologist DATE **MAY 1978**

CONDITIONS OF APPROVAL, IF ANY **Expires 11/1/78**