

UNITED STATES N. M. DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY HOBBS, NEW MEXICO 88240Form approved.  
Budget Bureau No. 42-R1424.  
5. LEASE DESIGNATION AND SERIAL NO.

NM25465

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER Dry Hole		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
2. NAME OF OPERATOR Sanders Petroleum Corporation		7. UNIT AGREEMENT NAME	
3. ADDRESS OF OPERATOR 7801 Academy Blvd. N.E.; Suite 201, Bldg. #2		8. FARM OR LEASE NAME Williamson Federal	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface  660' FEL & 1650' FSL		9. WELL NO. #1	
14. PERMIT NO.		10. FIELD AND POOL, OR WILDCAT Wildcat	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3632 GL		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec 25, T23S, R33E	
		12. COUNTY OR PARISH Lea	13. STATE N.M.

## 16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON\*

REPAIR WELL

CHANGE PLANS

(Other) Plug and Abandon

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT\*

(Other)

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) \*

P & A Well as Follows: (Top of cement was 4130' by Temp. Survey.  
Base of Salt is 4862')

1. Set CIBP at 5150', spot 35 sx. cement on top of plug. Pull 5 stands, WOC, tag top of cement, circ. hole with fresh water gel mud, pull tubing.
2. Perforate 4-1/2" casing with 3 jet shots at 1390'; cement with 150 sx. cement (25% excess, pump and plug method), leave 100' cement inside 4-1/2", 150' outside. WOC.
3. Tag Top of Cement with tubing, circ. hole w/ fresh water gel mud, pull tubing.
4. Spot 50' cement at top, remove wellhead.
5. Install 4" marker, 4' above GL, with welded lettering:  
SANDERS PETROLEUM CORPORATION  
Williamson Fed. #1  
660' FEL-1650'FSL  
25-T23S-R33E, Lea, N.M.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

President

DATE

April 15, 1988

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED  
APR 21 11 10 AM '88  
CARLETON COURTESY  
AREA HEADQUARTERS

RECEIVED  
APR 27 1999  
DEPT  
HOBBS CRIME