

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

U. S. OIL CONSERVATION COMMISSION

P. O. BOX 1900
HOBBS, NEW MEXICO 88240

Form Approved.
Budget Bureau No. 42-R1424

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil well ☒ gas well ☐ other ☐
2. NAME OF OPERATOR
Tenneco Oil Company
3. ADDRESS OF OPERATOR
6800 Park Ten Blvd., San Antonio, TX 78213
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 660 ENL & 1980' FEL
AT TOP PROD. INTERVAL: Same
AT TOTAL DEPTH: Same
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

5. LEASE
3503
6. IF INDIAN, ALLOTTEE OR TRIBE NAME
7. UNIT AGREEMENT NAME
8. FARM OR LEASE NAME
USA Jennings
9. WELL NO.
3
10. FIELD OR WILDCAT NAME
Double X Delaware
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Sec. 14, T24S, R32E
12. COUNTY OR PARISH
Lea
13. STATE
N. M.
14. API NO
15. ELEVATIONS (SHOW DF, KDB, AND WD)

- REQUEST FOR APPROVAL TO: SUBSEQUENT REPORT OF:
- TEST WATER SHUT-OFF ☐ ☐
- FRACTURE TREAT ☐ ☐
- SHOOT OR ACIDIZE ☐ ☐
- REPAIR WELL ☐ ☐
- PULL OR ALTER CASING ☐ ☐
- MULTIPLE COMPLETE ☐ ☐
- CHANGE ZONES ☐ ☐
- ABANDON* ☒ ☐
- (other) ☐ ☐

(NOTE: Report results of multiple completion or zone change on Form 9-331-C)

RECEIVED

NOV 5 1982

OIL & GAS
MINERALS MGMT. SERVICE
ROSWELL, NEW MEXICO

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. RIH with 2 7/8" tubing and tag bottom of open hole at approximately 4124' to verify depth.
2. Place 100' plug of cement at bottom of hole (4124' - 4024'). S.I. for 6 hours.
3. RIH w/tubing and tag cement to verify location.
4. Place 100' plug of cement from 1450' - 1350' to isolate salt zone.
5. Place 100' plug of cement from 400' - 300' (50' below existing 8 5/8" csg to 50' within csg). S.I. for 6 hrs. RIH with tubing and tag plug.
6. Place 15 sx of cement for surface plug.
7. Install surface plate & marker with proper identification.

NOTE: 10 lb. brine placed between all plugs.

Verbal approval per Armando Lopez 11-1-82 (M.M.S.) 505-624-1790

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED Robert A. Matthei TITLE Production Engineer DATE November 2, 1982

APPROVED

(This space for Federal or State office use)

APPROVED BY (Orig. Sgd.) PETER W. CHESTER TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

NOV 10 1982

FOR

JAMES A. GILLHAM
DISTRICT SUPERVISOR

See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

GPO 1976 O-214-149

NOV 1 1976
O.C.D.
HOBBS OFFICE