

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator <b>Skelly Oil Company</b>		8. Farm or Lease Name <b>R. R. Sims</b>
3. Address of Operator <b>P. O. Box 1351, Midland, Texas 79701</b>		9. Well No. <b>7</b>
4. Location of Well UNIT LETTER <b>K</b> <b>2200</b> FEET FROM THE <b>South</b> LINE AND <b>2200</b> FEET FROM THE <b>West</b> LINE, SECTION <b>3</b> TOWNSHIP <b>23S</b> RANGE <b>37E</b> NMPM.		10. Field and Pool, or Wildcat <b>W. C. Sims</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3307' DF</b>		12. County <b>Lea</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input checked="" type="checkbox"/> <b>Plug &amp; abandon the Blinebry Zone</b>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

**This well was temporarily abandoned in September of 1969. We propose to plug off the Blinebry Zone and hold the well bore for possible use in Skelly's Penrose "A" Unit. We propose the following work:**

- 1) Rig up workover rig. Pull tubing and packer.
- 2) Spot 35' cement plug at bottom of hole.
- 3) Set bridge plug above Blinebry perforations 5553-5587' at approximately 5525' and spot 35' cement plug on top of bridge plug.
- 4) Set 100' cement plug across Glorieta perforations 5180-5240'.
- 5) Run free point, cut off and pull 5-1/2" OD casing.
- 6) Set 100' cement plug across top of 5-1/2" OD casing cut off point.
- 7) Set 100' cement plug across 9-5/8" OD casing shoe at 3925'.
- 8) Move out rig.

**Well bore down to approximately 3700' to be held for possible use in Skelly's Penrose "A" Unit.**

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED D. R. Crow TITLE Lead Clerk DATE Feb. 20, 1973

APPROVED BY Joe D. Ramey TITLE Dist. I, Supv. DATE   
CONDITIONS OF APPROVAL, IF ANY: