

Form 3160-5
(July 1990)

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT *to*

1. Type of Well
☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Southwest Royalties, Inc.

3. Address and Telephone No.

P. O. Box 11390; Midland, TX 79702

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Sec. 19 T26S R37E 1980 FNL & 1650 FWL

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

5. Lease Designation and Serial No.
LC-030168 (A)

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Eaves "A" #4

9. API Well No.

30 025 12010

10. Field and Pool, or Exploratory Area

11. County or Parish, State

Lea, NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other _____
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

RU P&A Unit w/2-3/8" tbg. TIH to 3030' - spot 50 sx 1.32 ft 3/sx Class "C" cement up to 2700'. PUH WOC & TAB. If cement tags up below 2750', Set CIBP in 5-1/2" @ 2700'. Circulate hole w/9.5# mud. *cap w/35' cement*
Spot 30 sxs 1700-1500'. Perf @ 300', squeeze w/60 sxs, cement to leave 30 sxs outside & 30 sxs inside 5-1/2".
Spot 30' of cement inside 5-1/2" casing @ surface.
Cut off 5-1/2" & 10-3/4" casing 3' below ground level. Weld on steel plate to cover 5-1/2" & 10-3/4" casing. Cover cellar & place P&A Marker Pipe above Ground.

14. I hereby certify that the foregoing is true and correct

Signed *Matt Doffer* Matt Doffer Title Engineer

Date 4-17-96

(This space for Federal or State office use)

(ORIG. SCD.) JOE G. LARA

Approved by Conditions of approval, if any: *See attached.*

PETROLEUM ENGINEER

Date 5/31/96

This is U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See instruction on Reverse Side

[illegible]