

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

RECEIVED

SEP 24 10 38 AM '90

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or recomplete a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

5. Lease Designation and Serial No.

NMNM7951

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Leonard Federal #8

9. API Well No.  
300252188100S1

10. Field and Pool, or Exploratory Area  
Rhodes-Y

11. County or Parish, State

Lea Co., NM

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

BETTIS, BOYLE & STOVALL

3. Address and Telephone No.

P.O. Box 1240, Graham, TX 76046 817-549-0780

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

660' FSL & 660' FWL of Sec. 14, T-26S, R-37E

unit m

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment Notice

TYPE OF ACTION

☒ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☐ Other

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut-Off

☐ Conversion to Injection

☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Casing record: 7" set @ 400' in a 9 7/8" hole cemented with 170 sx; 4 1/2" 10.5# set @ 2701' in a 6 1/4" hole cemented with 100 sx., TOC @ 1250 - Temp. Survey.  
Total Depth: 3100' Open Interval: 2701-3100 (open Hole)

Permission requested to T & A well until we can plug with the following procedure:

- 1) CIBP set @ 2650' with 35' of cement on top
- 2) Cut & pull 4 1/2" @ 1050', 100' cement plug @ 1000-1100' (50' in pipe pulled and 50' out of pipe). This plug will be tagged.
- 3) Fill 7" from 400' to surface with cement.
- 4) 9# per gal. mud laden fluid will be used between plugs.

~~We request to leave well T&A'd until we can plug well. We anticipate being able to plug the well in January 1991 unless the weather makes it impossible to do so at that time.~~

14. I hereby certify that the foregoing is true and correct

Signed

Jim Fagon

Title

Production Analyst

Date

9/21/90

(This space for Federal or State office use)

Approved by

Conditions of approval, if any:

Title

Date

10-11-90