

UNITED STATES
DEPARTMENT OF THE INTERIOR

SUBMIT IN TRIPLI
(Other instructions
verse side)

Form approved.
Budget Bureau No. 42-R1424.

GEOLOGICAL SURVEY

5. LEASE DESIGNATION AND SERIAL NO.
LC 062132

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to re-perm or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

DeMooy Federal

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Wildcat-Bell Canyon

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 11-T26S-R35E

12. COUNTY OR PARISH

Lea

13. STATE

New Mexico

1. OIL WELL ☐ GAS WELL ☐ OTHER Plug and Abandon

2. NAME OF OPERATOR
SINCLAIR OIL & GAS COMPANY

3. ADDRESS OF OPERATOR
P. O. Box 1920, Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface
660' from the South and West lines.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☐
☐
☐
☐

PULL OR ALTER CASING

☐
☐
☒
☐
☐

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐
☐
☐
☐
☐

REPAIRING WELL

☐
☐
☐
☐
☐

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT*

(Other)

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Well drilled to Total Depth of 5486' Delaware Sand formation. No show oil or gas.
8-5/8"OD surface casing set @ 309' and cemented w/125 sacks cement to surface.

PROPOSE TO: Plug and Abandon as follows:

Fill hole w/mud laden material and spot 30 sacks cement (100' plug across top of Delaware sand 5100' to 5200'). Spot 30 sacks cement plug above salt 900' to 1000'. Spot 30 sacks cement plug bottom of 8-5/8"OD surface casing 235' to 355'. Spot 20 sacks cement plug 0-50' in top of 8-5/8"OD surface casing and cellar, install regulation dry hole marker, clean and level location.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Superintendent

DATE

5-7-68

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

Orig&cc: USGS, Hobbs

cc: Regional Office

cc: file

*See Instructions on Reverse Side

MAY 8 1968

A. R. BROWN

DISTRICT ENGINEER