

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLI
(Other instructions
verse side)

Form approved
Budget Bureau No. 1004-0135
Expires August 31, 1985
LEASE DESIGNATION AND SERIAL NO
NM 28063

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER ☐
2. NAME OF OPERATOR
Herman J. Ledbetter
3. ADDRESS OF OPERATOR
P.O. Box 5879 Abilene, TX 79608 (915)692-0671
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Jay Fed

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

So. Leonard Queen

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

24-265-37E

14. PERMIT NO.
30-025-25527
15. ELEVATIONS (Show whether DF, RT, OR, etc.)
2988 GR

12. COUNTY OR PARISH
Lea
13. STATE
New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREAT

MULTIPLE COMPLETION

FRACTURE TREATMENT

ALTERING CASING

SHOOT OR ACIDIZING

ABANDON*

SHOOTING OR ACIDIZING

ABANDONMENT*

REPAIR WELL

CHANGE PLANE

(Other)

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Propose to plug and abandon this well as follows:

1. Set a cast iron bridge plug at 3440' and dump a 35 foot plug on top of bridge plug with a bailer.
2. Set a cement plug in 4½" casing from 2460' to 2560'.
3. Cut and pull 4½" casing.
4. Set a 100' plug from 50' below stub to 50' above stub. TAG PLUG.
5. Set a 100' plug from 972' to 1072'. TAG PLUG.
6. Set marker in top of 8 5/8" casing.

Notes: (1) Notify BLM @ 505-393-3612 prior to commencing plugging operation.
(2) Use class "C" cement for plugs.
(3) Place drilling mud of at least 9lbs./gal. weight.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

DATE

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

RECEIVED

APR 01 1991

U.S.
HOBBS OFFICE

JAY NO. 2
SEC. 24, 26 S, 37 E
LEA COUNTY, NM

T.O. SALT - 1170'
B. SALT - 2510'
Queen - 3465'

8 5/8" CSG @ 1022'
Cemented TO THE SURFACE

T.O. C. - 2510 (EST.)

3516' petts.
3526'

4 1/2" CSG @ 3680' w/400 lb
in 7-7/8" hole
4.3891 ft/ft³ ANNULUS