

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIP DATE
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR Conoco Inc.	8. FARM OR LEASE NAME Eaves A
3. ADDRESS OF OPERATOR P.O. Box 460 - Hobbs, New Mexico 88240	9. WELL NO. 16
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1550' FNL & 2460' FWL - Unit Letter F	10. FIELD AND POOL, OR WILDCAT Scarbrough Yates 7 Rvs
14. PERMIT NO. 30-025-30423	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA 19-26S-37E
15. ELEVATIONS (Show whether DF, RT, GR, etc.)	12. COUNTY OR PARISH Lea
	13. STATE NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. MIRR. G/1H w/ CIBP to 3450'. Circulate hole w/ mud Pull CIBP up hole & set at 2815'. POOH.
2. R/1H w/ dump bailer & CCK & dump 4 sacks class "C" neat cement on top of CIBP at 2850'. POOH & rig up free point tool. Determine free point of 5 1/2" csg. POOH. Rig up csg shot. Shoot csg at free point & POOH. Rig up csg jacks & POOH w/ 2500' of 5 1/2" csg.
3. G/1H & spot 18 sacks class "C" neat cement plug from 50' below to 50' above csg stub. [TAG] Spot 62 sacks class "C" neat cement from 1350' - 1110' to isolate top of salt at 1300' & surface csg shoe at 1160'. Spot 26 sacks of class "C" neat cement from 100' to surface. [TAG]
4. Rig down. Install P & A marker.
For further information contact Brian Horanoff at 397-5873.

18. I hereby certify that the foregoing is true and correct

SIGNED DF FINNEY

TITLE Administrative Supervisor

DATE December 29, 1983

(This space for Federal or State office use)

APPROVED BY CHIEF OF RESOURCES

TITLE

DATE 1-11-89

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side