

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

N.M. Oil & Gas Division  
P.O. Box 1980  
Hobbs, NM 88241

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

**SUBMIT IN TRIPLICATE**

1. Type of Well

☐ Oil Well ☐ Gas Well ☒ Other INJECTION

2. Name of Operator

TEXACO EXPLORATION & PRODUCTION, INC.

3. Address and Telephone No.

P. O. BOX 3109, MIDLAND, TX 79702

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

660' FSL & 660' FWL, SEC. 15, TWN-25S, RANGE 32E

5. Lease Designation and Serial No.  
LC-062300

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

UNIT M

8. Well Name and No.

COTTON DRAW UNIT #1

9. API Well No.

30-025-08182

10. Field and Pool, or Exploratory Area

PUDUCA DELAWARE

11. County or Parish, State

LEA, NEW MEXICO

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ Other \_\_\_\_\_  
☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

- 1) Notify BLM of intent to plug & abandon well.
- 2) Well currently has a C.I.B.P. @ 4594' W/35' of cement.
- 3) MIRU, Nipple up B.O.P., TIH W/workstring to 4559', Circ. wellbore W/25# per bbl salt gel mud.
- 4) Spot 20 sx cement, plug from 4416' - 4316'.
- 5) Cut & pull 4 1/2" csg. @ 1250' & lay down same.
- 6) Spot 45 sx cement, plug from 1300' - 1200'
- 7) Spot 115 sx cement, plug from 403' - 303' (13-3/8" shoe plug)
- 8) Spot 30 sx cement, plug from 30' - surface.
- 9) Nipple down B.O.P. & rig down & cut off wellhead & install dry hole marker
- 10) Clean off location, move off well

14. I hereby certify that the foregoing is true and correct

Signed David W. Neas

Title Reservoir Engineer

Date 3/5/97

(This space for Federal or State office use)

Approved by DAVID R. GLASS

Title PETROLEUM ENGINEER

Date MAR 13 1997

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

\*See Instruction on Reverse Side

FOR  
CONSIDERATION  
APPROVA:

