

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

N OIL CONS. COMMISSION
P.O. BOX 1980
HOBBS, NEW MEXICO 88240

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Texaco E&P, Inc.

3. Address and Telephone No.

P. O. Box 3109 - Midland, TX 79702

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Unit L 2310' FSL; 330' FWL Sec. 22 T-25S R32E

5. Lease Designation and Serial No.
LC-062300

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

Unit L

8. Well Name and No.

Cotton Draw Unit #48

9. API Well No.

30-025-08220

10. Field and Pool, or Exploratory Area

Paduca Delaware

11. County or Parish, State

Lea, NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Notify BLM prior to plugging and abandonment of well.
2. TIH w/ tubing and tag cmt @ 4570'. Circ. well w/ 25# per bbl. salt gel mud.
3. POOH to 4430'. Spot 25 sx cmt plug from 4430' - 4230'. (Btm of salt 4380').
4. Perf. & sqz. casing @ 1180' w/85 sacks cement w/packer @ 1050'. WOC & tag (top of salt 1130').
5. POOH to 800'. Spot 25 sx cement plug from 800' - 700'. (Rustler 750').
6. Perf. @ 400' & circulate cement to surface behind 4 1/2" casing. Leave inside of 4 1/2" casing full of cement from 450' - surface. Should take 100 sacks cement.
7. Nipple down BOP & cut off wellhead; cap well & install dry hole marker. Clean up location & move off.

14. I hereby certify that the foregoing is true and correct

Signed

Title Operations Engineer

Date 5/16/95

(This space for Federal or State office use)

Approved by Shannon J. Shaw

Title PETROLEUM ENGINEER

Date 6/30/95

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side

NOT POSTED

RECEIVED

JUL 06 1985

UCC HOBBS
OFFICE