

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE  
(Other instructions on reverse side)

Form approved.  
Budget Bureau No. 1004-0135  
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	5. LEASE DESIGNATION AND SERIAL NO.
2. NAME OF OPERATOR	6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR	7. UNIT AGREEMENT NAME
Maralo, Inc.	8. FARM OR LEASE NAME
P. O. Box 832, Midland, Texas 79702 0832	Sholes "B"
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface	9. WELL NO.
660' FSL & 1830' FEL of Section 25	1
14. PERMIT NO.	10. FIELD AND POOL OR WILDCAT
15. ELEVATIONS (Show whether DF, RT, GR, etc.)	Jalmat Yates 7 Riv. Tan.
3017 C.T.	11. SEC., T., R., M., OR BLE. AND SURVEY OR AREA
	Sec 25, T-25S, R-36E
	12. COUNTY OR PARISH
	Lea
	13. STATE
	New Mexico

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON\*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

REASON FOR P&A: Well has depleted and there are no other prospective zones.  
INTENT:

1. Notify NMOCC prior to beginning plugging procedure. (and BLM)
2. Set CIBP @ 3000' w/35' cement on top.
3. Load hole with 10#/bal mud-laden fluid using 25# gel/bbl.
4. Set 100' (15sx) plug across top of Yates from 2755' to 2855'.
5. Pull freepoint on 5 1/2" casing. Cut and pull free casing. Spot 100' cement plug across casing cut (50' in and 50' out) [TAG PLUG] 150'
6. Set 100' (15sx) cement plug across 10 3/4" surface casing shoe from 376' to 476'. 87s
7. Using 10 sacks cement, set surface plug.
8. Remove wellhead, cut off casing & weld plate on casing.
9. Clean up location
10. Place a metal dry hole marker at location

RECEIVED

OCT 22 11 15 AM '87

LEAD SOURCE  
HEADQUARTERS

18. I hereby certify that the foregoing is true and correct

SIGNED Brenda Coffman TITLE Agent

DATE 10-19-87

(This space for Federal or State office use)

APPROVED BY  
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

11-17-87

\*See Instructions on Reverse Side