

Orig:2cc: OCC-Hobbs  
cc: Region, File

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

NEW MEXICO OIL CONSERVATION COMMISSION

SEP 3 9 45 AM '65

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- 2. Name of Operator <b>Sinclair Oil &amp; Gas Company</b> 3. Address of Operator <b>P.O. Box 1920, Hobbs, New Mexico</b> 4. Location of Well UNIT LETTER <b>D 24</b> <b>660</b> FEET FROM THE <b>North</b> LINE AND <b>660</b> FEET FROM THE <b>West</b> LINE, SECTION <b>7</b> TOWNSHIP <b>25S</b> RANGE <b>37E</b> N.M.P.M. 15. Elevation (Show whether DF, RT, GR, etc.)	7. Unit Agreement Name 8. Farm or Lease Name <b>W.H. Harrison WH</b> 9. Well No. <b>1</b> 10. Field and Pool, or Wildcat <b>Jalmat (Gas)</b> 12. County <b>Lea</b>
--	--

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

**PROPOSE TO PLUG AND ABANDON WELL AS FOLLOWS:**  
**With hole full of heavy mud - SET CEMENT PLUGS AT:**

**25 sks across perforations (perforated 2870-2910)**  
**25 sks in top of 7" casing stub.**  
**25 sks in bottom of 9-5/8" casing set at 2728'.**  
**10 sks in top of 13-3/8" casing and cellar.**  
**Set regulation dry hole marker.**

**In event any 9-5/8" casing is cut and pulled, set cement plugs as follows:**

**25 sks across perforations (perforated 2870-2910)**  
**25 sks in top of 7" casing stub.**  
**25 sks below salt.**  
**25 sks in top of salt.**  
**10 sks in top of 13-3/8" and cellar.**  
**Set regulation dry hole marker.**

*25 sks in bottom  
of 13 3/8" casing*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE **Superintendent** DATE **Sept. 3, 1965**

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: