

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-11859

5. Indicate Type of Lease  
STATE ☐ FEE ☒

6. State Oil & Gas Lease No.  
NM3-585

7. Lease Name or Unit Agreement Name

Legal

8. Well No. 4

9. Pool name or Wildcat  
Jalmat (Oil) T-Y-SR

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL  
WELL ☒

GAS  
WELL ☐

OTHER

2. Name of Operator

Meridian Oil Inc.

3. Address of Operator

PC Box 51810, Midland TX 79710-1810

4. Well Location

Unit Letter J : 1980 Feet From The S Line and 1915 Feet From The E Line  
Section 31 Township 25S Range 37E NMPM Lea County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

2989 GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Notify OCD prior to starting to work. MIRU PU. ND WH. NU BOP. POOH w/tubing laying down PU workstring and RIH w/ casing scraper to +3000', POOH. Set CIBP on tubing at +2990'. Cap CIBP with 60 sxs of cement. This will cover the base of the salt up to 2640'. Pull above plug and circulate hole w/9 ppg gelled brine.

2. Pull up to 1220' and spot a cement plug across the top of cement at 1160' to 1220'. Use 25 sxs of cement. Pull up to 325' and spot 25 sxs of cement across the surface shoe at 205' to 325'. Pull up to 50' and circulate cement to surface. Lay down workstring. RDMO PU. Cut off casing 3' below ground level and install a P & A marker.

3. Clear, rip, and reseed location

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Donna J. Williams TITLE Production Assistant DATE 1-4-93

TYPE OR PRINT NAME Donna J. Williams

TELEPHONE NO.

(This space for State Use)

ORIGINAL SIGNED BY JERRY SEXTON

DISTRICT I SUPERVISOR

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE JAN - 8 1993

CONDITIONS OF APPROVAL, IF ANY: