

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SAINTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

3-NMOCC-Hobbs 1-CK, Foreman
 1-A.B. Cary-Midland 1-File
 1-R.J. Starrak-Tulsa
 1-JDM-Engr.

Form C-103
 Supersedes Old
 C-102 and C-103
 Effective 1-1-65

5a. Indicate Type of Lease	
State ☒	Fee ☐
5. State Oil & Gas Lease No. B-9613	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO RE-ENTER OR RE-LEASE TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT TO DRILL (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL ☒	GAS WELL ☐	OTHER ☐
--	-----------------------------------	--------------------------------

2. Name of Operator
 GETTY OIL COMPANY

3. Address of Operator
 P.O. Box 730, Hobbs, New Mexico 88240

4. Location of Well
 UNIT LETTER G FEET FROM THE 1980 North LINE AND 1980 FEET FROM
 THE East LINE, SECTION 32 TOWNSHIP 24-S RANGE 38-E NMPM.

7. Unit Agreement Name
 West Dollarhide
 Drinkard Unit
 8. Name of Lease Holder
 West Dollarhide
 Drinkard Unit

9. Well No.
 54

10. Field and Pool, or Wildcat
 Dollarhide Tubb-Drinkard

11. Elevation (Show whether DF, RT, GR, etc.)
 3208' DF

12. County
 Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
 NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☒	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPS. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOB ☐	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Rig up pulling unit.
- Install BOP
- GIH with 4 1/4" swage and swage through collapsed casing at 3559'. Mill, if necessary.
- TOH with swage
- GIH with 2" tubing to 6300' and pump 50 sxs. Class "C" cement
- Pull up to 3900' and set through tubing BP and dump 20 sxs cement on top.
- TOH
- GIH with tension packer to 3400', set and circulate red dye to determine cement volume.
- Circulate cement to surface behind 7" casing
- TOH with tubing
- GIH with BP. Set at 3400'.
- Spot 20 sxs on top of plug
- Pull up to 1 jt from surface and spot 30 sxs and set dry hole marker

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Date R. Crockett TITLE Area Superintendent DATE 6/18/80

APPROVED BY Jerry Sexton TITLE Dist. 1. Supv. DATE JUN 23 1980