

Submit 3 Copies to Appropriate District Office

State of New Mexico Energy, Minerals and Natural Resources Department

Form C-103 Revised 1-1-89

DISTRICT I P.O. Box 1980, Hobbs, NM 88240

OIL CONSERVATION DIVISION P.O. Box 2038 Santa Fe, New Mexico 87504-2088

DISTRICT II P.O. Drawer DD, Artesia, NM 88210

DISTRICT III 1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO. 30-025-12532

5. Indicate Type of Lease STATE [] FEE [XX]

6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

7. Lease Name or Unit Agreement Name

Winningham

1419L

1. Type of Well:

OIL WELL [XX]

GAS WELL []

OTHER []

2. Name of Operator

Meridian Oil Inc.

8. Well No.

5

3. Address of Operator

P.O. Box 51810, Midland TX 79710-1810

9. Pool name or Wildcat

Jalmat T-Y-SR

4. Well Location

Unit Letter J 1980 Feet From The S Line and 1980 Feet From The E Line

Section 30 Township 25S Range 37E NMPM Lea County

10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3021 GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK []

PLUG AND ABANDON [XX]

REMEDIAL WORK []

ALTERING CASING []

TEMPORARILY ABANDON []

CHANGE PLANS []

COMMENCE DRILLING OPNS. []

PLUG AND ABANDONMENT []

PULL OR ALTER CASING []

CASING TEST AND CEMENT JOB []

OTHER: []

OTHER: []

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Notify OCD prior to starting to work. MIRU PU. Kill well if necessary. POOH w/rods laying down. ND WH, NU BOP. POOH w/tubing laying down. Pick up workstring and RIH with casing scraper to +3050', POOH. Set CIBP on tubing at +3040. Spot a cement plug across the base of the salt at 2555' to 3040'. Use 50 sxs of cement. Pull up above plug and circulate hole w/9 ppg gelled brine.

2. Pull up to 1230' and spot a cement plug across the top of the salt at 1110' to 1230' using 15 sxs of cement. Pull up to 370' and circulate cement to surface using 40 sxs of cement. POOH laying down workstring. ND BOP, RDMO PU. Cut off casing 3' below ground level and instal a P & A marker.

3. Clear, rip, and reseed location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE [Signature] TITLE Production Assistant DATE 1-4-93

TYPE OR PRINT NAME Donna J. Williams TELEPHONE NO.

(This space for State Use) ORIGINAL SIGNED BY JERRY SEXTON DISTRICT I SUPERVISOR

APPROVED BY DATE JAN 8 1993

CONDITIONS OF APPROVAL, IF ANY: