

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE*
(Other instructions on reverse side)

Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐	5. LEASE DESIGNATION AND SERIAL NO. NM-14216
2. NAME OF OPERATOR Terra Resources, Inc.	6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR 10 Desta Drive, Suite 500 West, Midland, Texas 79705	7. UNIT AGREEMENT NAME
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below) At surface 1980' FEL & 1980' FSL	8. FARM OR LEASE NAME Wells B
	9. WELL NO. 1
	10. FIELD AND POOL, OR WILDCAT Langlie - Mattix SR-468
	11. SEC., T., R., M., OR BLE. AND SURVEY OR AREA Sec 4 T25S R37E
14. PERMIT NO.	12. COUNTY OR PARISH Lea
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3183 GR	13. STATE NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF	☐	WATER SHUT-OFF	☐
FRACTURE TREAT	☐	FRACTURE TREATMENT	☐
SHOOT OR ACIDIZE	☐	SHOOTING OR ACIDIZING	☐
REPAIR WELL	☐	(Other)	☐
PULL OR ALTER CASING	☐	REPAIRING WELL	☐
MULTIPLE COMPLETE	☐	ALTERING CASING	☐
ABANDON*	☒	ABANDONMENT*	☐
CHANGE PLANE	☐		

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

- 1) Set CIBP @ 3400' & dump (w/bailer) 35' of cmt on it.
- 2) Perforate 5-1/2" csg @ 2400'. Set cmt retainer @ 2300'. Squeeze 35 sx. (100 ft plug in & out of 5-1/2" csg 2300'-2400'). (dump 35' CMT on Retainer) sss
- 3) Perforate 5-1/2" csg @ 1175'. Set cmt retainer @ 1075'. Circulate the 5-1/2" annulus to the surface w/200 sx. (Dump 35' CMT on Retainer) sss
- 4) Cut off csg & spot 10 sx plug @ surface.
- 5) Erect Plug & Abandon" marker.
- 6) Run Salt Gel (9.0 ppg minimum) between CMT plugs; and fresh-water Gel at surface as shown. sss

RECEIVED
JUL 7 11 12 AM '87
CARTER COUNTY RESOURCE
AREA HEADQUARTERS

18. I hereby certify that the foregoing is true and correct

SIGNED

Shirley Cuyler

TITLE

Engineer

DATE

7-2-87

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

7-10-87

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side