

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator EP Operating Company	8. Farm or Lease Name T. G. Bates
3. Address of Operator 6 Desta Drive, Suite 5250, Midland, TX 79705-5510	9. Well No. 1
4. Location of Well UNIT LETTER <u>G</u> , <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>14</u> TOWNSHIP <u>25S</u> RANGE <u>34E</u> NMPM.	10. Field and Pool, or Wildcat Fairview Mills (Atoka)
15. Elevation (Show whether DF, RT, GR, etc.) 3347' GR	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Pump 35 sack cement plug at permanent packer at 14,650'. Tag plug.
Circulate hole with 10# brine at 14,400'.
Spot 25 sack cement plug at 12,563'.
Spot 25 sack cement plug at 9546'.
Spot 25 sack cement plug at 7600'.
Spot 25 sack cement plug at 5665'. Tag plug.
Cut 10-3/4" casing at approximately 2600'. Pull casing out of hole.
Spot 60 sack cement plug 30' inside of 10-3/4" casing stub. Tag plug.
Spot 75 sack cement plug at 897'. Tag plug.
Cut wellhead off 3' below ground level.
Place 10 sack surface plug.
Install dry hole marker.

Anticipated start date 8/22/88.

THE COMMISSION MUST BE NOTIFIED 24
HOURS PRIOR TO THE BEGINNING OF
PLUGGING OPERATIONS FOR THE C-103
TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>S. D. Reed</u>	TITLE <u>Production Superintendent</u>	DATE <u>8/17/88</u>
ORIGINAL SIGNED BY JERRY SEXTON DISTRICT I SUPERVISOR		
APPROVED BY _____	TITLE _____	DATE _____
CONDITIONS OF APPROVAL, IF ANY:		

AUG 18 '88