

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-79

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT - FORM C-101 FOR SUCH PROPOSALS.)

1. ☐ OIL WELL ☒ GAS WELL ☐ OTHER	5a. Indicate Type of Lease State ☐ Fee ☒
2. Name of Operator Phillips Petroleum Company	5. State Oil & Gas Lease No. ---
3. Address of Operator Room 401, 4001 Penbrook Street, Odessa, Texas 79762	7. Unit Agreement Name ---
4. Location of Well UNIT LETTER <u>K</u> <u>1956</u> FEET FROM THE <u>East</u> LINE AND <u>636</u> FEET FROM THE <u>North</u> LINE SECTION <u>26</u> TOWNSHIP <u>T2-4S</u> RANGE <u>36-E</u> N.M.P.M.	8. Farm or Lease Name C. D. Woolworth
	9. Well No. 12
	10. Field and Pool or Wellbore Jalmat Tansill Yates Seven Rivers
11. Elevation (Show whether DF, RT, GR, etc.) 3311.7 GR	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☒	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPNS. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOB ☐	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

NU BOP. BOP eqpt., Ser. 900, 3,000# w/one set pipe rams & one set blind rams. Load hole and spot 100 sxs of 15.6#/gal. Class H cmt. mixed w/1/4#/sx Flocele. Displace cmt w/9.5# mud laden fluid, TOC, neglecting seepage to perforations, will be 2,500'.

Pull tubing to 2,400'.

Displace hole w/90 bbls of 9.5#/gal mud-laden fluid.

Pull tubing to 1,600'.

Spot 100 sxs of 15.6#/gal Class H cmt to cover 9-5/8" csg shoe & top of salt section. Displace plug w/9.5#/gal mud-laden fluid. TOC will be at approximately 1,100'.

Pull tubing to no less than 255' (50' below 12-1/2" shoe).

Spot 50/sx Class H cmt to cover 12-1/2" csg shoe and fill the 7" csg to the surface. Pull and lay down tbg. Fill 7" - 9-5/8" annulus and 9-5/8" - 12-1/2" annulus w/cmt.

Cut off all csg below surface level and weld a 1/2" steel plate on the 12-1/2" csg. Install a steel post (no smaller than 4-1/2" O.D.) to extend 4' above normal ground level. Bead weld on post the following information: C.D. Woolworth #12, NE/4 SW/4, Sec. 26, T-24-S, R-36-E.

Cover top of post with steel plate welded on and set in cement.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. W. Mueller TITLE Senior Engineering Specialist DATE August 7, 1979

Orig. Signed by
John Runyan
Geologist

APPROVED BY _____ TITLE _____ DATE AUG 10 1979

CONDITIONS OF APPROVAL, IF ANY: