

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1

3a. Indicate Type of Lease
State ☐ For ☒
3. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO REDEVELOP A WELL OR TO A DIFFERENT RESERVOIR.
USE APPLICATION FOR PERMIT TO DRILL (FORM C-101) FOR SUCH PROPOSALS.

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐	7. Unit Agreement Name Myers Langlie Mathis Unit
2. Name of Operator Texaco Producing Inc.	8. Farm or Lease Name
3. Address of Operator PO Box 728 Hobbs, New Mexico 88240	9. Well No. 199
4. Location of Well UNIT LETTER B' 660 FEET FROM THE North LINE AND 880 FEET FROM THE East LINE, SECTION 8 TOWNSHIP 24S RANGE 37 E	10. Field and Pool, or Whichever Langlie Mathis SR
11. Elevation (Show whether D.F., R.T., C.R., etc.) D.F. 3297	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPER. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐

ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Purpose and Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work, SEE RULE 13).

1. MTRU pulling unit and install BOP.
 2. TTH with workstring to 3295' and circulate 9.5 lb per gallon mud.
 3. TOH with workstring.
 4. Perforate 5 1/2" casing at 1200' with 2 holes using 1 9/16" decentralized guns.
 5. TTH with workstring and 5 1/2" cement retainer to 1125' and set retainer.
 6. Establish circulation between 5 1/2" and 8 5/8" casing using water.
 7. Circulate cement to surface between 5 1/2" and 8 5/8" casings. (Use class H cement (15.6 ppg, 1.18 cu ft/sk).
 8. Sting out of retainer and spot 20' of class H cement on top of retainer.
 9. Pull up and spot a 100' class H cement plug from 236'-336'.
 10. Pull up and spot a 10' plug of class H cement at the surface.
 11. Install a dry hole marker.
- Plug and Abandon.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED

K. J. Johnson

TITLE

Area Supt.

DATE

2-12-87

ORIGINAL SIGNED BY JERRY SEXTON

APPROVED BY

DISTRICT SUPERVISOR

TITLE

DATE

FEB 16 1987

RECEIVED
FEB 16 1987
OCE
HOBBS OFFICE