## PECOS DISTRICT SURFACE USE CONDITIONS OF APPROVAL

OPERATOR'S NAME:	Chisolm Energy Operating LLC
LEASE NO.:	NMNM032860
WELL NAME & NO.:	Buffalo 12-1 Fed Com WCC 6H
SURFACE HOLE FOOTAGE:	125'/S & 1260'/W
BOTTOM HOLE FOOTAGE	330'/N & 1270'/W
LOCATION:	Section 12, T.19 S., R.33 E., NMPM
COUNTY:	Lea County, New Mexico

## **TABLE OF CONTENTS**

Standard Conditions of Approval (COA) apply to this APD. If any deviations to these standards exist or special COAs are required, the section with the deviation or requirement will be checked below.

<ul> <li>General Provisions</li> <li>Permit Expiration</li> <li>Archaeology, Paleontology, and Historical Sites</li> </ul>
Noxious weeds
Watershed
Lesser Prairie-Chicken Timing Stipulations
Ground-level Abandoned Well Marker
Cultural
Notification
Topsoil
Closed Loop System
Federal Mineral Material Pits
Well Pads
Roads
Road Section Diagram
Production (Post Drilling)
Well Structures & Facilities
Interim Reclamation

Final Abandonment & Reclamation

# **Engineer Worksheet**

## Carlsbad Field Office

620 E. Greene St. Carlsbad, NM 88220-6292

Tracking	ATC 14	1200		<u></u>		Leo		
Number	A15-18	5-1309		County:				
Company:	Chishol	m Energy Operating I	LC	Well Na	me and Number:	BUFFALO 12-1 FED COM WCC-6H		
Location:	125'/S.a	& 1260'/W. SEC012 T	019S, R033E	Bottom	Hole Location:	330'/N.& 12	70'/W. SEC001 T019S, R033E	
Lease Number:	NMNN	1032860	Prod Status:			Effective:		
Bond:	Statewide		Bond #:	NMB00	1468	Potash:	No	
NOS Received:	NO		APD Received:	2-7-201	8	10-Day LTR Sent:		
Acreage:			Orthodox:	No		COM Agr Required:	Yes	
Deficiencies Note	ed:							
Form 3160	-3	Survey Plat	Drilling Plan	Surface Plan	Bonding	Original	Signature Operator Cert Statement	
Other Deficiencie	s:							
Adjudication Comments:								
GEO Report Completed	6-21-20	18	-					
			Te	echnical Che	cklist			
Plat:	ok		Elevation: 3710					
Proposed Depth:	TVD:	10990	MD: 21598			Targeted Formation:	Wolfcamp	
Anticipated Wate Gas, Etc.:	r-Oil,	Expected fresh water Wolfcamp.	above 102 ft /Oil and	gas: Yates, Seven	Rivers, Queen, Gr	ayburg, Sand A	Andres, Glorieta, Yeso, Bone Spring, and	
Casing/Cement P	rogram:	See COA for depth c	hanges /See COA for c	ement deficiencie	S			
Bottom Hole Mud Weight	11.5	<u></u>	BHP: 6572.02	MASP:	4154.22	-		
			Horizontal	Directional	Vertical R	e-entry		
Well Control Prog	g(BOP,	5M multibowl BOP/	Flex hose	Mud Pro	ogram:	Ok		
Test-Log-Cores P	rogram:	CBL,DS,GR,MWD				· · · · · ·	-	
H2S or Other Haz	zards:	H2S yes. Possibility Beds, Artesia Group,	of water flows in the A Capitan Reef, and Del	rtesia Group, Sala aware	do, and Capitan R	eef. Possibility	of lost circulation in the Rustler, Red	
Water Basin:	Capitan							
Casings to Witness:			✓ Surface	Intermediate	Production	CIT Req	uired	
		Other Witnes	s			_		
Comments:						-		
1								
Sanchez		8-15-2018						
Engineer		Date	Siganture		Adjudication Da	ate	Adjudicator Initials	

## I. GENERAL PROVISIONS

The approval of the Application For Permit To Drill (APD) is in compliance with all applicable laws and regulations: 43 Code of Federal Regulations 3160, the lease terms, Onshore Oil and Gas Orders, Notices To Lessees, New Mexico Oil Conservation Division (NMOCD) Rules, National Historical Preservation Act As Amended, and instructions and orders of the Authorized Officer. Any request for a variance shall be submitted to the Authorized Officer on Form 3160-5, Sundry Notices and Report on Wells.

## **II. PERMIT EXPIRATION**

If the permit terminates prior to drilling and drilling cannot be commenced within 60 days after expiration, an operator is required to submit Form 3160-5, Sundry Notices and Reports on Wells, requesting surface reclamation requirements for any surface disturbance. However, if the operator will be able to initiate drilling within 60 days after the expiration of the permit, the operator must have set the conductor pipe in order to allow for an extension of 60 days beyond the expiration date of the APD. (Filing of a Sundry Notice is required for this 60 day extension.)

## **III. ARCHAEOLOGICAL, PALEONTOLOGY & HISTORICAL SITES**

Any cultural and/or paleontological resource discovered by the operator or by any person working on the operator's behalf shall immediately report such findings to the Authorized Officer. The operator is fully accountable for the actions of their contractors and subcontractors. The operator shall suspend all operations in the immediate area of such discovery until written authorization to proceed is issued by the Authorized Officer. An evaluation of the discovery shall be made by the Authorized Officer to determine the appropriate actions that shall be required to prevent the loss of significant cultural or scientific values of the discovery. The operator shall be held responsible for the cost of the proper mitigation measures that the Authorized Officer assesses after consultation with the operator on the evaluation and decisions of the discovery. Any unauthorized collection or disturbance of cultural or paleontological resources may result in a shutdown order by the Authorized Officer.

## **IV. NOXIOUS WEEDS**

The operator shall be held responsible if noxious weeds become established within the areas of operations. Weed control shall be required on the disturbed land where noxious weeds exist, which includes the roads, pads, associated pipeline corridor, and adjacent land affected by the establishment of weeds due to this action. The operator shall consult with the Authorized Officer for

Page 2 of 12

acceptable weed control methods, which include following EPA and BLM requirements and policies.

## V. SPECIAL REQUIREMENT(S)

## Watershed

Surface disturbance will not be allowed (within x feet of drainage; or describe pad restriction).

The entire well pad will be bermed to prevent oil, salt, and other chemical contaminants from leaving the well pad. Topsoil shall not be used to construct the berm. No water flow from the uphill side(s) of the pad shall be allowed to enter the well pad. The berm shall be maintained through the life of the well and after interim reclamation has been completed.

Any water erosion that may occur due to the construction of the well pad during the life of the well will be quickly corrected and proper measures will be taken to prevent future erosion.

Stockpiling of topsoil is required. The top soil shall be stockpiled in an appropriate location to prevent loss of soil due to water or wind erosion and not used for berming or erosion control.

## <u>Timing Limitation Stipulation / Condition of Approval for lesser prairie-</u> <u>chicken</u>:

Oil and gas activities including 3-D geophysical exploration, and drilling will not be allowed in lesser prairie-chicken habitat during the period from March 1st through June 15th annually. During that period, other activities that produce noise or involve human activity, such as the maintenance of oil and gas facilities, pipeline, road, and well pad construction, will be allowed except between 3:00 am and 9:00 am. The 3:00 am to 9:00 am restriction will not apply to normal, around-the-clock operations, such as venting, flaring, or pumping, which do not require a human presence during this period. Additionally, no new drilling will be allowed within up to 200 meters of leks known at the time of permitting. Normal vehicle use on existing roads will not be restricted. Exhaust noise from pump jack engines must be muffled or otherwise controlled so as not to exceed 75 db measured at 30 feet from the source of the noise.

## Timing Limitation Exceptions:

The Carlsbad Field Office will publish an annual map of where the LPC timing and noise stipulations and conditions of approval (Limitations) will apply for the identified year (between March 1 and June 15) based on the latest survey information. The LPC Timing Area map will identify areas which are Habitat Areas (HA), Isolated Population Area (IPA), and Primary Population Area (PPA). The LPC Timing Area map will also have an area in red crosshatch. The red crosshatch area is the only area where an operator is required to submit a request for exception to the LPC Limitations. If an operator is operating outside

Page 3 of 12

the red crosshatch area, the LPC Limitations do not apply for that year and an exception to LPC Limitations is not required.

**Ground-level Abandoned Well Marker to avoid raptor perching**: Upon the plugging and subsequent abandonment of the well, the well marker will be installed at ground level on a plate containing the pertinent information for the plugged well. For more installation details, contact the Carlsbad Field Office at 575-234-5972.

## VI. CONSTRUCTION

## A. NOTIFICATION

The BLM shall administer compliance and monitor construction of the access road and well pad. Notify the Carlsbad Field Office at (575) 234-5909 at least 3 working days prior to commencing construction of the access road and/or well pad.

When construction operations are being conducted on this well, the operator shall have the approved APD and Conditions of Approval (COA) on the well site and they shall be made available upon request by the Authorized Officer.

## B. TOPSOIL

The operator shall strip the top portion of the soil (root zone) from the entire well pad area and stockpile the topsoil along the edge of the well pad as depicted in the APD. The root zone is typically six (6) inches in depth. All the stockpiled topsoil will be redistributed over the interim reclamation areas. Topsoil shall not be used for berming the pad or facilities. For final reclamation, the topsoil shall be spread over the entire pad area for seeding preparation.

Other subsoil (below six inches) stockpiles must be completely segregated from the topsoil stockpile. Large rocks or subsoil clods (not evident in the surrounding terrain) must be buried within the approved area for interim and final reclamation.

## C. CLOSED LOOP SYSTEM

Tanks are required for drilling operations: No Pits.

The operator shall properly dispose of drilling contents at an authorized disposal site.

## D. FEDERAL MINERAL MATERIALS PIT

Payment shall be made to the BLM prior to removal of any federal mineral materials. Call the Carlsbad Field Office at (575) 234-5972.

Page 4 of 12

## E. WELL PAD SURFACING

Surfacing of the well pad is not required.

If the operator elects to surface the well pad, the surfacing material may be required to be removed at the time of reclamation. The well pad shall be constructed in a manner which creates the smallest possible surface disturbance, consistent with safety and operational needs.

## F. EXCLOSURE FENCING (CELLARS & PITS)

## **Exclosure Fencing**

The operator will install and maintain exclosure fencing for all open well cellars to prevent access to public, livestock, and large forms of wildlife before and after drilling operations until the pit is free of fluids and the operator initiates backfilling. (For examples of exclosure fencing design, refer to BLM's Oil and Gas Gold Book, Exclosure Fence Illustrations, Figure 1, Page 18.)

## G. ON LEASE ACCESS ROADS

## **Road Width**

The access road shall have a driving surface that creates the smallest possible surface disturbance and does not exceed fourteen (14) feet in width. The maximum width of surface disturbance, when constructing the access road, shall not exceed twenty-five (25) feet.

## Surfacing

Surfacing material is not required on the new access road driving surface. If the operator elects to surface the new access road or pad, the surfacing material may be required to be removed at the time of reclamation.

Where possible, no improvements should be made on the unsurfaced access road other than to remove vegetation as necessary, road irregularities, safety issues, or to fill low areas that may sustain standing water.

The Authorized Officer reserves the right to require surfacing of any portion of the access road at any time deemed necessary. Surfacing may be required in the event the road deteriorates, erodes, road traffic increases, or it is determined to be beneficial for future field development. The surfacing depth and type of material will be determined at the time of notification.

## Crowning

Crowning shall be done on the access road driving surface. The road crown shall have a grade of approximately 2% (i.e., a 1" crown on a 14' wide road). The road shall conform to Figure 1; cross section and plans for typical road construction.

Page 5 of 12

### Ditching

Ditching shall be required on both sides of the road.

#### Turnouts

Vehicle turnouts shall be constructed on the road. Turnouts shall be intervisible with interval spacing distance less than 1000 feet. Turnouts shall conform to Figure 1; cross section and plans for typical road construction.

#### Drainage

Drainage control systems shall be constructed on the entire length of road (e.g. ditches, sidehill outsloping and insloping, lead-off ditches, culvert installation, and low water crossings).

A typical lead-off ditch has a minimum depth of 1 foot below and a berm of 6 inches above natural ground level. The berm shall be on the down-slope side of the lead-off ditch.



All lead-off ditches shall be graded to drain water with a 1 percent minimum to 3 percent maximum ditch slope. The spacing interval are variable for lead-off ditches and shall be determined according to the formula for spacing intervals of lead-off ditches, but may be amended depending upon existing soil types and centerline road slope (in %);

#### Formula for Spacing Interval of Lead-off Ditches

Example - On a 4% road slope that is 400 feet long, the water flow shall drain water into a lead-off ditch. Spacing interval shall be determined by the following formula:

400 foot road with 4% road slope: 400' + 100' = 200' lead-off ditch interval 4%

#### **Cattle guards**

Side

An appropriately sized cattle guard sufficient to carry out the project shall be installed and maintained at fence/road crossings. Any existing cattle guards on the access road route shall be repaired or replaced if they are damaged or have

Page 6 of 12

deteriorated beyond practical use. The operator shall be responsible for the condition of the existing cattle guards that are in place and are utilized during lease operations.

### Fence Requirement

Where entry is granted across a fence line, the fence shall be braced and tied off on both sides of the passageway prior to cutting. The operator shall notify the private surface landowner or the grazing allotment holder prior to crossing any fences.

### **Public Access**

Public access on this road shall not be restricted by the operator without specific written approval granted by the Authorized Officer.

Page 7 of 12



Figure 1. Cross-sections and plans for typical road sections representative of BLM resource or FS local and higher-class roads.

Page 8 of 12

## **VII. PRODUCTION (POST DRILLING)**

## A. WELL STRUCTURES & FACILITIES

## **Placement of Production Facilities**

Production facilities should be placed on the well pad to allow for maximum interim recontouring and revegetation of the well location.

## **Exclosure Netting (Open-top Tanks)**

Immediately following active drilling or completion operations, the operator will take actions necessary to prevent wildlife and livestock access, including avian wildlife, to all open-topped tanks that contain or have the potential to contain salinity sufficient to cause harm to wildlife or livestock, hydrocarbons, or Resource Conservation and Recovery Act of 1976-exempt hazardous substances. At a minimum, the operator will net, screen, or cover open-topped tanks to exclude wildlife and livestock and prevent mortality. If the operator uses netting, the operator will cover and secure the open portion of the tank to prevent wildlife entry. The operator will net, screen, or cover the tanks until the operator removes the tanks from the location or the tanks no longer contain substances that could be harmful to wildlife or livestock. Use a maximum netting mesh size of 1  $\frac{1}{2}$  inches. The netting must not be in contact with fluids and must not have holes or gaps.

## **Chemical and Fuel Secondary Containment and Enclosure Screening**

The operator will prevent all hazardous, poisonous, flammable, and toxic substances from coming into contact with soil and water. At a minimum, the operator will install and maintain an impervious secondary containment system for any tank or barrel containing hazardous, poisonous, flammable, or toxic substances sufficient to contain the contents of the tank or barrel and any drips, leaks, and anticipated precipitation. The operator will dispose of fluids within the containment system that do not meet applicable state or U. S. Environmental Protection Agency livestock water standards in accordance with state law; the operator must not drain the fluids to the soil or ground. The operator will design, construct, and maintain all secondary containment systems to prevent wildlife and livestock exclosure systems such as fencing, netting, expanded metal mesh, lids, and grate covers. <u>Use a maximum netting mesh size of 1 ½ inches.</u>

## **Open-Vent Exhaust Stack Enclosures**

The operator will construct, modify, equip, and maintain all open-vent exhaust stacks on production equipment to prevent birds and bats from entering, and to discourage perching, roosting, and nesting. (*Recommended exclosure structures on open-vent exhaust stacks are in the shape of a cone.*) Production

Page 9 of 12

equipment includes, but may not be limited to, tanks, heater-treaters, separators, dehydrators, flare stacks, in-line units, and compressor mufflers.

## **Containment Structures**

Proposed production facilities such as storage tanks and other vessels will have a secondary containment structure that is constructed to hold the capacity of 1.5 times the largest tank, plus freeboard to account for precipitation, unless more stringent protective requirements are deemed necessary.

## **Painting Requirement**

All above-ground structures including meter housing that are not subject to safety requirements shall be painted a flat non-reflective paint color, **Shale Green** from the BLM Standard Environmental Color Chart (CC-001: June 2008).

## VIII. INTERIM RECLAMATION

During the life of the development, all disturbed areas not needed for active support of production operations should undergo interim reclamation in order to minimize the environmental impacts of development on other resources and uses.

Within six (6) months of well completion, operators should work with BLM surface management specialists (Jim Amos: 575-234-5909) to devise the best strategies to reduce the size of the location. Interim reclamation should allow for remedial well operations, as well as safe and efficient removal of oil and gas.

During reclamation, the removal of caliche is important to increasing the success of revegetating the site. Removed caliche that is free of contaminants may be used for road repairs, fire walls or for building other roads and locations. In order to operate the well or complete workover operations, it may be necessary to drive, park and operate on restored interim vegetation within the previously disturbed area. Disturbing revegetated areas for production or workover operations will be allowed. If there is significant disturbance and loss of vegetation, the area will need to be revegetated. Communicate with the appropriate BLM office for any exceptions/exemptions if needed.

All disturbed areas after they have been satisfactorily prepared need to be reseeded with the seed mixture provided below.

Upon completion of interim reclamation, the operator shall submit a Sundry Notices and Reports on Wells, Subsequent Report of Reclamation (Form 3160-5).

Page 10 of 12

## IX. FINAL ABANDONMENT & RECLAMATION

At final abandonment, well locations, production facilities, and access roads must undergo "final" reclamation so that the character and productivity of the land are restored.

Earthwork for final reclamation must be completed within six (6) months of well plugging. All pads, pits, facility locations and roads must be reclaimed to a satisfactory revegetated, safe, and stable condition, unless an agreement is made with the landowner or BLM to keep the road and/or pad intact.

After all disturbed areas have been satisfactorily prepared, these areas need to be revegetated with the seed mixture provided below. Seeding should be accomplished by drilling on the contour whenever practical or by other approved methods. Seeding may need to be repeated until revegetation is successful, as determined by the BLM.

Operators shall contact a BLM surface protection specialist prior to surface abandonment operations for site specific objectives (Jim Amos: 575-234-5909).

Ground-level Abandoned Well Marker to avoid raptor perching: Upon the plugging and subsequent abandonment of the well, the well marker will be installed at ground level on a plate containing the pertinent information for the plugged well.

## Seed Mixture for LPC Sand/Shinnery Sites

Holder shall seed all disturbed areas with the seed mixture listed below. The seed mixture shall be planted in the amounts specified in pounds of pure live seed (PLS)\* per acre. There shall be <u>no</u> primary or secondary noxious weeds in the seed mixture. Seed will be tested and the viability testing of seed shall be done in accordance with State law(s) and within nine (9) months prior to purchase. Commercial seed shall be either certified or registered seed. The seed container shall be tagged in accordance with State law(s) and available for inspection by the Authorized Officer.

Seed will be planted using a drill equipped with a depth regulator to ensure proper depth of planting where drilling is possible. The seed mixture will be evenly and uniformly planted over the disturbed area (smaller/heavier seeds have a tendency to drop the bottom of the drill and are planted first). Holder shall take appropriate measures to ensure this does not occur. Where drilling is not possible, seed will be broadcast and the area shall be raked or chained to cover the seed. When broadcasting the seed, the pounds per acre are to be doubled. Seeding shall be repeated until a satisfactory stand is established as determined by the Authorized Officer. Evaluation of growth may not be made before completion of at least one full growing season after seeding.

Species to be planted in pounds of pure live seed\* per acre:

<u>Species</u>	<u>lb/acre</u>
Plains Bristlegrass	5lbs/A
Sand Bluestem	5lbs/A
Little Bluestem	3lbs/A
Big Bluestem	6lbs/A
Plains Coreopsis	2lbs/A
Sand Dropseed	1lbs/A

\*Pounds of pure live seed:

Pounds of seed **x** percent purity **x** percent germination = pounds pure live seed

Page 12 of 12



#### U.S. Department of the Interior BUREAU OF LAND MANAGEMENT



## **Operator Certification**

I hereby certify that I, or someone under my direct supervision, have inspected the drill site and access route proposed herein; that I am familiar with the conditions which currently exist; that I have full knowledge of state and Federal laws applicable to this operation; that the statements made in this APD package are, to the best of my knowledge, true and correct; and that the work associated with the operations proposed herein will be performed in conformity with this APD package and the terms and conditions under which it is approved. I also certify that I, or the company I represent, am responsible for the operations conducted under this application. These statements are subject to the provisions of 18 U.S.C. 1001 for the filing of false statements.

NAME: Jennifer Elrod

Title: Senior Regulatory Technician

Street Address: 801 CHERRY STREET, SUITE 1200-UNIT 20

State:

City: Fort Worth

State: TX

Zip: 76102

Zip:

Signed on: 01/31/2018

Phone: (817)953-3728

Email address: jelrod@chisholmenergy.com

**Field Representative** 

Representative Name:

Street Address:

City:

Phone:

Email address:

## Chisholm Energy Operating, LLC

801 Cherry St., Suite 1200-Unit 20 Fort Worth, TX 76102

H2S Contingency Plan Lea County, NM

Casing Program: Minis (13 3/8" x 9 5/8" x 5 1/2")

nsion dy SF 1.8)		0.43		. 97		.92
ght Te Bo (;		Ť c		2 0,		0
Air Weig (Ibs)		81,75(		212,00		219,80
Tension Body (klbs)		853,000		630,000		641,000
Tension Jaint SF (1.8)		11.12		2.45		3.03
Air Weight (Ibs)		81,750		212,000		219,800
Tension Joint (klbs)		000'606		520,000		667,000
Collapse SF (1.125)		1.72		1.37		2.04
Coltapse (psi)		1130		2570		11100
Burst SF (1.125)		4.17		1.41		2.33
Burst (psi)		0672		3950		12630
Anticipated Mud Weight (ppg)		8.4		10.2		9.5
Condition		New		New		New
Thread		8TC		LTC		BTC
Casing Grade		J-55		J-55		P110
Casing Weight (Ib/ft)		54.5		40		20
Casing Size (inches)		"8/E ET		9 5/8"		5 1/2"
Casing Setting Depth (ft) TVD		1,500'		5,300'		10,990'
Casing Setting Depth (ft) MD		1,500'		5,300'		21,598'
Casing Depth; From (ft)		,0		,0		.0
Open Hote Size (Inches)	Surface	17.5"	Intermediate	12.25"	Production	8.75"

Casing Design Criteria and Casing Loading Assumptions: Surface		
Tension A 1.8 design factor with effects of buoyancy with a fluid equal to a mud weight of:	8.4 ppg	
Collapse A 1.125 design factor with full internal evacuation and collapse force equal to a mud gradient of:	8.4 ppg	
Burst A 1.125 design factor with full external evacuation and burst force equal to a mud gradient of:	8.4 ppg	
Intermediate		
Tension A 1.8 design factor with effects of buoyancy with a fluid equal to a mud weight of:	10.2 ppg	
Collapse A 1.125 design factor with 1/3 TVD internal evacuation and collapse force equal to a mud gradient of:	10.2 ppg	
Burst A 1.125 design factor with full external evacuation and burst force equal to a mud gradient of:	10.2 ppg	
Production		
Tension A 1.8 design factor with effects of buoyancy with a fluid equal to a mud weight of:	9.5 ppg	
Collapse A 1.125 design factor with full internal evacuation and collapse force equai to a mud gradient of:	9.5 ppg	
Burst A 1.125 design factor with full external evacuation and burst force equal to a mud gradient of:	9.5 ppg	

### Escape

Crews shall escape upwind of escaping gas in the event of an emergency release of gas. Escape can be facilitated from the location entrance road. Crew should then block entrance to the location from the lease road so as not to allow anyone traversing into a hazardous area. The blockade should be at a safe distance outside of the ROE. <u>There are NO homes or buildings in or near the ROE</u>.

## Assumed 100 ppm ROE = 3000' 100 ppm H2S concentration shall trigger activation of this plan

#### **Emergency Procedures**

In the event of a release of gas containing H2S, the first responder(s) must:

- « Isolate the area and prevent entry by other persons into the 100 ppm ROE.
- « Evacuate any public places encompassed by the 100 ppm ROE.
- « Be equipped with H2S monitors and air packs in order to control the release.
- « Use the "buddy system" to ensure no injuries occur during the response.
- « Take precautions to avoid personal injury during this operation.
- « Contact operator and/or local officials to aid in operation. See list of phone numbers attached. « Have received training
  - in the: Detection of

H2S, and

Measures for protection against the gas,

Equipment used for protection and emergency response.

### **Ignition of Gas Source**

Should control of the well be considered lost and ignition considered, take care to protect against exposure to Sulfur Dioxide (S02). Intentional ignition must be coordinated with the NMOCD and local officials. Additionally, the NM State Police may become involved. NM State Police shall be the Incident Command on scene of any major release. Take care to protect downwind whenever there is an ignition of the gas.

#### Characteristics of H2S and SO,

Common Name	Chemical Formula	Specific Gravity	Threshold Limit	Hazardous Limit	Lethal Concentration
Hydrogen Sulfide	H2S	1.189 Air=1	10 ppm	100 ppm/hr	600 ppm
Sulfur Dioxide	SO2	2.21 Air=1	2 ppm	N/A	1000 ppm

## **Contacting Authorities**

Chisholm Energy Operating personnel must liaise with local and state agencies to ensure **a** proper response to a major release. Additionally, the OCD must be notified of the release as soon **as** possible but no later than 4 hours. Agencies will ask for information such as type and volume of release, wind direction, location of release, etc. Be prepared with all information available including directions to sit e. The following call list of essential and potential responders has been prepared for use during a release. Chisholm Energy Operating, LLC response must be in coordination with the State of New Mexico's "Hazardous Materials Emergency Response Plan" (HMERP).

## Hydrogen Sulfide Drilling Operations Plan

- 1. <u>All Company and Contract personnel admitted on location must be trained by a qualified H2S safety instructor to the following:</u>
  - A. Characteristics of H2S
  - B. Physical effects and hazards
  - C. Principal and operation of H2S detectors, warning system and briefing areas.
  - D. Evacuation procedure, routes and first aid.
  - E. Proper use of safety equipment & life support systems
  - F. Essential personnel meeting Medical Evaluation criteria will receive additional training on the proper use of 30-minute pressure demand air packs.

## 2. H2S Detection and Alarm Systems:

- a. H2S sensors/detectors to be located on the drilling rig floor, in the base of the sub structure/cellar area, on the mud pits in the shale shaker area. Additional H2S detectors may play placed as deemed necessary.
- b. An audio alarm system will be installed on the derrick floor and in the top doghouse.

## 3. Windsock and/or wind streamers:

- a. Windsock at mudpit area should be high enough to be visible.
- b. Windsock on the rig floor and/ or top doghouse should be high enough to be visible.

## 4. <u>Condition Flags and Signs</u>

- a. Warning sign on access road to location.
- Flags to be displayed on sign at entrance to location. Green flag indicates normal safe condition. Yellow flag indicates potential pressure and danger. Red flag indicates danger (H2S present in dangerous concentration). Only H2S trained and certified personnel

admitted to location.

- 5. <u>Well control equipment</u>:
  - a. See exhibit BOP and Choke Diagrams

#### 6. <u>Communication</u>:

- a. While working under masks chalkboards will be used for communication.
- b. Hand signals will be used where chalk board is inappropriate.
- c. Two-way radio will be used to communicate off location in case of emergency help is required. In most cases, cellular telephones will be available at most drilling foreman's trailer or living quarters.

#### Drill stem Testing:

No DSTs are planned at this time.

- 8. Drilling contractor supervisor will be required to be familiar with the effects H2S has on tubular goods and other mechanical equipment.
- If H25 is encountered, mud system will be altered if necessary to maintain control of formation. A mud gas separator will be brought into service along with H2S scavengers if necessary.

#### **Emergency Assistance Telephone List**

Chisholm Energy Holdings, LLC		
Chisholm Energy Operating, LLC	Office:	(817)953-6063
Vice President of Operations-Brad Grandstaff	Office:	(817)953-3150
	Cell:	(972)977-9221
Drilling Superintendent-Russell Simons	Cell:	(830)285-7501
Production Superintendent-Paul Martinez	Cell:	(325)206-1722

Public Safety:			<u>911 or_</u>					
Lea County Sheriff's Department		Number:	(575)396-3611					
Lea County Emergency Manageme	(575)391-2983							
Lea County Fire Marshal								
Lorenzo Velasquez, Directo	or	Number:	(575)391-2983					
Jeff Broom, Deputy Fire Ma	Jeff Broom, Deputy Fire Marshal Number:							
Fire Department:								
Knowles Fire Department		Number:	(505)392-2810					
City of Hobbs Fire Departmer	nt	Number:	(505)397-9308					
Jal Volunteer Fire Departmen	it	Number:	(505)395-2221					
Lovington Fire Department		Number:	(575)396-2359					
Maljamar Fire Department		Number:	(505)676-4100					
Tatum Volunteer Fire Depart	ment	Number:	(505)398-3473					
Eunice Fire Department		Number:	(575)394-3258					
Hospital: Lea Regional Medical Cente	r	Number:	(575)492-5000					
AirMed: Medevac		Number:	(888)303-9112					
Dept. of Public Safety		Number:						
New Mexico OCD-Dist. 1-Hobbs-	Office	Number:	(575)393-6161					
	Emergency	Number:	(575)370-3186					
Lea County Road Department		Number:	(575)391-2940					
NMDOT		Number:	(505)827-5100					

e ,

# **Chisholm Energy Holdings, LLC**

Lea County, NM (NAD83) Sec 12-T19S-R33E Buffalo 12-1 Fed Com WCC 6H

Wellbore #1

Plan: Plan #1

# **Standard Planning Report**

11 January, 2018





understation and states of a sec	911 - 1. 1. T. MARINA	د <del>اد</del> ا بر معصفته						a statute stats	anda anatan Kata a	energian antier a commu		
Database:	EDM 50	000.1				Local Co	-ordinate Refe	erence:	Well Buffalo	12-1 Fed Con	n WCC 6H	, an inn i na i na i 1
Company:	Chishol	m Energy I	Holdings,	LLC		TVD Refe	erence:		KB=26 @ 3	736.30ft (Lats)	1aw 17)	÷
Project:	Lea County, NM (NAD83)					MD Refe	rence:		KB=26 @ 3	736.30ft (Latsh	naw 17)	
Site:	Sec 12-T19S-R33E					North Re	ference:		Grid			1
Well:	Buffalo	12-1 Fed (	Com WCC	6H		Survey C	alculation Me	thod:	Minimum C	urvature		1
Wellbore:	Weilbor	e #1				:						
Design:	Plan #1		هما دية منتقد	ساد هابندید د		1 Miles and the second				فتطريقها مسروكاته وراري والرقيب		
Project	Lea Cou	nty, NM (N	AD83)				· · · · · · ·					
Map System:	US State	Plane 1983	3			System Da	atum:		Mean Sea Lev	/el		
Geo Datum:	North Ame	erican Datu	m 1983									
Map Zone:	New Mexi	co Eastern	Zone								,	
Site	Sec 12-1	[195-R33E					·····	· · · · · · · · · · · · · · · · · · ·				
Site Position:				Northing:		607,2	285.4100 usft	Latitude:				32.667475
From:	Мар			Easting:		759,2	263.6300 usft	Longitude:				-103.625148
Position Uncertainty	r:		0.00 ft	Slot Radi	us:		13-3/16 "	Grid Conve	ergence:	•		0.38 °
Well	Buffalo 1	2-1 Fed Co	om WCC (	3H		······································						
Well Position	+N/-S		129.97 ft	North	ing:		607,415.380	0 usft L	atitude:			32.667809
	+E/-W	1	259.29 ft	Eastin	ig:		760,522.920	0 usft L	.ongitude:			-103.621053
Position Uncertainty	,		0.00 ft	Wellh	ead Eleva	tion:	c	0.00 ft 🖸	Fround Level:			3,710.30 ft
Wellbore	Wellbor	e #1										
				Comple D		Dealin				 E)/		
Magnetics	MOG	ei name		Sample Da	ste	Cecim	)		(°)	FR	nt Strength (nT)	
		HDG	M	1/1	1/2018	······	6.77		60.6	7	4	8,331
Design	Plan #1											
Audit Notes:												
Version:				Phase:	ſ	PLAN	Ti	ie On Depth:		0.00		
Vertical Section:			Depth F	rom (TVD) (ft)		+N/-S (ft)	+	E/-W (ft)		Direction (°)		an annan ammana ba ann an an
			C	).00		0.00		0.00		359.80		·
Plan Sections				· · · · ·		* . * . * . * . * . * . *	<b>n n</b> - m					
Messurad			Verti	cat			Dogleg	Build	Turn			
Depth Incl	ination	Azimuth	Dep	th ·	+N/-S	+E/-W	Rate	Rate	Rate	TFO		
(ft)	(°)	(°)	(ft	)	(ft)	(ft)	(°/100usft)	(°/100usft	) (°/100usft	) (°)		Target
0.00	0.00	0.0	0	0.00	0.00	0.00	0.00	0.0	00 0.	00 0	.00	·
10,367.91	0.00	0.0	0 10,3	67.91	0.00	0.00	0.00	0.0	00 0.	00 0	.00	

10,979.58

11,079.58

11,827.98

21,598.52

270.00

270.00

359.80

359.80

73.40

73.40

90.00

90.00

10,825.48

10,854.05

10,990.00

10,990.00

0.00

0.00

475.87

10,246.35

-341.06

-436.89

-894.59

-928.46

12.00

0.00

12.00

0.00

12.00

0.00

2.22

0.00

0.00

0.00

12.00

0.00

270.00

0.00

89.94

90.99 PBHL Buffalo 12-1 Fe

Database:	EDM 5000.1	Local Co-ordinate Reference:	Well Buffalo 12-1 Fed Com WCC 6H	<b>ب</b> ۱
Company:	Chisholm Energy Holdings, LLC	TVD Reference:	KB=26 @ 3736.30ft (Latshaw 17)	
Project:	Lea County, NM (NAD83)	MD Reference:	KB=26 @ 3736.30ft (Latshaw 17)	
Site:	Sec 12-T19S-R33E	North Reference:	Grid	
Well:	Buffalo 12-1 Fed Com WCC 6H	Survey Calculation Method:	Minimum Curvature	i i
Wellbore:	Wellbore #1			1
Design:	Plan #1		· · · · · · · · · · · · · · · · · · ·	'

- ..

- ----

. . . . .

Planned Survey

Measured Depth	Inclination	Azimuth	Vertical Depth	+N/-S	+E/-W	Vertical Section	Dogleg Rate	Build Rate	Turn Rate
(ft)	(°)	(°)	(ft)	(ft)	(ft)	(ft)	(°/100usft)	(°/100usft)	(°/100usft)
0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
100.00	0.00	0.00	100.00	0.00	0.00	0.00	0.00	0.00	0.00
200.00	0.00	0.00	200.00	0.00	0.00	0.00	0.00	0.00	0.00
300.00	0.00	0.00	300.00	0.00	0.00	0.00	0.00	0.00	0.00
400.00	0.00	0.00	400.00	0.00	0.00	0.00	0.00	0.00	0.00
400.00	0.00	0.00	400.00	0.00	0.00	0.00	0.00	0.00	0.00
500.00	0.00	0.00	500.00	0.00	0.00	0.00	0.00	0.00	0.00
600.00	0.00	0.00	600.00	0.00	0.00	0.00	0.00	0.00	0.00
700.00	0.00	0.00	700.00	0.00	0.00	0.00	0.00	0.00	0.00
800.00	0.00	0.00	800.00	0.00	0.00	0.00	0.00	0.00	0.00
900.00	0.00	0.00	900.00	0,00	0.00	0.00	0.00	0.00	0.00
1,000.00	0.00	0.00	1,000.00	0.00	0.00	0.00	0.00	0.00	0.00
1.100.00	0.00	0.00	1,100.00	0.00	0.00	0.00	0.00	0.00	0.00
1,200.00	0.00	0.00	1 200 00	0.00	0.00	0.00	0.00	0.00	0.00
1 300 00	0.00	0.00	1 300 00	0.00	0.00	0.00	0.00	0.00	0.00
1 400 00	0.00	0.00	1 400 00	0.00	0.00	0.00	0.00	0.00	0.00
1,400.00	0.00	0.00	1,400.00	0.00	0.00	0.00	0.00	0.00	0.00
1,500.00	0.00	0.00	1,500.00	0.00	0.00	0.00	0.00	0.00	0.00
1,600.00	0.00	0.00	1,600.00	0.00	0.00	0.00	0.00	0.00	0.00
1,700.00	0.00	0.00	1,700.00	0.00	0.00	0.00	0.00	0.00	0.00
1,800.00	0.00	0.00	1,800.00	0.00	0.00	0.00	0.00	0.00	0.00
1,900.00	0.00	0.00	1,900.00	0.00	0.00	0.00	0.00	0.00	0.00
2,000.00	0.00	0.00	2,000.00	0.00	0.00	0.00	0.00	0.00	0.00
2,100.00	0.00	0.00	2,100.00	0.00	0.00	0.00	0.00	0.00	0.00
2 200 00	0.00	0.00	2 200 00	0.00	0.00	0.00	0.00	0.00	0.00
2 300 00	0.00	0.00	2 300 00	0.00	0.00	0.00	0.00	0.00	0.00
2,000.00	0.00	0.00	2,000.00	0.00	0.00	0.00	0.00	0.00	0.00
2,400.00	0.00	0.00	2,400.00	0.00	0.00	0.00	0.00	0.00	0.00
2,500.00	0.00	0.00	2,500.00	0.00	0.00	0.00	0.00	0.00	0.00
2,600.00	0.00	0.00	2,600.00	0.00	0.00	0.00	0.00	0.00	0.00
2,700.00	0.00	0.00	2,700.00	0.00	0.00	0.00	0.00	0.00	0.00
2,800.00	0.00	0.00	2,800.00	0.00	0.00	0.00	0.00	0.00	0.00
2,900.00	0.00	0.00	2,900.00	0.00	0.00	0.00	0.00	0.00	0.00
3,000.00	0.00	0.00	3,000.00	0.00	0.00	0.00	0.00	0.00	0.00
3,100.00	0.00	0.00	3,100.00	0.00	0.00	0.00	0.00	0.00	0.00
3,200,00	0.00	0.00	3,200,00	0.00	0.00	0.00	0.00	0.00	0.00
3,300,00	0.00	0.00	3,300,00	0.00	0.00	0.00	0.00	0.00	0.00
3,400.00	0.00	0.00	3,400.00	0.00	0.00	0.00	0.00	0.00	0.00
3 500 00	0.00	0.00	3 500 00	0.00	0.00	0.00	0.00	0.00	0.00
3 600 00	0.00	0.00	3,600,00	0.00	0.00	0.00	0.00	0.00	0.00
3,000.00	0.00	0.00	3 700 00	0.00	0.00	0.00	0.00	0.00	0.00
3,700.00	0.00	0.00	3,700.00	0.00	0.00	0.00	0.00	0.00	0.00
3,000,00	0.00	0.00	3,800.00	0.00	0.00	0.00	0.00	0.00	0.00
3,900.00	0.00	0.00	3,900.00	0.00	0.00	0.00	0.00	0.00	0.00
4,000.00	0.00	0.00	4,000.00	0.00	0.00	0.00	0.00	0.00	0.00
4,100.00	0.00	0.00	4,100.00	0.00	0.00	0.00	0.00	0.00	0.00
4,200.00	0.00	0.00	4,200.00	0.00	0.00	0.00	0.00	0.00	0.00
4,300.00	0.00	0.00	4,300.00	0.00	0.00	0.00	0.00	0.00	0.00
4,400.00	0.00	0.00	4,400.00	0.00	0.00	0.00	0.00	0.00	0.00
4,500.00	0.00	0.00	4,500.00	0.00	0.00	0.00	0.00	0.00	0.00
4,600.00	0.00	0.00	4,600.00	0.00	0.00	0.00	0.00	0.00	0.00
4,700,00	0.00	0.00	4,700.00	0.00	0.00	0.00	0.00	0.00	0.00
4 800 00	0.00	0.00	4,800.00	0.00	0.00	0.00	0.00	0.00	0.00
4,900.00	0.00	0.00	4,900.00	0.00	0.00	0.00	0.00	0.00	0.00
5 000 00	0.00	0.00	5 000 00	0.00	0.00	0.00	0.00	0.00	0.00
5,000,00	0.00	0.00	5 100 00	0.00	0.00	0.00	0.00	0.00	0.00
5,100.00	0.00	0.00	5 200 00	0.00	0.00	0.00	0.00	0.00	0.00
5,200.00	0.00	0.00	5,200,00	0.00	0.00	0.00	0.00	0.00	0.00
5,300.00	0.00	0.00	5,300.00	0.00	0.00	0.00	0.00	0.00	0.00

Database:	EDM 5000.1	Local Co-ordinate Reference:	Well Buffalo 12-1 Fed Com WCC 6H	
Company:	Chisholm Energy Holdings, LLC	TVD Reference:	KB=26 @ 3736.30ft (Latshaw 17)	
Project:	Lea County, NM (NAD83)	MD Reference:	KB=26 @ 3736.30ft (Latshaw 17)	
Site:	Sec 12-T19S-R33E	North Reference:	Grid	· 9
Well:	Buffalo 12-1 Fed Com WCC 6H	Survey Calculation Method:	Minimum Curvature	
Wellbore:	Wellbore #1			
Design:	<sup>°</sup> Plan #1		د. در از میاندهای میبرهای میبرهای در از میبرهای ویکنی ویکنی و از میبرهای از میبرهای میبرهای میبرهای میبرهای از می	: الحصا
Diamand Cumunu		·	n na	111
Planned Survey	· • · · · · · ·	· · · · · · · · · · · ·	and the second	~ · '

	Planned	Survey
--	---------	--------

Measured Depth (ft)	Inclination (°)	Azimuth (°)	Vertical Depth (ft)	+N/-S (ft)	+E/-W (ft)	Vertical Section (ft)	Dogleg Rate (°/100usft)	Build Rate (°/100usft)	Turn Rate (°/100usft)
5,400.00	0.00	0.00	5,400.00	0.00	0.00	0.00	0.00	0.00	0.00
5 500 00	0.00	0.00	5 500 00	0.00	0.00	0.00	0.00	0.00	0.00
5,500.00	0.00	0.00	5,500,00	0.00	0.00	0.00	0.00	0.00	0.00
5,000.00	0.00	0.00	5 700 00	0,00	0.00	0.00	0.00	0.00	0.00
5,700.00	0.00	0.00	5 800 00	0.00	0.00	0.00	0.00	0.00	0.00
5,800.00	0.00	0.00	5,000.00	0.00	0.00	0.00	0.00	0.00	0.00
5,900.00	0.00	0.00	5,900.00	0.00	0.00	0.00	0.00	0.00	0.00
6,000.00	0.00	0.00	6,000.00	0.00	0.00	0.00	0.00	0.00	0.00
6,100.00	0.00	0.00	6,100.00	0.00	0.00	0.00	0.00	0.00	0.00
6,200.00	0.00	0.00	6,200.00	0.00	0.00	0.00	0.00	0.00	0.00
6,300.00	0.00	0.00	6,300.00	0.00	0.00	0.00	0.00	0.00	0.00
6,400.00	0.00	0.00	6,400.00	0.00	0.00	0.00	0.00	0.00	0.00
6,500.00	0.00	0.00	6,500.00	0.00	0.00	0.00	0.00	0.00	0.00
6,600.00	0.00	0.00	6,600.00	0.00	0.00	0.00	0.00	0.00	0.00
6,700.00	0.00	0.00	6,700.00	0.00	0.00	0.00	0.00	0.00	0.00
6,800.00	0.00	0.00	6,800.00	0.00	0.00	0.00	0.00	0.00	0.00
6,900.00	0.00	0.00	6,900.00	0.00	0.00	0.00	0.00	0.00	0.00
7,000.00	0.00	0.00	7,000.00	0.00	0.00	0.00	0.00	0.00	0.00
7,100.00	0.00	0.00	7,100.00	0.00	0.00	0.00	0.00	0.00	0.00
7,200.00	0.00	0.00	7,200.00	0.00	0.00	0.00	0.00	0.00	0.00
7,300.00	0.00	0.00	7,300.00	0.00	0.00	0.00	0.00	0.00	0.00
7,400.00	0.00	0.00	7,400.00	0.00	0.00	0.00	0.00	0.00	0.00
7,500.00	0.00	0.00	7,500.00	0.00	0.00	0.00	0.00	0.00	0.00
7.600.00	0.00	0.00	7,600.00	0.00	0.00	0.00	0.00	0.00	0.00
7,700.00	0.00	0.00	7,700.00	0.00	0.00	0.00	0.00	0.00	0.00
7.800.00	0.00	0.00	7.800.00	0.00	0.00	0.00	0.00	0.00	0.00
7,900.00	0.00	0.00	7 900.00	0.00	0.00	0.00	0.00	0.00	0.00
8.000.00	0.00	0.00	8,000.00	0.00	0.00	0.00	0.00	0.00	0.00
8,100.00	0.00	0.00	8,100.00	0.00	0.00	0.00	0.00	0.00	0.00
8,200.00	0.00	0.00	8,200.00	0.00	0.00	0.00	0.00	0.00	0.00
8,300.00	0.00	0.00	8,300.00	0.00	0.00	0.00	0.00	0.00	0.00
8,400.00	0.00	0.00	8,400.00	0.00	0.00	0.00	0.00	0.00	0.00
8 500 00	0.00	0.00	8 500 00	0.00	0.00	0.00	0.00	0.00	0.00
8 600 00	0.00	0.00	8 600 00	0.00	0.00	0.00	0.00	0.00	0.00
8 700 00	0.00	0.00	8 700 00	0.00	0.00	0.00	0.00	0.00	0.00
8 800 00	0.00	0.00	8 800 00	0.00	0.00	0.00	0.00	0.00	0.00
8,900,00	0.00	0.00	8,900.00	0.00	0.00	0.00	0.00	0.00	0.00
0,000,00	0.00	0.00	0,000,00	0.00	0.00	0.00	0.00	0.00	0.00
9,000.00	0.00	0.00	9,000.00	0.00	0.00	0.00	0.00	0.00	0.00
9,100.00	0.00	0.00	9,100.00	0.00	0.00	0.00	0.00	0.00	0.00
9,200.00	0.00	0.00	9,200.00	0.00	0.00	0.00	0.00	0.00	0.00
9,300.00	0.00	0.00	9,400.00	0.00	0.00	0.00	0.00	0.00	0.00
0,500,00	0.00	0.00	0,500,00	0.00	0.00	0.00	0.00	0.00	0.00
9,500.00	0.00	0.00	9,500.00	0.00	0.00	0.00	0.00	0.00	0.00
9,000.00	0.00	0.00	9,000.00	0.00	0.00	0.00	0.00	0.00	0.00
9,700.00	0.00	0.00	9,700.00	0.00	0.00	0.00	0.00	0.00	0.00
9,800.00	0.00	0.00	9,800,00	0.00	0.00	0.00	0.00	0.00	0.00
9,900.00	0.00	0.00	9,900.00	0.00	0.00	0.00	0.00	0.00	0.00
10,000.00	0.00	0.00	10,000.00	0.00	0.00	0.00	0.00	0.00	0.00
10,100.00	0.00	0.00	10,100.00	0.00	0.00	0.00	0.00	0.00	0.00
10,200.00	0.00	0.00	10,200.00	0.00	0.00	0.00	0.00	0.00	0.00
10,300.00	0.00	0.00	10,300.00	0.00	0.00	0.00	0.00	0.00	0.00
10,367.91	0.00	0.00	10,367.91	0.00	0.00	0.00	0.00	0.00	0.00
Start Build 1	2.00								
10,375.00	0.85	270.00	10,375.00	0.00	-0.05	0.00	12.00	12.00	0.00

Database:	EDM 5000.1	Local Co-ordinate Reference:	Well Buffalo 12-1 Fed Com WCC 6	+ .!
Company:	Chisholm Energy Holdings, LLC	TVD Reference:	KB=26 @ 3736.30ft (Latshaw 17)	
Project:	Lea County, NM (NAD83)	MD Reference:	KB=26 @ 3736.30ft (Latshaw 17)	
Site:	Sec 12-T19S-R33E	North Reference:	Grid	i ti
Well:	Buffalo 12-1 Fed Com WCC 6H	Survey Calculation Method:	Minimum Curvature	
Wellbore:	Weilbore #1		(	I
Design:	Plan #1			
Planned Survey				

	Measured Depth	Inclination	Azimuth	Vertical Depth	+N/-S	+E/-W	Vertical Section	Dogleg Rate	Build Rate	Turn Rate
	(ft)	(°)	(°)	(ft)	(ft)	(ft)	(ft)	(°/100usft)	(°/100usft)	(°/100usft)
	10,400.00	3.85	270.00	10,399.98	0.00	-1.08	0.00	12.00	12.00	0.00
1	10,425.00	6.85	270.00	10,424,86	0.00	-3.41	0.01	12.00	12.00	0.00
	10 450.00	9.85	270.00	10.449.60	0 00	-7 04	0.02	12.00	12.00	0.00
	10,475.00	12.85	270.00	10,474.10	0.00	-11.96	0.04	12.00	12.00	0.00
	10,500.00	15.85	270.00	10,498.32	0.00	-18,15	0.06	12.00	12.00	0.00
	10,525.00	18.85	270.00	10,522,18	0.00	-25.61	0.09	12.00	12.00	0.00
	10,550.00	21.85	270.00	10.545.62	0.00	-34.30	0.12	12.00	12.00	0.00
	10 575 00	24.85	270.00	10 568 57	0.00	-44 21	0.15	12.00	12.00	0.00
	10,600.00	27.85	270.00	10,590.97	0,00	-55.31	0.19	12,00	12,00	0.00
	10 625 00	30.85	270.00	10 612 76	0 00	-67 56	0.24	12.00	12.00	0.00
	10,650,00	33.85	270.00	10 633 87	0.00	-80.93	0.28	12.00	12.00	0.00
	10 675 00	36.85	270.00	10,654,26	0.00	-00,00	0.33	12.00	12.00	0.00
	10,075.00	30.05	270.00	10,034.20	0.00	-93,40	0.33	12.00	12.00	0.00
	10,700,00	39,05	270.00	10,073,07	0.00	-110.91	0.39	12.00	12.00	0.00
	10,725.00	42.85	270.00	10,692,63	0,00	-127.42	0.44	12,00	12.00	0.00
	10,750.00	45.85	270.00	10,710.50	0.00	-144.90	0.51	12.00	12.00	0.00
	10,775.00	48.85	270.00	10,727.44	0.00	-163.28	0.57	12.00	12.00	0.00
	10,800.00	51.85	270.00	10,743.39	0.00	-182.53	0.64	12.00	12.00	0.00
	10,825.00	54.85	270.00	10,758.31	0.00	-202.58	0.71	12.00	12.00	0.00
	10,850.00	57.85	270.00	10,772,16	0.00	-223.39	· 0,78	12.00	12.00	0.00
	10,875.00	60.85	270.00	10,784.91	0.00	-244.90	0.85	12.00	12.00	0.00
	10,900.00	63.85	270.00	10,796.51	0.00	-267.04	0.93	12.00	12.00	0.00
	10,925.00	66.85	270.00	10,806.93	0.00	-289.76	1.01	12.00	12.00	0.00
	10,950.00	69.85	270.00	10,816,15	0.00	-312.99	1.09	12.00	12.00	0.00
	10,975.00	72.85	270.00	10.824.15	0.00	-336.68	1,18	12.00	12.00	0.00
	10,979.58	73.40	270.00	10,825.48	0.00	-341.06	1.19	12.00	12.00	0.00
	Start 100.00	hold at 10979.5	BMD							
	11,000.00	73.40	270.00	10,831.31	0.00	-360.63	1.26	0.00	0.00	0.00
	11,079.58	73.40	270.00	10,854.05	0.00	-436.89	1.53	0.00	0.00	0.00
	Start DLS 12	2.00 TFO 89.94								
	11,100.00	73,42	272.56	10,859.88	0.44	-456.46	2.03	12.00	0.09	12.52
	11,125.00	73.48	275.69	10,867.00	2.16	-480.36	3.84	12.00	0.26	12.52
	11,150.00	73.59	278.81	10,874.09	5.18	-504.14	6,94	12.00	0.44	12.50
	11,175.00	73,75	281.93	10.881.12	9.50	-527.73	11.35	12.00	0.63	12.49
	11,200.00	73. <del>9</del> 5	285.05	10,888.07	15.11	-551.08	17.03	12.00	0.81	12.46
	11,225.00	74.20	288.16	10,894.93	21.97	-574.11	23.98	12.00	0.99	12.44
	11,250.00	74.49	291.26	10,901.68	30.09	-596.77	32.18	12.00	1.17	12.40
	11,275.00	74.83	294.35	10,908.29	39.44	-619.00	41.60	12.00	1.34	12.37
	11,300.00	75,21	297.43	10,914,76	49,98	-640.72	52,22	12.00	1.51	12.32
	11,325.00	75,62	300.50	10,921.05	61.70	-661,88	64.01	12.00	1.67	12.28
	11,350.00	76.08	303.56	10,927.17	74.55	-682.43	76.94	12.00	1.83	12.23
	11,375.00	76.58	306.60	10,933.08	88.51	-702.31	90.97	12.00	1.98	12.18.
	11,400.00	77.11	309.64	10,938.77	103.54	-721.45	106.06	12.00	2.13	12.13
	11,425.00	77.67	312.66	10,944.23	119,59	-739.82	122,17	12.00	2.26	12.08
	11,450,00	78,27	315.66	10,949,44	136.62	-757.36	139.27	12.00	2,40	12,02
	11 475 00	78.90	318.65	10,954,39	154.59	-774.02	157.29	12.00	2.52	11.97
	11,500.00	79.56	321.63	10,959.06	173.44	-789.76	176.20	12.00	2.64	11.92
	11,525.00	80.25	324.60	10,963.44	193.13	-804.53	195.93	12.00	2.75	11.86
	11,550.00	80.96	327 55	10,967 52	213.59	-818 29	216.45	12.00	2.85	11.81
	11 575 00	81 70	330 49	10 971 29	234 78	-831 01	237 68	12.00	2 95	11.77
	11 600 00	87 46	333 43	10 974 74	256 63	-842 65	259 57	12.00	3.03	11 72
	11,625.00	83.23	336.35	10,977.85	279.09	-853.17	282.07	12.00	3.11	11.68
	11 650 00	84.03	339.26	10.980.63	302.09	-862.56	305,10	12.00	3,18	11.64
	11 675 00	84 84	342 16	10 983 05	325 57	-870 78	328.61	12.00	3 24	11.61
	11 700 00	85.66	345.05	10 985 13	349.47	-877.81	352.53	12.00	3.29	11.58

Database:	EDM 5000.1	Local Co-ordinate Reference:	Well Buffalo 12-1 Fed Corn WCC 6H
Company:	Chisholm Energy Holdings, LLC	TVD Reference:	KB=26 @ 3736.30ft (Latshaw 17)
Project:	Lea County, NM (NAD83)	MD Reference:	KB=26 @ 3736.30ft (Latshaw 17)
Site:	Sec 12-T19S-R33E	North Reference:	Grid
Well:	Buffalo 12-1 Fed Com WCC 6H	Survey Calculation Method:	Minimum Curvature
Wellbore:	Wellbore #1		
Design:	Plan #1	a a second a	ار این
Planned Survey	an an an an an an		
Flatified Survey		and a second	

Measured Depth (ft)	Inclination (°)	Azimuth (°)	Vertical Depth (ft)	+N/-S (ft)	+E/-W (ft)	Vertical Section (ft)	Dogleg Rate (°/100usft)	Build Rate (°/100usft)	Turn Rate (°/100usft)
11 725 00	86.49	347 94	10 986 84	373 72	-883.63	376.80	12 00	3 34	11 55
11,750.00	87.34	350.83	10,988.18	398.25	-888.23	401.35	12.00	3.37	11.53
				400.00		100.11	10.00	0.40	
11,775.00	88.19	353.71	10,989.16	423.00	-891.59	426.11	12.00	3.40	11.52
11,800.00	89.04	356.58	10,989.76	447.91	-893.71	451.02	12.00	3.42	11.51
11,825.00	89.90	359.46	10,989.99	4/2.89	-894.57	4/6.01	12.00	3.43	11.50
11,827.98	90.00	359.80	10,990.00	475.87	-894.59	478.99	12.00	3.43	11.50
Start DLS 0.	.00 TFO 90.99								
11,900.00	90.00	359.80	10,990.00	547.89	-894.84	551.01	0.00	0.00	0.00
12,000.00	90.00	359.80	10,990.00	647.89	-895.19	651.01	0.00	0.00	0.00
12,100.00	90.00	359.80	10,990.00	747.88	-895.54	751.01	0.00	0.00	0.00
12,200.00	90.00	359.80	10,990.00	847.88	-895.89	851.01	0.00	0.00	0.00
12,300.00	90.00	359.80	10,990.00	947.88	-896.24	951.01	0.00	0.00	0.00
12,400.00	90.00	359.80	10,990.00	1,047.88	-896.59	1,051.01	0.00	0.00	0.00
12,500.00	90.00	359.80	10,990.00	1,147.88	-896.94	1,151.01	0.00	0.00	0.00
12,600.00	90.00	359.80	10,990.00	1,247.88	-897.28	1,251.01	0.00	0.00	0.00
12,700.00	90.00	359.80	10,990.00	1,347.88	-897.63	1,351.01	0.00	0.00	0.00
12,800.00	90.00	359.80	10,990.00	1,447.88	-897.98	1,451.01	0.00	0.00	0.00
12,900.00	90.00	359.80	10,990.00	1,547.88	-898.33	1,551.01	0.00	0.00	0.00
13,000.00	90.00	359.80	10,990.00	1,647.88	-898.68	1,651.01	0.00	0.00	0.00
13,100.00	90.00	359.80	10,990.00	1,747.88	-899.03	1,751.01	0.00	0.00	0.00
13,200.00	90.00	359.80	10,990.00	1,847.88	-899,38	1,851.01	0.00	0.00	0.00
13,300,00	90.00	359.80	10,990.00	1,947.88	-899.72	1,951.01	0.00	0.00	0.00
13,400.00	90.00	359.80	10,990.00	2,047.88	-900.07	2,051.01	0.00	0.00	0.00
13,500.00	90.00	359.80	10,990.00	2,147.88	-900.42	2,151.01	0.00	0.00	0.00
13,600.00	90.00	359.80	10,990.00	2,247.88	-900.77	2,251.01	0.00	0.00	0.00
13,700.00	90.00	359.80	10,990.00	2,347.87	-901.12	2,351.01	0.00	0.00	0.00
13,800.00	90.00	359.80	10,990.00	2,447.87	-901.46	2,451.01	0.00	0.00	0.00
13,900.00	90.00	359.80	10,990.00	2,547.87	-901.81	2,551.01	0.00	0.00	0.00
14,000.00	90.00	359.80	10,990.00	2,647.87	-902.16	2,651.01	0.00	0.00	0.00
14,100.00	90.00	359.80	10,990.00	2,747.87	-902.51	2,751.01	0.00	0.00	0.00
14,200.00	90.00	359.80	10,990.00	2,847.87	-902.86	2,851.01	0.00	0.00	0.00
14,300.00	90.00	359.80	10,990.00	2,947.87	-903.20	2,951.01	0.00	0.00	0.00
14,400.00	90.00	359.80	10,990.00	3,047.87	-903.55	3,051.01	0.00	0.00	0.00
14,500.00	90.00	359.80	10,990.00	3,147.87	-903.90	3,151.01	0.00	0.00	0.00
14,600.00	90.00	359.80	10,990.00	3,247.87	-904.25	3,251.01	0.00	0.00	0.00
14,700.00	90.00	359.80	10,990.00	3,347.87	-904.60	3,351.01	0.00	0.00	0.00
14,800.00	90.00	359.80	10,990.00	3,447.87	-904.94	3,451.01	0.00	0.00	0.00
14,900.00	90.00	359.80	10,990.00	3,547.87	-905.29	3,551.01	0.00	0.00	0.00
15,000.00	90.00	359.80	10,990.00	3,647.87	-905.64	3,651.01	0.00	0.00	0.00
15,100.00	90.00	359.80	10,990.00	3,747.87	-905.99	3,751.01	0.00	0.00	0.00
15,200.00	90.00	359.80	10,990.00	3,847.87	-906.33	3,851.01	0.00	0.00	0.00
15,300.00	90.00	359.80	10,990.00	3,947.87	-906.68	3,951.01	0.00	0.00	0.00
15,400.00	90.00	359.80	10,990.00	4,047.86	-907.03	4,051.01	0.00	0.00	0.00
15,500.00	90.00	359.80	10,990.00	4,147.86	-907.38	4,151.01	0.00	0.00	0.00
15,600.00	90.00	359.80	10,990.00	4,247.86	-907.72	4,251.01	0.00	0.00	0.00
15,700.00	90,00	359.80	10,990.00	4,347.86	-908.07	4,351.01	0.00	0.00	0.00
15,800.00	90.00	359,80	10,990.00	4,447.86	-908.42	4,451.01	0.00	0.00	0.00
15,900.00	90.00	359.80	10,990.00	4,547.86	-908.76	4,551.01	0.00	0.00	0.00
16,000.00	90.00	359.80	10,990.00	4,647.86	-909.11	4,651.01	0.00	0.00	0.00
16,100.00	90.00	359.80	10,990.00	4,747.86	-909.46	4,751.01	0.00	0.00	0.00
16,200.00	90.00	359.80	10,990.00	4,847.86	<del>-</del> 909.81	4,851.01	0.00	0.00	0.00
16,300.00	90.00	359.80	10,990.00	4,947.86	-910.15	4,951.01	0.00	0.00	0.00
16,400.00	90.00	359.80	10,990.00	5,047.86	-910.50	5,051.01	0.00	0.00	0.00

Database: Company: Project:	EDM 5000.1 Chisholm Energy Holdings, LLC Lea County, NM (NAD83)	Local Co-ordinate Reference: TVD Reference: MD Reference:	Well Buffalo 12-1 Fed Com WCC 6H KB=26 @ 3736.30ft (Latshaw 17) KB=26 @ 3736.30ft (Latshaw 17)		
Site:	Sec 12-T19S-R33E	North Reference:	Grid		
Well:	Buffalo 12-1 Fed Com WCC 6H	Survey Calculation Method:	Minimum Curvature		
Wellbore:	Wellbore #1	-			
Design:	Plan #1	·			
Diannad Sumou					
Flameu Survey			···· · · ·	· ·	

Measured Depth	d Inclination	Azimuth	Vertical Depth	+N/-S	+E/-W	Vertical Section	Dogleg Rate	Build Rate	Turn Rate
(ft)	(°)	(°)	(ft)	(ft)	(ft)	(ft)	(°/100usft)	(°/100usft)	(°/100usft)
16,500.	00 90.00	359.80	10,990.00	5,147.86	-910.85	5,151.01	0.00	0.00	0.00
16,600.	00 90,00	) 359.80	10,990.00	5,247,86	-911,19	5,251,01	0.00	0.00	0.00
16,700.	00 90.00	359.80	10,990,00	5.347.86	-911.54	5,351.01	0.00	0.00	0.00
16,800.	00 90.00	359.80	10,990,00	5 447 86	-911.89	5 451 01	0.00	0.00	0.00
16,900.	00 90.00	359.80	10,990.00	5.547.86	-912.23	5.551.01	0.00	0.00	0.00
47.000	00 00 00		10,000,00	5,0 17,00	010.50	5,051,01	0.00	0.00	0.00
17,000.	00 90.00	359.80	10,990.00	5,647.86	-912.58	5,651.01	0.00	0.00	0.00
17,100.	90.00	359,80	10,990.00	5,747.85	-912.93	5,751.01	0.00	0.00	0.00
17,200.	00 90,00	359,80	10,990.00	5,847.85	-913.27	5,851.01	0.00	0,00	0.00
17,300.	00 90,00	359,80	10,990.00	5,947.85	-913.62	5,951.01	0.00	0.00	0.00
17,400.	00 90.00	359,80	10,990.00	6,047.85	-913.96	6,051.01	0.00	0.00	0.00
17,500.	00 90.00	359.80	10,990.00	6,147.85	-914.31	6,151.01	0.00	0.00	0.00
17,600.	00 90,00	359.80	10,990.00	6,247.85	-914.66	6,251.01	0.00	0.00	0.00
17,700.	00 90.00	359,80	10,990.00	6,347.85	-915.00	6,351.01	0.00	0.00	0.00
17,800.	00 90,00	359.80	10,990.00	6,447,85	-915,35	6,451,01	0.00	0.00	0.00
17,900.	00 90.00	359.80	10,990.00	6,547.85	-915.70	6,551.01	0,00	0.00	0.00
18.000	00 90.00	359.80	10 990 00	6 647 85	-916 04	6.651.01	0.00	0.00	0.00
18 100	00 90.00	359.80	10,000,00	6 747 85	-916 39	6 751 01	0.00	0.00	0.00
18 200	00 90.00	359.80	10,000.00	6 847 85	-916 73	6 851 01	0.00	0.00	0.00
18 300	00 00.00	359.80	10,000.00	6 947 85	-017.08	6 951 01	0.00	0,00	0.00
18,400.	00 90.00	359.80	10 990 00	7 047 85	-917 43	7.051.01	0.00	0.00	0.00
40,500	00 00.00		10,000,00	7,017,00	017.77	7 454 04	0,00	0.00	0.00
18,500.	00 90.00	359.80	10,990.00	7,147.85	-917.77	7,151.01	0.00	0.00	0.00
10,000.	90.00	359.80	10,990.00	7,247.85	-918.12	7,251.01	0.00	0.00	0.00
18,700.	90.00	359.80	10,990.00	7,347.84	-918.46	7,351.01	0.00	0.00	0.00
18,800.	90.00	359.80	10,990.00	7,447.84	-918.81	7,451.01	0.00	0.00	0.00
18,900.	00 90.00	359,80	10,990.00	7,547.84	-919.15	7,551.01	0.00	0.00	0.00
19,000.	00 90.00	359.80	10,990.00	7,647.84	-919.50	7,651.01	0.00	0.00	0.00
19,100.	00 90.00	) 359.80	10,990.00	7,747.84	-919.85	7,751.01	0.00	0.00	0.00
19,200.	00 90.00	359.80	10,990.00	7,847.84	-920.19	7,851.01	0.00	0.00	0.00
19,300.	00 90.00	359.80	10,990.00	7,947.84	-920.54	7,951.01	0.00	0.00	0.00
19,400.	00 90.00	359.80	10,990.00	8,047.84	-920.88	8,051.01	0.00	0.00	0.00
19 500	00 90 00	359.80	10 990 00	8 147 84	-921 23	8 151 01	0.00	0.00	0.00
19,600	00 90.00	359.80	10,990,00	8 247 84	-921.57	8 251 01	0.00	0.00	0.00
19,000.	00 00.00	350.00	10,350,00	9 347 94	021.07	8 351 01	0.00	0.00	0.00
19,700.	00 90.00	359.80	10,990.00	8 447 84	-927.92	8 451 01	0.00	0.00	0.00
19,900.	00 90.00	359.80	10,990,00	8.547.84	-922.61	8.551.01	0.00	0.00	0.00
20.000	00 00 00	050.00	10,000,00	0.047.04	000.05	0.054.04	0.00	0.00	0.00
20,000.	00 90,00	359.80	10,990,00	8,047.84 9 747 94	-922.95	8,051,01 9,751,01	0.00	0.00	0.00
20,100.	00 90.00	309.00	10,990.00	0,/4/.04	-823.30	0,701.01	0.00	0.00	0.00
20,200.	00 90.00	· 359.00	10,990.00	0,047.04	-923.04	0,001.01	0.00	0.00	0.00
20,300.	00 Q0 Q0 Q0	359.60	10,990,00	0,947.04 9 047 83	-923.99	0,901,01 9,051,01	0.00	0.00	0.00
20,400.	50,01		10,000,00	3,047,03	-024,00	0,001,01	0,00	0,00	0.00
20,500.	00 90.00	359,80	10,990.00	9,147.83	-924.68	9,151.01	0.00	0.00	0.00
20,600.	00 90.00	359,80	10,990.00	9,247.83	-925.02	9,251.01	0.00	0.00	0.00
20,700.	00 90.00	) 359,80	10,990.00	9,347.83	-925.37	9,351.01	0.00	0.00	0.00
20,800.	00 90.00	359.80	10,990.00	9,447.83	-925.71	9,451.01	0.00	0.00	0.00
20,900.	00 90.00	) 359.80	10,990.00	9,547.83	-926.06	9,551.01	0.00	0.00	0.00
21,000.0	00 90.00	359.80	10,990.00	9,647.83	-926.40	9,651.01	0.00	0.00	0.00
21,100.0	00 90.00	) 359.80	10,990.00	9,747.83	-926.75	9,751.01	0.00	0.00	0.00
21,200.	00 90.00	359.80	10,990.00	9,847.83	-927.09	9,851.01	0.00	0.00	0.00
21.300.	00 90 00	) 359.80	10,990.00	9,947.83	-927.43	9,951.01	0.00	0.00	0.00
21,400.	00 90.00	359.80	10,990.00	10,047.83	-927.78	10,051.01	0,00	0.00	0.00
21 500	00 00 00	350 80	10,000,00	10 147 83	028 42	10 151 01	0.00	0.00	0.00
21,000,0	52 00.00	/ 328.0U	10,990,00	10,147.03	-920.12 _079 /F	10,151.01	0.00	0.00	0.00
21,030.3	JZ 90.00	, 228.00	10,590.00	10,240.33	-720.40	10,249.00	0.00	0.00	0.00

Database: Company: Project: Site: Well: Well: Wellbore: Design:	EDM 5000.1 Chisholm Energy Holdings, LLC Lea County, NM (NAD83) Sec 12-T19S-R33E Buffalo 12-1 Fed Com WCC 6H Wellbore #1 Plan #1			Local Co- TVD Refer MD Refere North Refe Survey Ca	ordinate Reference: rence: ance: erence: alculation Method:	Well Buffa KB=26 @ KB=26 @ Grid Minimum (	Well Buffalo 12-1 Fed Com WCC 6H KB=26 @ 3736.30ft (Latshaw 17) KB=26 @ 3736.30ft (Latshaw 17) Grid Minimum Curvature			
Design Targets	· · · ·	-			· · · · ·				·····	
Target Name - hit/miss target - Shape	Dip A (°	ngle )	Dip Dir. (°)	TVD (ft)	+N/-S (ft)	+E/-W (ft)	Northing (usft)	Easting (usft)	Latitude	Longitude
PBHL Buffalo 12-1 Fe - plan hits target o - Point	d ( center	0.00	0.00	10,990.00	10,246.35	-928.46	617,661.7100	759,594.4600	32.695988	-103.623848
Plan Annotations										
Meas	sured	Vert	lical	Loca	I Coordinates	в .				
De (1	pth ft)	Dej (f	pth t)	+N/-S (ft)	+	E/-W (ft)	Comment			
10,	367.91	10,	367.91	0.0	00	0.00	Start Build 12.00			
10,	979.58	10,	825.48	0.0	00	-341.06	Start 100.00 hold a	at 10979.58 MD		
11,	079.58	10,0	854.05	0.0	)0 17	-436.89	Start DLS 12.00 TF	-0 89.94		
11, 21,	827.98 598.52	10,9 10,9	990.00 990.00	475.8 10,246.3	57 15	-894.59 -928.46	TD at 21598.52	0 AD'AA		





Installation Procedure Prepared For:

## **Chisholm Energy** 13-3/8" x 9-5/8" x 5-1/2" 5/10M MBU-3T Wellhead System With CTH-HPS-F MOD Tubing Head

Publication # IP0571

May, 2017

INFORMATION CONTAINED HEREIN IS THE PROPERTY OF CACTUS WELLHEAD, LLC. REPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC.

INFORMATION CONTAINED HER	, THE PROPERTY OF CACTUS WELLHEAD, .	REPRODUCTION, DISCLOSURE,
OR USE THEREOF IS PERMISSIBLE (	ONLY AS PROVIDED BY CONTRACT OR AS EXPI	RESSLY AUTHORIZED BY CACTUS
WELLHEAD, LLC .		

## **Table of Contents**

	System Drawing	1
	Bill of Materials	2
Stage 1 —	Install the MBU-3T Housing	5
Stage 2	Nipple Up The BOP Stack	6
Stage 3 —	Test the BOP Stack	7
Stage 4	Run the Lower Wear Bushing	
oluge 4 -	Run the Wear Bushing Before Drilling	8
	Retrieve the Wear Bushing After Drilling	8
Stage 5 —	Hang Off the 9-5/8" Casing	<b> 9</b>
Stage 5A —	Hang Off the 9-5/8" Casing (Emergency)	16
Stage 6	Install the MBIL3T Mandrel Hanger Packoff	
oluge v ==		20
	Landing the Packon	20
	Engaging the Lockring	21
	Retrieving the Packoff	22
Stage 6A —	Install the MBU-3T Emergency Packoff	23
•	Landing the Packoff	25
	Seal Test	26
<b>-</b>	Engaging the Lockring	26
Stage 7 —	Test the BOP Stack	27
Stage 8 —	Run the Upper Wear Bushing	28
	Run the Wear Bushing Before Drilling	28
<b>•</b>	Retrieve the Wear Bushing After Drilling	28
Stage 9 —	Hang Off the 5-1/2" Casing	29
Stage 10 —	Install the 'Quick Connect' TA Cap Assembly	<b> 31</b> 32
Stage 11 —	Remove the TA Cap Assembly	33
Stage 12	Install the Tubing Head	35
	Seal Test	36
	Flange Test	37
	Recommended Procedure for Field Welding Pipe to	
	Wellhead Parts for Pressure Seal	38

.



Chisholm Energy 13-3/8" x 9-5/8" x 5-1/2" 5/10M MBU-3T Wellhead, With CTH-HPS-F MOD Tubing Head



# System Drawing

INFORMATION CONTAINED HEI 3 THE PROPERTY OF CACTUS WELLHEAD, REPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC.

- 29.40"

INFORMATION CONTAINED HER. THE PROPERTY OF CACTUS WELLHEAD, CEPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC

## **Bill of Materials**



IP 0571 Page 2 Chisholm Energy 13-3/8" x 9-5/8" x 5-1/2" 5/10M MBU-3T Wellhead, With CTH-HPS-F MOD Tubing Head



# INFORMATION CONTAINED HEI 3 THE PROPERTY OF CACTUS WELLHEAD, REPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC

MBU-3T HOUSING ASSEMBLY			MBU-3T HOUSING ASSEMBLY			TUBING HEAD ASSEMBLY		
ltem	Qty	Description	ltem	Qty	Description	ltem	Qty	Description
A1	1	Housing, CW, MBU-3T, 13.5/8" 5M x 13-3/8" SOW, with two 2-1/16" 5M studded upper and lower outlets with o-ring, 6A-PU-AA-1-2 Part # 117620	 A11	1	Casing Hanger, CW, MBU–3T-LWR-TP, fluted, 13-5/8" x 9-5/8" (40#) LC bottom x 10.250" 4 Stub Acme 2G RH box top, with 11-1/2" OD neck, 6A-U-AA-1-2 Part # 120251	B1	1	Tubing Head, CW, CTH-HPS-F, 9" (MOD), 13-5/8" 5M x 7-1/16" 10M, with two 1-13/16" 10M studded outlets, round bar, 17-4PH lockscrews, 6A-PU-EE- 0,5-2-1 Part #
A2	1	Nipple, 2" line pipe x 6" long Part # NP6A	A12	1	Packoff, CW, MBU-3T, Mandrel, 13-5/8" nested x 11"	B2	1	Secondary Seal, CW, HPS-F, 9 MOD x 5-1/2", 6A-PU-DD-
A3	1	Ball Valve, TV, 2" RP, 5M x 2" LP, WCB body SS trim, Delrin seats, HNBR seals, nace with leaking bondle			With 11.250" 4 Stub Acme 2G LH box top, 1/8" NPT test ports, 6A-U-AA-1-1 Port # 117152	22	1	NL-1-2 Part # 110503
	2	Part # 115184	A13	1	Casing Hanger, C2, 11" x	53	I	1-1/4" hex Part # VR1
A5	1	pipe, 4130 60K Part # BP2T Gate valve, CW1, 2-1/16" 3/5M, flanged end, handwheel	A14	1	Part # 108067 Hold Down Ring, for C2 hanger, 11" x 7 through 4-1/2", arranged for packoff MBU-3T, 13-5/8"	B4	1	Gate valve, AOZE, 1-13/16" 10M, flanged end, handwheel operated, EE-0,5 trim, (6A-LU-EE-0,5-3-1) Part # 103188
A6	4	operated, AA/DD-NL trim, (6A-LU-AA/DD-NL-1-2) Part # 610003 Companion Flange, 2-1/16" 5M			with 11.250" 4 Stub Acme 2G LH pin x 9.06" ID x 6.25" long, with 2.12" thread length, 4140 110K Part # 117418	B5	2	Companion Flange, 1-13/16" 10M x 2" LP, 5000 psi max WP, 6A-KU-EE-NL-1 Part # 200010
		x 2" line pipe, 4130 CMS-102, CMS-002 Part # 200002				B6	2	Bull Plug, 2" line pipe x 1/2" line pipe, 4130 60K Part # BP2T
A7	2	VR Plug, 1-1/2" Sharp Vee x 1-1/4" hex Part # VR2				В7	3	Ring Gasket, BX151, 1-13/16" 10M Part # BX-151
A8	2	Fitting, grease, vented cap, 1/2" NPT alloy non-nace Part # FTG1				B8	8	Studs, all thread with two nuts, black, 3/4" x 5-1/2" long, B7/2H Part # 780080
A9	5	Ring Gasket, R-24, 2-1/16" 3/5M Part # R24				B9	1	Fitting, grease, vented cap, 1/2" NPT alloy non-nace Part # FTG1
ATU	8	Studs, all thread with two nuts, black, 7/8" x 6-1/2" long, B7/2H Part # 780067				B10	1	Needle Valve, MFA, 1/2" NPT 10M service Part # NVA
						B11	1	Pressure Gauge, 5M, 4-1/2" face, liquid filled, 1/2" NPT PG5M
						B12	1	Ring Gasket, BX-160, 13-5/8" 15M Part # BX-160
						B13	16	Studs, all thread with two nuts, black, 1-5/8" x 12-3/4" long, B7/2H Part # 780087



# INFORMATION CONTAINED HER. , THE PROPERTY OF CACTUS WELLHEAD, CRUSE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC.

RECOMMENDED SERVICE TOOLS		RENTAL EQUIPMENT				EMERGENCY EQUIPMENT			
Item Qty	Description	ltem	Qty	Description		ltem	Qty	Description	
ST1 1	Test Plug/Retrieving Tool, CW, 13-5/8" x 4-1/2" IF (NC-50), 1-1/4" LP bypass and spring loaded lift dogs Part # 104467	R1	1	Threaded Hub, CW, MBU-3T, 13-5/8" 5M With 19.000" 2 Stub Acme-2G Left Hand Box Thread Part # 117268		A11a A12a	1	Casing Hanger, CW, MBU-3T, 13-5/8" x 9-5/8" 6A-PU-DD-3-1 Part # 116998 Packoff, CW, MBU-3T,	
ST2 1	Wear Bushing, CW, MBU-3T-LWR, 13-5/8" x 12.31" ID x 27.0" long with 3/8" o-ring Part # 116974	R2	1	Drilling Adapter, CW, MBU-3T, 13-5/8" 5M Quick Connect Bottom x 13-5/8" 5M Studded Top, Temp Rating PU Part # 117278				2G LH box top, 1/8" NPT test ports, 6A-U-AA-1-1 Part # 117184	
ST3 1	Casing Hanger Running Tool, CW, MBU-3T-LR-TP, 13-5/8" x 9-5/8" LC box top x 10.250" 4 Stub Acme 2G RH pin bottom, max load capacity 1000K, max torque 18000 ft-lbs. spec for rotating casing Part # 105845	R3	1	TA Cap, CW, MBU-3T-HPS, 13-5/8" 5M quick connect, with one 2" LPO & 1/2" NPT port, with 1/2" NPT needle valve and 2" LP nipple and valve, 6A-U-AA-1-1 Part # 117317					
ST4 1	Torque Collar, CW, for use with running tool, TP, 10.250 4 stub Acme 2G RH pin bottom and arranged for 11.50" OD x 5.00" long box hanger neck, maximum torque 18,000 ft-lbs	R4	1 4	Secondary Seal Bushing, CW, HPS, 9" x 5-1/2 Part # 109026 Lift Eyes, 3/4", side pull hoist ring					
	Part # 118906			Part # 115542					
ST5 1	Wash Tool, CW, Casing Hanger, MBU-LR/MBS2, fluted, 13-5/8" x 4-1/2" IF (NC-50) box top threads, with brushes Part # 106277								
ST6 1	Packoff Running Tool, CW, MBU-3T UPR, 13-5/8" nested, with 11.250" 4 Stub Acme 2G LH pin bottom x 4-1/2" IF (NC-50) box top with seal sleeve Part # 117310								
ST7 1	Test Plug, CW, MBU-2LR Inner, 11" x 4-1/2" IF, 1-1/4" LP bypass Part # 108848								
ST8 1	Wear Bushing, MBU-3T-UPR, nested, 13-5/8" x 11" x 9.00" I.D. x 20.0" long, arranged for 13-5/8" tool Part # 117158								



# INFORMATION CONTAINED HEF J THE PROPERTY OF CACTUS WELLHEAD, REPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC.

# Stage 1 — Install the MBU-3T Housing

- 1. Run the conductor and 13-3/8" surface casing to the required depth and cement as required.
- 2. Cut the conductor pipe off level with the cellar floor.
- 3. Final cut the 13-3/8" surface casing at 39.00" below ground level (grade). Ensure the cut is level and square with the horizon.
- 4. Place an 3/16" x 3/8" bevel on the OD of the stub.

**Note:** The slip on and weld preparation is 4.25" in depth.

- 5. Examine the 13-5/8" 5M x 13-3/8" SOW x 19.00" 2 Stub Acme LH (Left Hand Thread) MBU-3T Wellhead Housing (Item A1). Verify the following:
  - internal bore is clean and in good condition
  - external Acme thread is clean and in good condition
  - thread flange is in place and rotates freely
  - valves are intact and in good condition
  - weld socket is clean and free of grease and debris and o-ring is in place and in good condition
- Align and level the Wellhead Assembly over the casing stub, orienting the outlets so they will be compatible with the drilling equipment.
- 7. Remove the pipe plug from the port on the bottom of the Head.
- 8. Slowly and carefully lower the assembly over the casing stub, weld and test the MBU-3T wellhead to the surface casing.
- 9. Replace the pipe plug in the port on the bottom of the wellhead.



**Note:** The weld should be a fillet-type weld with legs no less than the wall thickness of the casing. Legs of 1/2" to 5/8" are adequate for most jobs.

Refer to the back of this publication for the **Recommended Procedure for Field Welding Pipe to Wellhead Parts for Pressure Seal** and for field testing of the weld connection.


### Stage 2 — Nipple Up The BOP Stack

- Examine the 13-5/8" 5M x 19.00" 4 Stub Acme Threaded Hub (Item R1). Verify the following:
  - Acme thread are clean and in good condition
  - remove the (4) retainer set screws an place them in a safe place
- 2. Thoroughly clean and lightly lubricate the mating threads of the housing and the Thread Hub with Copper Coat or Never Seize.
- 3. Pick up the Hub and carefully thread it onto the top of the housing with counter clockwise rotation until the top of the ring is approximately a 1/4" below the top of the housing.
- Position the hub gage ring on top of the housing with the counter bore down as indicated. Ensure the gage ring is level and straight.
- 5. Rotate the Hub clockwise (UP) until it contacts the gage ring.

WARNING: Do not off seat the gage ring.

- 6. Locate the retainer screw holes in the threaded hub.
- 7. Rotate the Hub up or down to align the holes in the hub with the notches in the housing.
- 8. Install the set screws and tighten securely. Remove gage ring.
- Make up the 13-5/8" 5M Quick Connect x 13-5/8" 5M Studded Adapter (Item R2) to the bottom of the BOP stack using a new BX-160 Ring Gasket.
- 10. Thoroughly clean the MBU-3T hub, ring groove and the mating clamp segments and ring groove of the Adapter attached to the BOP stack.
- 11. Install a new **BX-160** Ring Gasket into the ring groove of the housing.
- 12. Pick up the BOP stack and carefully lower it over the top of the housing and land it on the ring gasket.





- 13. Ensure the BOP is level and then carefully run in all of the drive screws of the upper adapter to contact point.
- 14. Ensure the assembly remains level, run in one actuation and torque to 100 ft lbs.
- 15. Locate the screw 180° from the first and torque it to 100 ft lbs.
- 16. Locate the screws 90° to the right and left and torque them to 100 ft lbs.

- 17. Position the second 4 point sequence 90° from the first and torque each screw to 200 ft lbs.
- Run in all remaining screws to contact and then torque each screw to 400 ft lbs.
- Make one additional round until a stable torque of 400 ft lbs on all (16) screws is achieved.



INFORMATION CONTAINED HEI J THE PROPERTY OF CACTUS WELLHEAD, REPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC.

#### Stage 3 — Test the BOP Stack

Immediately after making up the BOP stack and periodically during the drilling of the well for the next casing string the BOP stack (connections and rams) must be tested.

- Examine the 13-5/8" Nominal x 4-1/2" IF (NC-50) CW Test Plug/ Retrieving Tool (Item ST1). Verify the following:
  - 1-1/4" VR plug and weep hole plug are in place and tightened securely
  - elastomer seal is in place and in good condition
  - retractable lift lugs are in place, clean, and free to move
  - drill pipe threads are clean and in good condition
- Position the test plug with the elastomer seal down and the lift lugs up and make up the tool to a joint of drill pipe.

WARNING: Ensure that the lift lugs are up and the elastomer seal is down

- 3. Remove the 1/2" NPT pipe plug from the weep hole if pressure is to be supplied through the drill pipe.
- 4. Open the housing lower side outlet valve.
- 5. Lightly lubricate the test plug seal with oil or light grease.
- Carefully lower the test plug through the BOP and land it on the load shoulder in the housing, 29.69" below the top of the drilling adapter.
- Close the BOP rams on the pipe and test the BOP to 5000 psi or as required by site supervisor.

**Note:** Any leakage past the test plug will be clearly visible at the open side outlet valve.

 After a satisfactory test is achieved, release the pressure and open the rams.



9. Remove as much fluid as possible from the BOP stack and the retrieve the test plug with a straight vertical lift.

**Note:** When performing the BOP blind ram test it is highly recommended to suspend a stand of drill pipe below the test plug to ensure the plug stays in place while disconnecting it from the drill pipe.

10. Repeat this procedure as required during the drilling of the hole section.



## INFORMATION CONTAINED HER. , THE PROPERTY OF CACTUS WELLHEAD, . REPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC.

### Stage 4 — Run the Lower Wear Bushing

Note: Always use a Wear Bushing while drilling to protect the load shoulders from damage by the drill bit or rotating drill pipe. The Wear Bushing **must be retrieved** prior to running the casing.

- 1. Examine the **13-5/8" Nominal MBU-3T-LWR Wear Bushing (Item ST2).** Verify the following
  - internal bore is clean and in good condition
  - upper trash o-ring is in place and in good condition
  - shear o-ring cord is in place and in good condition
  - paint anti-rotation lugs white and allow paint to dry

#### Run the Wear Bushing Before Drilling

- Orient the 13-5/8" Nominal x 4-1/2" IF (NC-50) CW Test Plug/Retrieving Tool (Item ST1) with drill pipe connection up.
- 3. Attach the Retrieving Tool to a joint of drill pipe.

WARNING: Ensure that the lift lugs are down and the elastomer seal is up

4. Align the retractable lift lugs of the tool with the retrieval holes of the bushing and carefully lower the tool into the Wear Bushing until the lugs snap into place.

**Note:** If the lugs did not align with the holes, rotate the tool in either direction until they snap into place.

- 5. Apply a heavy coat of grease, not dope, to the OD of the bushing.
- 6. Ensure the BOP stack is drained and free of any debris from previous test.
- 7. Slowly lower the Tool/Bushing Assembly through the BOP stack and land it on the load shoulder in the housing, 29.69" below the top of the drilling adapter.
- 8. Rotate the drill pipe clockwise (right) to locate the stop lugs in their mating notches in the head. When properly aligned the bushing will drop an additional 1/2".

**Note:** The Shear O-Ring on bottom of the bushing will locate in a groove above the load shoulder in the head to act as a retaining device for the bushing.



- 9. Remove the tool from the Wear Bushing by rotating the drill pipe counter clockwise (left) 1/4 turn and lifting straight up.
- 10. Drill as required.

**Note:** It is highly recommended to retrieve, clean, inspect, grease, and reset the wear bushing each time the hole is tripped during the drilling of the hole section.

#### **Retrieve the Wear Bushing After Drilling**

- 11. Make up the Retrieving Tool to the drill pipe.
- 12. Drain BOP stack and wash out if necessary.
- 13. Slowly lower the tool into the Wear Bushing.
- 14. Rotate the Retrieving Tool clockwise until a positive stop is felt. This indicates the lugs have snapped into the holes in the bushing.
- 15. Using the top drive, slowly pick up on the landing joint in 1000 lbs increments until the busing starts to rise. This action should take a minimum of 3000 lbs pull. Do Not Exceed 60,000 lbs.
- 16. Retrieve the Wear Bushing, and remove it and the Retrieving Tool from the drill string.



#### Stage 5 — Hang Off the 9-5/8" Casing

- Examine the 13-5/8" x 9-5/8" CW-MBU-3T-TP4 Casing Hanger Running Tool (Item ST3). Verify the following:
  - internal bore and threads are clean and in good condition
  - o-ring seal is clean and in good condition
  - torque dogs are in place, in upper most position and retainer set screws are tightened securely
- 2. Make up a landing joint to the top of the Running Tool and torque connection to thread manufacturer's maximum make up torque.
- 3. Lay down the landing joint on the pipe rack.
- 4. On the pipe rack, examine the 13-5/8" x 9-5/8" CW-MBU-3T-TP4 Mandrel Casing Hanger (Item A11). Verify the following:
  - internal bore and threads are clean and in good condition
  - neck seal area is clean and undamaged
  - torque slots are clean and in good condition
  - pin threads are clean and in good condition. Install thread protector
  - paint indicator groove white as indicated and allow paint to dry
- Liberally lubricate the mating threads, seal areas and o-ring of the hanger and running tool with a oil or light grease.
- 6. <u>Using chain tongs only</u>, thread the Running Tool into the hanger, with right hand rotation, until it shoulders out on the Hanger body.

WARNING: Do Not apply torque to the Hanger/Tool connection.

**Note:** If steps 1 through 6 were done prior to being shipped to location, the running tool should be backed off 1 turn and made back up to ensure it will back off freely.



- 7. Calculate the total landing dimension by adding the previously determined RKB dimension and 29.69", the depth of the wellhead.
- 8. Starting at the top of the 45° angle load shoulder of the casing hanger measure up the landing joint and place a paint mark on the joint. Mark HANGER LANDED.
- 9. Place a second mark 30" below the first and mark STOP ROTATING.
- 10. Run the 9-5/8" casing as required and space out appropriately for the mandrel casing hanger.



INFORMATION CONTAINED HER. THE PROPERTY OF CACTUS WELLHEAD, CEPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC

Stage 5 — Hang Off the 9-5/8" Casing



**Note:** If the 9-5/8" casing becomes stuck and the mandrel casing hanger cannot be landed, Refer to **Stage 5A** for the emergency slip casing hanger procedure.

- 11. Pick up the casing hanger/running tool joint assembly.
- 12. Remove the casing hanger thread protector and carefully thread the hanger into the last joint of casing ran. Rotate the hanger clockwise, by hand, to a positive stop.
- 13. Rotate the running tool clockwise by hand to a positive stop.

IP 0571 Page 10



## INFORMATION CONTAINED HEI 3 THE PROPERTY OF CACTUS WELLHEAD, REPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC.

#### Stage 5 — Hang Off the 9-5/8" Casing

14. Locate the (4) 3/8" socket head set screws in the side of the hanger running tool and remove the screws.

**WARNING:** Place the screws in a safe place to reinstall in the tool when the job is completed.

**Note:** This will release the running tool torque dogs allowing them to move downward.

15. Using only chain tongs, rotate the running tool to the left to allow the torque dogs to engage the torque slots in the top of the hanger.

WARNING: Do not rotate the running tool more than 1/4 turn to the left. Doing so will decrease the torque dog engagement





### Stage 5 — Hang Off the 9-5/8" Casing

16. Engage the CRT tool on the landing joint and torque the casing hanger in the casing string to thread manufacturer's maximum make up torque.





INFORMATION CONTAINED HEF J THE PROPERTY OF CACTUS WELLHEAD, REPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC.

### Stage 5 — Hang Off the 9-5/8" Casing

- 17. Pick up the casing string and remove the floor slips and rotary bushings.
- 18. Carefully lower the hanger completely through the BOP annular and then engage the top drive to allow the casing to be rotated clockwise.
- 19. While rotating the casing clockwise, carefully lower the casing string until the **STOP ROTATING** mark on the landing joint is level with the rig floor.

**Note:** The torque dogs have a maximum rated capacity of 18,000 ft lbs.





Chisholm Energy 13-3/8" x 9-5/8" x 5-1/2" 5/10M MBU-3T Wellhead, With CTH-HPS-F MOD Tubing Head

IP 0571 Page 13

## INFORMATION CONTAINED HER. , THE PROPERTY OF CACTUS WELLHEAD, . . . REPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC .

### Stage 5 — Hang Off the 9-5/8" Casing

WARNING: Torque wrap can build in the casing string as it is rotated. Ensure the string comes to a neutral position, by allowing it to back off slowly counter clockwise, before the casing hanger is fully landed.

- 20. Cease rotation and continue carefully lowering the hanger through the wellhead and land it on the load shoulder in the MBU-3T housing, 29.69" below the top of the drilling adapter.
- 21. Slack off all weight on the casing and verify that the **HANGER LANDED** paint mark has aligned with the rig floor.
- 22. Open the MBU-3T housing lower outlet valve and drain the BOP stack.
- 23. Sight through the valve bore to confirm the hanger is properly landed. The white painted indicator groove will be clearly visible in the center of the open outlet valve.
- 24. Close the open valve and place a vertical paint mark on the landing joint to verify if the casing string rotates during the cementing process.
- 25. Cement the casing as required.

**Note:** Returns may be taken through the circulation slots and out the BOP or out the side outlets on the housing.

- 26. With cement in place, bleed off all pressure and remove the cementing head.
- 27. <u>Using Chain Tongs Only located</u> <u>180° apart</u>, retrieve the Running Tool and landing joint by rotating the landing joint counter clockwise (left) approximately 13 turns or until the tool comes free of the hanger.

WARNING: The rig floor tong may be used to break the connection but under no circumstances is the top drive to be used to rotate or remove the casing hanger running tool.



IP 0571 Page 14



#### Stage 5 — Hang Off the 9-5/8" Casing

#### Running the 13-5/8" Wash Tool

- Examine the 13-5/8" x 4-1/2" IF Wash Tool (Item ST5). Verify the following:
  - drill pipe threads and bore are clean and in good condition
  - all ports are open and free of debris
- 2. Orient the Wash Tool with drill pipe box up. Make up a joint of drill pipe to the tool.
- Carefully lower the Wash Tool through the BOP and land it on top of the 9-5/8" casing hanger, 28.20" below the top flange of the wellhead housing.
- 4. Place a paint mark on the drill pipe level with the rig floor.
- 5. Open the housing lower side outlet valve and drain the BOP stack.
- Using chain tongs, rotate the tool clockwise approximately 6 turns to loosen any debris that may be on top of the hanger flutes.
- Pick up on the tool approximately 1" and attach a high pressure water line or the top drive to the end of the drill pipe and pump water (at approximately 200 to 300 PSI on the rig pump) through the tool and up the BOP stack.
- While flushing, raise and lower the tool the full length of the wellhead and BOP stack. The drill pipe should be slowly rotated (approximately 20 RPM) while raising and lowering to wash the inside of the housing and BOP stack to remove all caked on debris.
- 9. Once washing is complete, land the wash tool on the hanger flutes.
- 10. Shut down pumps and allow the BOP stack to drain.



 Reengage the pump and fully wash the inside of the wellhead and the entire BOP one additional cycle ensuring the stopping point is with the was tool resting on top of the hanger flutes.

**Note:** Observe the returns at the open outlet valve. If returns are not clean, continue flushing until they are.

- Once the returns are clean and free of debris, retrieve the tool to the rig floor.
- 13. Using a bright light, sight through the bore of the BOP stack and observe the top of the hanger neck and flutes. Ensure that there are no dark areas on top of the flutes of the hanger.

**WARNING:** Continue washing until all debris is removed.



Chisholm Energy 13-3/8" x 9-5/8" x 5-1/2" 5/10M MBU-3T Wellhead, With CTH-HPS-F MOD Tubing Head

IP 0571 Page 15

## INFORMATION CONTAINED HER. , THE PROPERTY OF CACTUS WELLHEAD, LOW REPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC

### Stage 5A — Hang Off the 9-5/8" Casing (Emergency)

- 1. Cement the hole as required.
- 2. Drain the BOP stack through the housing side outlet valve.
- 3. Locate the actuation screw on the OD of the drilling adapter.
- 4. Using a hex drive, fully retract the actuation screws until they are slightly over flush with the glandnuts.
- Pick up on the BOP stack a minimum of 12" above the housing hub and secure with safety slings.
- 6. Washout as required.
- Examine the 13-5/8" x 9-5/8" MBU-3T Slip Casing Hanger (Item A11a). Verify the following:
  - slips and internal bore are clean and in good condition
  - all screws are in place
- There are two latch screws located in the top of the casing hanger. Using a 5/16" Allen wrench, remove the two latch screws located 180° apart and separate the hanger into two halves.
- 9. Place two boards on the lower adapter against the casing to support the Hanger.
- 10. Pick up one half of the hanger and place it around the casing and on top of the boards.
- 11. Pick up the second hanger half and place it around the casing adjacent the first half.
- 12. Slide the two hanger halves together ensuring the slip alignment pins properly engage the opposing hanger half.
- 13. Reinstall the latch screws and tighten securely.
- 14. Prepare to lower the hanger into the housing bowl.







### Stage 5A — Hang Off the 9-5/8" Casing (Emergency)

WARNING: Do Not Drop the Casing Hanger!

- Grease the Casing Hanger's body and remove the slip retaining screws.
- 16. Remove the boards and allow the hanger to slide into the housing bowl. When properly positioned the top of the hanger will be approximately 22.56" below the top of the housing.
- 17. Pull tension on the casing to the desired hanging weight and then slack off.

**Note:** A sharp decrease on the weight indicator will signify that the hanger has taken weight and at what point, If this does not occur, pull tension again and slack off once more.

WARNING: Because of the potential fire hazard and the risk of loss of life and property, It is highly recommended to check the casing annulus and pipe bore for gas with an approved sensing device prior to cutting off the casing. If gas is present, do not use an open flame torch to cut the casing. It will be necessary to use a air driven mechanical cutter which is spark free.

- Rough cut the casing approximately 4" above the top of the housing and move the excess casing out of the way.
- 19. Using the Wach's internal casing cutter, final cut the casing at 17.54" ± 1/8" below the top of the lower adapter or 5.02" ± 1/8" above the hanger body.
- 20. Remove the internal casing cutter assembly and reconfigure the assembly to bevel the casing. Reinstall the cutter assembly and then place a 3/16" x 3/8" bevel on the O.D. and a I.D. chamfer to match the minimum bore of the packoff to be installed.



**Note:** There must not be any rough edges on the casing or the seals of the Packoff will be damaged.

- 21. Thoroughly clean the housing bowl, removing all CEMENT AND CUTTING DEBRIS.
- 22. Locate the two anti-rotation notches in the top of the sip bowl.
- Place a straight edge on top of the slip bowl and in line with the center of one of the notches.
- 24. Ensure the straight edge is vertical and then place a paint mark on top of the housing in line with the notch in the slip bowl.



## INFORMATION CONTAINED HER. , THE PROPERTY OF CACTUS WELLHEAD, L. REPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC.

## Stage 6 — Install the MBU-3T Mandrel Hanger Packoff

The following steps detail the installation of the MBU-3T Nested Packoff Assembly for the mandrel hanger. If the casing was landed using the emergency slip hanger, skip this step and proceed with Stage 6A for installing the emergency MBU-3T Nested packoff.

- 1. Examine the 13-5/8" x 11.250" 4 Stub Acme 2G LH box top MBU-3T Mandrel Hanger Nested Packoff Assembly (Item A12). Verify the following:
  - all elastomer seals are in place and undamaged
  - internal bore, and ports, are clean and in good condition
  - lockring is fully retracted
  - energizer ring is in its upper most position and retained with shear pins and stop screws are loose
  - anti-rotation plungers are in place, free to move
- 2. Inspect the ID and OD seals for any damage and replace as necessary.
- 3. Examine the 13-5/8" Nominal x 11.250" 4 Stub Acme 2G LH, MBU-3T Nested Packoff Running Tool (Item ST6). Verify the following:
  - Acme threads are clean and in good condition
  - retrieval latch is in position and retained with cap screws
  - Remove seal sleeve protector sleeve
  - seal sleeve is in position and rotates freely
  - seal sleeve o-rings are in place and in good condition
  - reinstall seal sleeve protector
- 4. Remove the retrieval latch and set aside.





#### INFORMATION CONTAINED HE I IT THE PROPERTY OF CACTUS WELLHEAD, REPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC

#### Stage 6 — Install the MBU-3T Mandrel Hanger Packoff

- Make up the running tool to 4-1/2" IF (NC-50) drill pipe and torque the connection to optimum make up torque.
- 6. Pick up the Running Tool with landing joint and suspend it above the packoff.
- 7. Remove the tool protector sleeve with counter clockwise rotation and set the sleeve aside.
- 8. Thoroughly clean and lightly lubricate the mating Acme threads of the running tool and packoff with oil or light grease.
- 9. Lightly lubricate the seal sleeve o-rings with oil or a light grease.
- 10. Carefully lower the tool into the packoff and thread them together by first rotating the tool clockwise (RIGHT) to locate the thread start and then counter clockwise (LEFT) until the tool upper body makes contact with the packoff Energizing Ring. Approximately 4 turns.
- 11. Install (1) 1/8" NPT pipe plug in the OD test port of the packoff and tighten securely.
- 12. Attach a test pump to the remaining open port and inject test fluid between the seal sleeve o-rings until a stable test pressure of 5000 psi is achieved.
- 13. If the test fails, remove the tool and replace the leaking o-rings.
- 14. After a satisfactory test is achieved remove the test pump and the 1/8" pipe plug from the opposite test port.

WARNING: All 1/8" pipe plugs must be removed prior to installing the packoff

 Pick up the assembly and thoroughly clean and lightly lubricate the packoff ID 'S' seals and the OD dovetail seals with oil or light grease.





### Stage 6 — Install the MBU-3T Mandrel Hanger Packoff

#### Landing the Packoff

- 16. Remove the hole cover.
- Measure up 5 foot from the paint mark on the OD of the packoff and place a paint mark on the drill pipe.
- 18. Pick up the packoff/running tool assembly and carefully lower the assembly through the BOP marking the landing joint every five feet until the calculated dimension is reached.
- Place a paint mark on the landing joint at that dimension and mark land off. Place an additional mark 1-1/2" above the first one and mark engaged.
- 20. Continue lowering the packoff until it passes over the neck of the hanger and lands on the casing hanger neck, 23.23" below the top of the drilling adapter.
- 21. Locate the upper 1" sight port pipe plug and remove the plug
- 22. Look through the port to verify that the packoff is properly landed. The white paint scribe line will be clearly visible in the center of the open port.
- 23. Reinstall the pipe plug and tighten securely.





### Stage 6 — Install the MBU-3T Mandrel Hanger Packoff

#### Seal Test

- 24. Locate the upper and lower seal test fittings on the O.D. of the housing and remove the dust cap from the fittings.
- 25. Attach a test pump to the open lower fitting and pump clean test fluid between the seals until a stable test pressure of 5,000 psi is achieved.
- 26. Hold test pressure for 5 minutes.
- 27. If a leak develops, bleed off test pressure, remove the packoff from the wellhead and replace the leaking seals.
- 28. Repeat steps 24 through 27 for the remaining seal test.
- 29. After satisfactory tests are achieved, bleed off the test pressure but leave the test manifolds in place.

#### **Engaging the Lockring**

- 30. Using chain tongs only located 180° apart, slowly rotate the drill pipe counter clockwise until the anti-rotation plungers align with the slots in the top of the hanger. Expect torque of approximately 400 ft lbs. to rotate the packoff.
- Using only chain tongs, rotate the landing joint approximately 6 to 6-1/2 turns counter clockwise to engage the packoff lockring in its mating groove in the bore of the MBU-LR housing.

**Note:** Approximately 800 to 900 ft. lbs. of torque will be required to break over the shear pins in the packoff. The torque will drop off and then increase slightly when the energizing ring pushes the lockring out. A positive stop will be encountered when the lockring is fully engaged.



**Note:** When properly engaged the second paint mark on the landing joint will align with the rig floor. VERIFY PAINT MARKS.

WARNING: It is imperative that the landing joint remain concentric with the well bore when rotating to engage the lockring. This can be accomplished with the use of the air hoist.

WARNING: If the required turns to engage the lockring are not achieved or excessive torque is encountered, remove the packoff and first call local branch and then Houston Engineering.

- 32. Back off the landing joint/running tool approximately three turns. Using the top drive, exert a 40,000 lbs, pull on the landing joint.
- 33. Reattach the test pump to the open test manifolds and retest the packoff seals to 5,000 psi for 15 minutes. This will also verify that the packoff is in place.
- 34. After satisfactory test is achieved, bleed off all test pressure, remove test pump and reinstall the dust cap on the open fittings.
- 35. Using only chain tongs, rotate the landing joint clockwise until the tool comes free of the packoff (approximately 9 to 9-1/2 turns) and then retrieve the tool with a straight vertical lift.



## INFORMATION CONTAINED HER THE PROPERTY OF CACTUS WELLHEAD, CONTAINED HER THE PROPERTY OF CACTUS WELLHEAD, CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC .

### Stage 6 — Install the MBU-3T Mandrel Hanger Packoff

In the event the packoff is required to be removed after the lockring is engaged the following procedure is to be followed.

#### **Retrieving the Packoff**

- 1. Position the retrieval latch so the latch finger extend from the bottom of the running tool body.
- 2. Reinstall the cap screws and tighten them securely.
- 3. Ensure the retrieval latch freely rotates on the running tool body.
- Carefully lower the running tool through the BOP stack and into the packoff.
- Rotate the drill pipe clockwise (Right) to locate the thread start and then counter clockwise (Left) (approximately 9 to 9-1/2 turns) to a positive stop.

**Note:** At this point the retrieval latches will have passed over the energizing ring and snapped into place.

 Rotate the drill pipe clockwise (right) approximately 6 turns to a positive stop. The drill pipe should rise approximately 1-1/2".

Warning: Do not exceed the 6 turns or the packoff may be seriously damaged.

- Carefully pick up on the drill pipe and remove the packoff from the MBU-3T wellhead with a straight vertical lift.
- 8. Rotate the packoff 1 turn clockwise to relax the retrieval latch.
- 9. Remove the (4) 1/2" cap screws and remove the latch assembly.



- 10. Redress the Packoff and reset as previously outlined.
- 11. Once the packoff is properly set, reinstall the retrieval latch on the tool.

**Cactus** Wellhead

#### Stage 6A — Install the MBU-3T Emergency Packoff

- 1. Examine the 13-5/8" 10M x 9-5/8" x 11.250" 4 Stub Acme 2G LH box top MBU-3T Emergency Nested Packoff Assembly (Item A12a). Verify the following:
  - all elastomer seals are in place and undamaged
  - internal bore, and ports, are clean and in good condition
  - lockring is fully retracted
  - energizer ring is in its upper most position and retained with shear pins
- 2. Inspect the ID and OD seals for any damage and replace as necessary.
- 3. Examine the 13-5/8" Nominal x 11.250" 4 Stub Acme 2G LH, MBU-3T Nested Packoff Running Tool (Item ST6). Verify the following:
  - Acme threads are clean and in good condition
  - retrieval latch is in position and retained with cap screws
  - seal sleeve is in position and rotates freely
  - seal sleeve o-rings are in place and in good condition
  - reinstall seal sleeve protector
- Make up a joint 4-1/2" IF (NC-50) drill pipe to the top of the Running Tool and tighten connection to thread manufacturer's maximum make up torque.
- 5. Run in the hole with two stands of drill pipe and set in floor slips.





## INFORMATION CONTAINED HER , THE PROPERTY OF CACTUS WELLHEAD, LEPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC

#### Stage 6A — Install the MBU-2LR Emergency Packoff

- 6. Pick up the packoff and carefully pass it over the drill pipe and set it on top of the floor slips.
- Pick up the running tool with landing joint and remove the tool protector sleeve with counter clockwise rotation and set the sleeve aside.
- 8. Thoroughly clean and lightly lubricate the mating acme threads of the running tool and packoff with oil or light grease.
- 9. Lightly lubricate the seal sleeve o-rings with oil or a light grease.
- 10. Make up the running tool to the drill pipe in the floor slips using the appropriate length pip x pin sub.
- Pick up the packoff and thread it onto the running tool with clockwise (Right) rotation until the Energizing Ring makes contact with the lower body of the tool. (Approximately 4 turns).
- 12. Install (1) 1/8" NPT pipe plug in the OD test port of the packoff and tighten securely
- 13. Attach a test pump to the remaining open port and inject test fluid between the seal sleeve o-rings until a stable test pressure of 5,000 psi is achieved.
- 14. If the test fails, remove the tool and replace the leaking o-rings.
- After a satisfactory test is achieved remove the test pump and the 1/8" pipe plug from the opposite test port.

**WARNING:** All 1/8" pipe plugs must be removed prior to installing the packoff

16. Thoroughly clean and lightly lubricate the packoff ID 'HPS' seals and the OD dovetail seals with oil or light grease.



17. Using a straight edge positioned vertically and centered on the anti-rotation lug on the bottom of the packoff, place a white paint mark up the side of the packoff in line with the lug.

**Note:** The line will be used to guide the packoff anti-rotation lug into its mating notch in the slip bowl.



#### Stage 6A — Install the MBU-2LR Emergency Packoff

#### Landing the Packoff

- 18. Pick up the drill string and remove the floor slips.
- 19. Carefully lower the packoff through the rig floor and position it just above the housing.
- 20. Align the white paint line with the existing paint mark on top of the housing.
- 21. While holding the packoff to maintain alignment, carefully lower the packoff into the housing until it lands on top of the slip hanger.

**Note:** When properly positioned the top of the running tool will be approximately 30.12" above the top of the MBU-3T Housing.

22. Remove the upper 1" LP pipe plug from the sight port to verify the packoff is properly landed. The 5/16" scribe line should be clearly visible in the center of the port.

With landing verified, reinstall the pipe plug and tighten securely.





## INFORMATION CONTAINED HER. THE PROPERTY OF CACTUS WELLHEAD, CRUSE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC.

### Stage 6A — Install the MBU-2LR Emergency Packoff

#### Seal Test

- 1. Locate the upper and lower seal test fittings on the O.D. of the housing and remove the dust cap from the fittings.
- Attach a test pump to the open lower fitting and pump clean test fluid between the seals until a stable test pressure of 5,000 psi is achieved.
- 3. Hold test pressure for 5 minutes.
- If a leak develops, bleed off test pressure, remove the packoff from the wellhead and replace the leaking seals.
- 5. After satisfactory test is achieved, bleed off the test pressure but leave the test manifold in place.
- Repeat steps 1 through 5 for the upper seal test port.

#### **Engaging the Lockring**

 Using only chain tongs, rotate the landing joint approximately 6 to 6-1/2 turns counter clockwise (Left) to engage the packoff lockring in its mating groove in the bore of the MBU-3T housing.

**Note:** Approximately 800 to 900 ft. lbs. of torque will be required to break over the shear pins in the packoff. The torque will drop off and then increase slightly when the energizing ring pushes the lockring out. A positive stop will be encountered when the lockring is fully engaged.



WARNING: It is imperative that the drill pipe landing joint remain concentric with the well bore when rotating to engage the lockring. This can be accomplished with the use of the air hoist.

WARNING: If the required turns to engage the lockring are not achieved or excessive torque is encountered, remove the packoff and first call local branch and then Houston Engineering.

- 8. Back off the landing joint/running tool approximately three turns. Using the top drive, exert a 40,000 lbs. pull on the landing joint.
- Reattach the test pump to the open test manifolds and retest the packoff seals to 5,000 psi for 15 minutes. This will also verify that the packoff is in place.
- 10. After satisfactory test is achieved, bleed off all test pressure, remove test pump and reinstall the dust cap on the open fittings.
- 11. Using only chain tongs, rotate the landing joint clockwise until the tool comes free of the packoff (approximately 9 to 9-1/2 turns) and then retrieve the tool with a straight vertical lift.
- 12. Reinstall and nipple up the BOP stack.



INFORMATION CONTAINED HEF J THE PROPERTY OF CACTUS WELLHEAD, REPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC.

#### Stage 7 — Test the BOP Stack

Immediately after making up the BOP stack and periodically during the drilling of the well for the next casing string the BOP stack (connections and rams) must be tested.

- Examine the 11" Nominal x 4-1/2" IF (NC-50) CW Test Plug/ Retrieving Tool (Item ST7). Verify the following:
  - 1-1/4" VR plug and weep hole plug are in place and tightened securely
  - elastomer seal is in place and in good condition
  - retractable lift lugs are in place, clean, and free to move
  - drill pipe threads are clean and in good condition
- Position the test plug with the elastomer seal down and the lift lugs up and make up the tool to a joint of drill pipe.

WARNING: Ensure that the lift lugs are up and the elastomer seal is down

- 3. Remove the 1/2" NPT pipe plug from the weep hole if pressure is to be supplied through the drill pipe.
- 4. Open the housing upper side outlet valve.
- 5. Lightly lubricate the test plug seal with oil or light grease.
- Carefully lower the test plug through the BOP and land it on the load shoulder in the packoff, 18.26" below the top of the drilling adapter.
- 7. Close the BOP rams on the pipe and test the BOP to 5,000 psi.



**Note:** Any leakage past the test plug will be clearly visible at the open side outlet valve.

- After a satisfactory test is achieved, release the pressure and open the rams.
- 9. Remove as much fluid as possible from the BOP stack and the retrieve the test plug with a straight vertical lift.

**Note:** When performing the BOP blind ram test it is highly recommended to suspend a stand of drill pipe below the test plug to ensure the plug stays in place while disconnecting from it with the drill pipe.

10. Repeat this procedure as required during the drilling of the hole section.



### Stage 8 — Run the Upper Wear Bushing

Note: Always use a Wear Bushing while drilling to protect the load shoulders from damage by the drill bit or rotating drill pipe. The Wear Bushing **must be retrieved** prior to running the casing.

- 1. Examine the 13-5/8" x 11" x 9.00" ID MBU-3T-UPR Wear Bushing (Item ST8). Verify the following
  - internal bore is clean and in good condition
  - o-ring is in place and in good condition
  - shear o-ring cord is in place and in good condition
  - paint anti-rotation lugs white and allow paint to dry

## Run the Wear Bushing Before Drilling

- Orient the 13-5/8" Nominal x 4-1/2" IF (NC-50) CW Test Plug/ Retrieving Tool (Item ST1) with drill pipe connection up.
- 3. Attach the Retrieving Tool to a joint of drill pipe.

WARNING: Ensure that the lift lugs are down and the elastomer seal is up

 Align the retractable lift lugs of the tool with the retrieval holes of the bushing and carefully lower the tool into the Wear Bushing until the lugs snap into place.

**Note:** If the lugs did not align with the holes, rotate the tool in either direction until they snap into place.

#### 5. Apply a heavy coat of grease, not dope, to the OD of the bushing.

- 6. Ensure the BOP stack is drained and free of any debris from previous test.
- Slowly lower the Tool/Bushing Assembly through the BOP stack and land it on the load shoulder in the housing, 18.26" below the top of the drilling adapter.
- 8. Rotate the drill pipe clockwise (right) to locate the stop lugs in their mating notches in the head. When properly aligned the bushing will drop an additional 1/2".



**Note:** The Shear O-Ring on bottom of the bushing will locate in a groove above the load shoulder in the head to act as a retaining device for the bushing.

- 9. Remove the tool from the Wear Bushing by rotating the drill pipe counter clockwise (left) 1/4 turn and lifting straight up.
- 10. Drill as required.

**Note:** It is highly recommended to retrieve, clean, inspect, grease, and reset the wear bushing each time the hole is tripped during the drilling of the hole section.

#### **Retrieve the Wear Bushing After Drilling**

- 11. Make up the Retrieving Tool to the drill pipe.
- 12. Drain BOP stack and wash out if necessary.
- 13. Slowly lower the tool into the Wear Bushing.
- 14. Rotate the Retrieving Tool clockwise until a positive stop is felt. This indicates the lugs have snapped into the holes in the bushing.
- 15. Using the top drive, slowly pick up on the landing joint in 1000 lbs increments until the busing starts to rise. This action should take a minimum of 3000 lbs pull. Do Not Exceed 60,000 lbs.
- 16. Retrieve the Wear Bushing, and remove it and the Retrieving Tool from the drill string.

IP 0571 Page 28



## INFORMATION CONTAINED HEI J THE PROPERTY OF CACTUS WELLHEAD, REPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC.

#### Stage 9 — Hang Off the 5-1/2" Casing

- 1. Run and cement the 5-1/2" casing string as required.
- 2. Open the housing upper side outlet valve to drain the BOP stack.
- Clean the ID of the BOP stack and OD of the casing with a high pressure water hose until returns through the open side outlet valve are clean and free of debris.
- 4. Thoroughly inspect the BOP stack to ensure all rams are fully retracted into their respective ram bores, the annular rubber is fully relaxed, all drilling adapters/spools are full opening and there are no casing collars between the rig floor and the wellhead.

**Note:** Side outlet valve to remain open while setting the casing hanger.

- 5. Examine the 11" x 5-1/2" C2 Slip Casing Hanger (Item A13). Verify the following:
  - slips and internal bore are clean and in good condition
  - all screws are in place
  - packoff rubber is in good condition

**Note:** Ensure that the packoff rubber does not protrude beyond the O.D. of the casing hanger body. If it does, loosen the cap screws in the bottom of the hanger.

- 6. Measure the distance from the rig floor to the top of the wellhead flange and record this measurement.
- 7. Pour a light oil through the BOP stack to thoroughly coat the OD of the casing.
- Using a 5/16" Allen wrench, remove the two latch screws located 180° apart on top of the hanger and separate the hanger into two halves.
- 9. Place two boards on the housing flange against the casing to support the hanger.
- 10. Pick up one half of the hanger and place it around the casing and on top of the boards.
- 11. Pick up the second hanger half and place it around the casing adjacent the first half.



- 12. Slide the two hanger halves together ensuring the slip guide pins properly engage the opposing hanger half.
- 13. Reinstall the latch screws and tighten securely.
- 14. Using a 5/16" allen wrench, remove the slip retainer cap screws and discard them.
- 15. Lubricate the OD of the Casing Hanger liberally with a light grease or oil.
- 16. Prepare to lower the hanger through the BOP stack.



## INFORMATION CONTAINED HER. , THE PROPERTY OF CACTUS WELLHEAD, . . . REPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC .

### Stage 9 — Hang Off the 5-1/2" Casing

**WARNING:** Do not drop or allow the hanger to fall through the BOP stack.

One method commonly used is to loop or tie four lengths of soft line through the hanger eye bolts as shown. Tie a knot in the soft line at the measurement noted in step six (6).

**Note:** The soft line may stretch and give an imprecise indication of the Casing Hanger's location.

- 17. Remove the boards and allow the Casing Hanger to slide through the BOP and into the MBU-3T packoff bowl using the cat line to center that casing if necessary.
- 18. When the Casing Hanger is down as indicated by the knots in the soft line, pull tension to the desired hanging weight and slack off.

**Note:** A sharp decrease on the weight indicator will signify that the Hanger has taken weight and at what point.

- 19. Untie the soft lines and pull them back through the lift eyes or drop them inside the BOP stack.
- 20. Prior to nippling down the BOP the integrity of the slip hanger seal can be verified by closing the BOP annular on the casing string and applying customer specific pressure through the kill line.
- 21. Once a satisfactory test is achieved, bleed off all test pressure, and drain the BOP stack.
- 22. Locate the actuation screws on the OD of the lower drilling adapter.
- 23. Using a hex drive, fully retract the (16) actuation screws until they are slightly over flush with the glandnuts.
- 24. Pick up on the BOP stack a minimum of 12" above the housing and secure with safety slings.
- 25. Remove the four lift eyes.
- 26. Rough cut the casing approximately 8" above the top of the housing and move the excess casing out of the way.
- 27. Final cut the casing at 5-3/4" ± 1/8" above the top flange of the housing.
- Grind the casing stub level and then place a 3/16" x 3/8" bevel on the O.D. and a I.D. chamfer to match the minimum bore of the tubing head to be installed.





- 29. Thoroughly clean the top of the housing and Casing Hanger. Ensure all cutting debris are removed.
- 30. Thoroughly clean and lightly lubricate the mating acme threads of the MBU-3T packoff and the slip *Hold Down Ring (Item A14)*.
- 31. Thread the ring into the packoff with counter clockwise rotation to a positive stop on top of the slip hanger.
- 32. Re-land the BOP stack and prepare to remove the upper adapter with the BOP stack



## INFORMATION CONTAINED HEF: J THE PROPERTY OF CACTUS WELLHEAD, REPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC.

#### Stage 10 — Install the 'Quick Connect' TA Cap Assembly

- 1. Examine the 13-5/8" 5M 'Quick Connect' TA Cap Assembly (Item R3). Verify the following:
  - bore is clean and free of debris
  - ring groove is clean and undamaged
  - (16) drive screws and clamp segments are properly installed and fully retracted
  - 5-1/2" HPS seal bushing is in place and properly retained with the square snap wire
- Thoroughly clean the top of the MBU-3T housing, thread hub, and the mating seal surfaces of the TA Cap.
- 3. Install a new **BX-160** Ring Gasket into the ring groove of the housing.
- Using a suitable lifting devise with weight rated slings, pick up the TA Cap assembly and carefully lower it over the casing stub and land it on the ring gasket.
- 5. Ensure the TA Cap is level and then carefully run in all of the drive screws of the TA Cap to contact point.
- Ensure the assembly remains level, run in one actuation and torque to 100 ft lbs.
- 7. Locate the screw 180° from the first and torque to 100 ft lbs.
- 8. Locate the screws 90° to the right and left and torque to 100 ft lbs.
- Position the second 4 point sequence 90° from the first and torque each screw to 200 ft lbs
- 10. Run in all remaining screws to contact and then torque each screw to 400 ft lbs.
- 11. Make one additional round until a stable torque of 400 ft lbs on all (16) screws is achieved.







INFORMATION CONTAINED HER. THE PROPERTY OF CACTUS WELLHEAD, CONTRICTOR, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC.

#### Stage 10 — Install the 'Quick Connect' TA Cap Assembly

#### **Connection Test**

- 1. Open the TA Cap ball valve and the housing upper side outlet valve to monitor leakage.
- 2. Locate the two test fittings marked flange test and remove the dust caps from the fittings.
- 3. Attach a bleeder tool to one of the open fitting and open the tool.
- 4. Attach a test pump to the remaining open fitting and pump clean test fluid into the void area until a continuous stream flows from the open bleeder tool.
- Close the tool and continue pumping fluid until a stable test pressure of 5,000 psi or 80% of casing collapse is achieved, whichever is less.
- 6. Hold test pressure for 15 minutes.
- After a satisfactory test is achieved, bleed off the test pressure, drain the fluid, remove the bleeder tool and re install the dust cap on the open fittings.
- 8. Close all open valves.





## INFORMATION CONTAINED HEI 3 THE PROPERTY OF CACTUS WELLHEAD, REPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC.

### Stage 11 — Remove the TA Cap Assembly

- 1. Open the ball valve on the TA cap to check for trapped pressure above the casing hanger.
- 2. Locate the actuation screws on the OD of the TA Cap Assembly.
- Using a hex drive, fully retract the actuation screws until they are slightly over flush with the glandnuts.
- 4. Install a lift eye with pick up sling to the top of the TA Cap and lift the cap free of the wellhead.
- 5. Remove the thread hub set screws.
- 6. Remove the thread hub from the top of the housing with clockwise rotation.







## INFORMATION CONTAINED HERE S THE PROPERTY OF CACTUS WELLHEAD, LO REPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC.

#### Stage 11 — Remove the TA Cap Assembly

- 7. Examine the 13-5/8" 5M Thread Flange. Verify the following:
  - Acme thread are clean and in good condition
- 8. Thoroughly clean and lightly lubricate the mating threads of the housing and the Thread Flange with Copper Coat or Never Seize.
- 9. Pick up the flange and carefully thread it onto the top of the housing with counter clockwise rotation until the top of the flange is level with the top of the Acme thread of the housing.
- 10. Rotate the flange in either direction to two hole.
- 11. Prepare to install the tubing head.





## INFORMATION CONTAINED HEF THE PROPERTY OF CACTUS WELLHEAD, EPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EAL OF SSLY AUTHORIZED BY CACTUS WELLHEAD, LLC

#### Stage 12 — Install the Tubing Head

**Note:** The tubing head may be shipped to location with the lower frac valve pre installed and tested.

- Examine the 13-5/8" 5M x 7-1/16" 10M CW, CTH-HPS-F MOD Tubing Head With 5-1/2" DBLHPS Bottom (Item B1) Verify the following:
  - seal area and bore are clean and in good condition
  - HPS-F MOD Secondary Seal Bushing is in place and properly retained with a square snap wire
  - all peripheral equipment is intact and undamaged
- 2. Clean the mating ring grooves of the MBU-3T Housing and tubing head.
- 3. Lightly lubricate the I.D. of the tubing head 'HPS' seals and the casing stub with a light oil or grease.





**Note:** Excessive oil or grease may prevent a good seal from forming!

- 4. Install a new **BX-160 Ring Gasket (Item B12)** in the ring groove of the housing.
- 5. Pick up the tubing head and suspend it above the housing.
- Orient the head so that the outlets properly align with the housing upper outlets and then carefully lower the head over the casing stub and then land it on the ring gasket.

Warning: Do Not damage the 'HPS' seals or their sealing ability will be impaired!

7. Make up the flange connection using the appropriate size *studs and nuts (Item B13)*, tightening them in an alternating cross pattern.



INFORMATION CONTAINED HER. THE PROPERTY OF CACTUS WELLHEAD, L CEPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC.

### Stage 12 — Install the Tubing Head

#### Seal Test

- Locate the seal test fitting and one flange test fitting on the Tubing Head lower flange and remove the dust cap from both fittings.
- 2. Attach a Bleeder Tool to one of the open flange test fittings and open the Tool.
- 3. Attach a test pump to the seal test fitting and pump clean test fluid between the HPS Seals until a test pressure of 10,000 psi or 80% of casing collapse Whichever is less.
- 4. Hold test pressure for 15 minutes.
- 5. If pressure drops, a leak has developed. Bleed off test pressure and take the appropriate action in the adjacent table.
- 6. After a satisfactory test is achieved, remove the Test Pump, drain test fluid and reinstall the dust cap on the open seal test fitting.



Seal Test		
Leak Location	Appropriate Action	
Open bleeder tool - Lower HPS seal is leaking	Remove Tubing Head and replace leaking seals. Re land and retest seals	
Into the tubing head bore - Upper HPS seal is leaking		



INFORMATION CONTAINED HERE IS THE PROPERTY OF CACTUS WELLHEAD, REPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC.

### Stage 12 — Install the Tubing Head

#### **Flange Test**

- Locate the remaining flange test fitting on the Tubing Head lower flange and remove the dust cap from the fitting.
- Attach a test pump to the open flange test fitting and inject test fluid into the flange connection until a continuous stream flows from the opposite flange test bleeder tool.
- 3. Close the bleeder tool and continue to pumping test fluid to 5,000 psi or 80% of casing collapse -Whichever is less..
- 4. Hold test pressure for 15 minutes.
- 5. If pressure drops a leak has developed. Take the appropriate action from the adjacent chart.
- 6. Repeat this procedure until a satisfactory test is achieved.
- 7. Once a satisfactory test is achieved, remove the test pump and bleeder tool, drain all test fluid, and reinstall the dust caps.



Flange Test	
Leak Location	Appropriate Action
Between flanges - Ring gasket is leaking	Verify flange bolt torque. If correct, remove tubing head to clean, inspect and possibly replace damaged ring gasket.



INFORMATION CONTAINED HER THE PROPERTY OF CACTUS WELLHEAD, CEPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC

# Recommended Procedure for Field Welding Pipe to Wellhead Parts for Pressure Seal

 Introduction and Scope. The following recommended procedure has been prepared with particular regard to attaining pressure-tight weld when attaching casing heads, flanges, etc., to casing. Although most of the high strength casing used (such as N-80) is not normally considered field weldable, some success may be obtained by using the following or similar procedures.

<u>Caution:</u> In some wellheads, the seal weld is also a structural weld and can be subjected to high tensile stresses. Consideration must therefore be given by competent authority to the mechanical properties of the weld and its heat affected zone.

- a. The steels used in wellhead parts and in casing are high strength steels that are susceptible to cracking when welded. It is imperative that the finished weld and adjacent metal be free from cracks. The heat from welding also affects the mechanical properties. This is especially serious if the weld is subjected to service tension stresses.
- b. This procedure is offered only as a recommendation. The responsibility for welding lies with the user and results are largely governed by the welder's skill. Weldability of the several makes and grades of casing varies widely, thus placing added responsibility on the welder. Transporting a qualified welder to the job, rather than using a less-skilled man who may be at hand, will, in most cases, prove economical. The responsible operating representative should ascertain the welder's qualifications and, if necessary, assure himself by instruction or demonstration, that the welder is able to perform the work satisfactorily.
- 2. Welding Conditions. Unfavorable welding conditions must be avoided or minimized in every way possible, as even the most skilled welder cannot successfully weld steels that are susceptible to cracking under adverse working conditions, or when the work is rushed. Work above the welder on the drilling floor should be avoided. The weld should be protected from dripping mud, water, and oil and from wind, rain, or other adverse weather conditions. The drilling mud, water, or other fluids must be lowered in the casing and kept at a low level until the weld has properly cooled. It is the responsibility of the user to provide supervision that will assure favorable working conditions, adequate time, and the necessary cooperation of the rig personnel.

- **3. Welding.** The welding should be done by the shielded metal-arc or other approved process.
- 4. Filler Metal. Filler Metals. For root pass, it's recommended to use E6010, E6011 (AC), E6019 or equivalent electrodes. The E7018 or E7018-A1 electrodes may also be used for root pass operations but has the tendency to trap slag in tight grooves. The E6010, E6011 and E6019 offer good penetration and weld deposit ductility with relatively high intrinsic hydrogen content. Since the E7018 and E7018-A1 are less susceptible to hydrogen induced cracking, it is recommended for use as the filler metal for completion of the weld groove after the root pass is completed. The E6010, E6011 (AC), E6019, E7018 and E7018-A1 are classified under one of the following codes AWS A5.1 (latest edition): Mild Steel covered electrodes or the AWS A5.5 (latest edition): Low Alloy Steel Covered Arc-Welding Electrodes. The low hydrogen electrodes, E7018 and E7018-A1, should not be exposed to the atmosphere until ready for use. It's recommended that hydrogen electrodes remain in their sealed containers. When a job arises, the container shall be opened and all unused remaining electrodes to be stored in heat electrode storage ovens. Low hydrogen electrodes exposed to the atmosphere, except water, for more than two hours should be dried 1 to 2 hours at 600°F to 700 °F (316°C to 371 °C) just before use. It's recommended for any low hydrogen electrode containing water on the surface should be scrapped.
- 5. Preparation of Base Metal. The area to be welded should be dry and free of any paint, grease/oil and dirt. All rust and heat-treat surface scale shall be ground to bright metal before welding.

**l'Cactus** 

INFORMATION CONTAINED HEI J THE PROPERTY OF CACTUS WELLHEAD, REPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC.

# Recommended Procedure for Field Welding Pipe to Wellhead Parts for Pressure Seal

- 6. Preheating. Prior to any heating, the wellhead member shall be inspected for the presence of any o-rings or other polymeric seals. If any o-rings or seals are identified then preheating requires close monitoring as noted in paragraph 6a. Before applying preheat, the fluid should be bailed out of the casing to a point several inches (>6" or 150 mm) below the weld joint/location. Preheat both the casing and wellhead member for a minimum distance of three (3) inches on each side of the weld joint using a suitable preheating torch in accordance with the temperatures shown below in a and b. The preheat temperature should be checked by the use of heat sensitive crayons. Special attention must be given to preheating the thick sections of wellhead parts to be welded, to insure uniform heating and expansion with respect to the relatively thin casing.
  - a. Wellhead members containing o-rings and other polymeric seals have tight limits on the preheat and interpass temperatures. Those temperatures must be controlled at 200°F to 325°F or 93 °C to 160°C and closely monitored to prevent damage to the o-ring or seals.
  - b. Wellhead members not containing o-rings and other polymeric seals should be maintained at a preheat and interpass temperature of 400°F to 600°F or 200°C to 300°C.
- 7. Welding Technique. Use a 1/8 or 5/32-inch (3.2 or 4.0 mm) E6010 or E7018 electrode and step weld the first bead (root pass); that, weld approximately 2 to 4 inches (50 to 100 mm) and then move diametrically opposite this point and weld 2 to 4 inches (50 to 100 mm) halfway between the first two welds, move diametrically opposite this weld, and so on until the first pass is completed. This second pass should be made with a 5/32-inch (4.0 mm) low hydrogen electrode of the proper strength and may be continuous. The balance of the welding groove may then be filled with continuous passes without back stepping or lacing, using a 3/16-inch (4.8 mm) low hydrogen electrode. All beads should be no undercutting and weld shall be workmanlike in appearance.
  - a. Test ports should be open when welding is performed to prevent pressure buildup within the test cavity.
  - b. During welding the temperature of the base metal on either side of the weld should be maintained at 200 to 300°F (93 to 149°C).
  - c. Care should be taken to insure that the welding cable is properly grounded to the casing, but ground wire should not be welded to the casing or the wellhead. Ground wire should be firmly clamped to the casing, the wellhead, or fixed in position between pipe slips. Bad contact may cause sparking, with resultant hard spots beneath which incipient cracks may develop. The welding cable should not be grounded to the steel derrick, nor to the rotary-table base.

- 8. Cleaning. All slag or flux remaining on any welding bead should be removed before laying the next bead. This also applies to the completed weld.
- 9. Defects. Any cracks or blow holes that appear on any bead should be removed to sound metal by chipping or grinding before depositing the next bead.
- **10. Postheating.** Post-heating should be performed at the temperatures shown below and held at that temperature for no less than one hour followed by a slow cooling. The post-heating temperature should be in accordance with the following paragraphs.
  - a. Wellhead members containing o-rings and other polymeric seals have tight limits on the post-heating temperatures. Those temperatures must be controlled at 250°F to 300°F or 120 °C to 150°C and closely monitored to prevent damage to the o-ring or seals.
  - b. Wellhead members not containing o-rings and other polymeric seals should be post-heated at a temperature of 400°F to 600°F or 200°C to 300°C.
- 11. Cooling. Rapid cooling must be avoided. To assure slow cooling, welds should be protected from extreme weather conditions (cold, rain, high winds, etc.) by the use of suitable insulating material. (Specially designed insulating blankets are available at many welding supply stores.) Particular attention should be given to maintaining uniform cooling of the thick sections of the wellhead parts and the relatively thin casing, as the relatively thin casing will pull away from the head or hanger if allowed to cool more rapidly. The welds should cool in air to less than 200°F (93°C) (measured with a heat sensitive crayon) prior to permitting the mud to rise in the casing.
- **12. Test the Weld.** After cooling, test the weld. The weld must be cool otherwise the test media will crack the weld. The test pressure should be no more than 80% of the casing collapse pressure.



#### **Cactus Speed Head Pressure Testing Statement**

Our procedure is to nipple up BOP's to the surface casing, pressure test the BOP's to 5000 psi high and 250 psi low. We do not anticipate breaking any seals on the BOP from that point until rig release, however if we do break any seal, the entire BOP will be retested to 5000 psi high and 250 psi low.

INFORMATION CONTAINED HEI 3 THE PROPERTY OF CACTUS WELLHEAD, REPRODUCTION, DISCLOSURE, OR USE THEREOF IS PERMISSIBLE ONLY AS PROVIDED BY CONTRACT OR AS EXPRESSLY AUTHORIZED BY CACTUS WELLHEAD, LLC.

#### **System Drawing**





Chisholm Energy 13-3/8" x 9-5/8" x 5-1/2" 5/10M MBU-3T Wellhead, With CTH-HPS-F MOD Tubing Head

IP 0571 Page 1