Submit 1 Copy To Appropriate District	State of New Mexico	Form C-103				
Office District I - (575) 393-6161	Revised July 18, 2013					
1625 N. French Dr., Hobbs, NM 88240	Energy, Minerals and Natural Resources	WELL API NO.				
<u>District II</u> - (575) 748-1283 811 S. First St., Artesia, NM 88210	OIL CONSERVATION DIVISION	30-025-05401 5. Indicate Type of Lease				
District III - (505) 334-6178 1000 Rio Brazos Rd., Aztec, NM 87410	1220 South St. Francis Dr.	STATE FEE				
<u>District IV</u> - (505) 476-3460	Santa Fe, NM 87505	6. State Oil & Gas Lease No.				
1220 S. St. Francis Dr., Santa Fe, NM 87505		1				
	ICES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name				
	SALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A CATION FOR PERMIT" (FORM C-101) FOR SUCH	TII Dawn (A)				
PROPOSALS.) 1. Type of Well: Oil Well	Gas Well Other	H.L. Batton 'A'				
	Gas well Guitel	8. Well Number 1				
2. Name of Operator SUNDOWN ENERGY LP		9. OGRID Number 232611				
3. Address of Operator		10. Pool name or Wildcat				
16400 DALLAS PARKWAY, ST	E. 100 DALLAS, TX 75248	Lovington Paddock; Pool ID 40660				
4. Well Location						
Unit LetterE :	1653 feet from the <u>NORTH</u> line and	330 feet from the WEST line				
Section 5	Township 17-S Range 37-E	NMPM LEA County				
	11. Elevation (Show whether DR, RKB, RT, GR, etc. 3808' GL	; <i>)</i>				
_						
12. Check A	Appropriate Box to Indicate Nature of Notice	, Report or Other Data				
		•				
NOTICE OF IN	PLUG AND ABANDON 🛛 REMEDIAL WO	BSEQUENT REPORT OF: RK □ ALTERING CASING □				
TEMPORARILY ABANDON		RILLING OPNS. P AND A				
PULL OR ALTER CASING	MULTIPLE COMPL CASING/CEMEN	NT JOB				
DOWNHOLE COMMINGLE						
CLOSED-LOOP SYSTEM OTHER: Plug TA	well OTHER: □					
13. Describe proposed or comp	leted operations. (Clearly state all pertinent details, a	nd give pertinent dates, including estimated date				
	ork). SEE RULE 19.15.7.14 NMAC. For Multiple Co	ompletions: Attach wellbore diagram of				
proposed completion or rec	ompletion.					
1) MIRU P&A rig.						
	ent on top of existing CIBP & cmt f/ 5900' - 6140	7 CCD				
•	cement 2900' – 3100' (Yates)	HOBBS OCD				
	cement 2400' – 2500' (Btm of Salt)					
	cement 1900' – 2150' (Surf csg shoe)	JUN 0 9 2020				
·	cement 1100' - 1200' (top of salt)	2014.0 0 505				
7) Perf and squeeze 25 sxs	cement from 0 to 200' (FW &surface plug).					
INSTALL	- 00 00 W , Z ,	RECEIVED				
7 N 3/2 (C	Diy hole marker	1/2				
Spud Date:	Rig Release Date:					
I hereby certify that the information above is true and complete to the best of my knowledge and belief.						
SIGNATURE DATE 6/8/2020						
Type or print name Belinda Bradley E-mail attaress: bbradley@sundownenergy.com PHONE 432-943-8770						
Approved by State Use Only						
APPROVED BY: DATE THE CONTROL DATE OF THE CONT						
Conditions of Approval (if any)						

See Attached Conditions of Approval

			F۲					

WELL DATA SHEET

LEASE:	Battan "A"		WELL:	#1	FIELD:
LOC:					
STATUS:	TA				
TD:	6300'	 _	<u></u>	Lon	·
	6295'		CO:	Lea Nov Movico	
PBTD:	0293		ST:	New Mexico	
					
			~ ™	Csg Detail	•
		li li	<u>+/</u>	Hole Size:	
		<u> </u>	الحلا	9 5/8"	OD, 32.5 #/ft, grade J-55, ST&C, new
			1 1	csg set @	2116' w/ 1200 sx.
		·		Circ?	Yes TOC @ Surface By Circulation
		1. 1		DLUG #61	25 sx perf and squeeze cement plug from 0 to 200°
			~ ~√	PLUG #6;	25 SX peri and squeeze cement plug from v to 200 (Fresh Wtr & Surface Plug)
		- 11	1-4	PLUG #5	(1 165H 17H & GHILDOW 1 16B)
			721	25 sx perf	and squeeze cement plug from 1100' to 1200'
			-		(Top of Salt)
		. ألم	/_	PLUG #4	
			<u> </u>	Surf Cag	and squeeze cement plug from 1900' to 2150'
				(aun cag	Silve)
	Top of cmt at 3380'				
	•				•
			1	Hole Size:	7 7/8" (10,600')
			1	5-1/2*	OD, 15.5 #/ft, gradeJ-55, LT&C, new
			Ī	csg set @ in	6298' w/ 800 sx. 1 stages w/DV tool @
					No TOC @ 3380' By CBL
			1	<u> </u>	100 g
			ŀ		
		~~~	4		
			┵.	PLUG #3	
					seze cement plug from 2400' to 2500' (Btm of Salt)
			1 '	as on post and oqu	to about plug it out a root to about (auth of outly
			1		
			i		
		. ~	۸		
		~ .	٦ ,	PLUG #2	
					seze cement plug from 2900' to 3100' (Yates)
			7		
			l l		C OCD
			ı		-a85
		-			4000
		•			0.3030
			1		" WY O B TOPE
			ŀ		7014
		1	I		-NEU
					-CEIVE
					REUL
		J	1		HOBBS OCD JUN 0 9 2020 RECEIVED
		j	1		
		Į.	1		
		1			
		-]			•
		i	1		
		1	1		
		1	1		
			4		
		ı	1 .	LUG #1	
		i i	•		ent plug 5900' to 6140' (Plug back Perfs)
	Dump Bailed CMT @ 6140"	<b></b>	9 .		, g ,g ,/
	CIBP @ 6180" w/ 40" cant on top		9		
			1		
		1 3	Ŧ ·	215' - 6290'	
		1 -	T		
		h~~~	4		
	PBTD = 621	95.	7		
	TD = 630		٨		

CURREN	IT WELLBORE		WELL DATA SHEE	<u>I</u>
LEASE:	Battan "A"		WELL: #1	FIELD:
LOC:				
STATUS:	TA 6300'		aà Las	
TD: PBTD:	6295		co: Lea ST: New Mexico	
roib.	<u> </u>		31. NOW INICALCO	
			Csg Detail	
	<del></del>	11		OD, 32.5 #/ft, grade J-55, ST&C, new
		11	csg set @	2116' w/ 1200 sx.
		1 1	Circ?	Yes TOC @ Surface By Circulation
	<del></del>			
		1 1		
			1 1	
		_ J		
		~	_	
	Top of cmt at 3380'			
			Ci	7.7/09 440.0000
			Hote Size: 5-1/2"	
		1	csg set @	
			in	1 stages w/DV tool @
			Circ?	No TOC @ 3380' By CBL
		i i		
		- 1	1	
				_
				C.D
				26
				"UBP"
				2:2030
				111 0 9 70Co
			:	JUNIO
				-11
				-ECEIVE
		l		REG
		1	Ì	HOBBS OCD JUN 0 9 2020 RECEIVED
		1		
		1		
		ď		
		ľ	1	
			<b>{</b>	
			1	
			1	
		l	1	
		I		

Dump Bailed CMT @ 8140' CIBP @ 8180' w/ 40' cmt on top

> PBTD = 6295' TD = 6300'

# CONDITIONS OF APPROVAL FOR PLUGGING AND ABANDONMENT OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify **NMOCD District Office I** (Hobbs) at (575)-263-6633 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down.

# Company representative will be on location during plugging procedures.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private- shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 8. Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
  - 11. Class 'C' cement will be used above 7500 feet.
  - 12. Class 'H' cement will be used below 7500 feet.
- 13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.
- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
  - 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).

- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
- A) Fusselman
- B) Devonian
- C) Morrow
- D) Wolfcamp
- E) Bone Springs
- F) Delaware
- G) Any salt sections
- H) Abo
- I) Glorieta
- J) Yates.
- K) Potash---(In the R-111-P Area (Potash Mine Area),

A solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, woe 4 hours and tag, this plug will be SO' below the bottom and 50' above the top of the Formation.

21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, woe and tagged. These plugs will be set SO' below formation bottom to 50' above formation top inside the casing

# **DRY HOLE MARKER REQ.UIRMENTS**

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

- 1. Operator name
- 2. Lease and Well Number
- 3. API Number
- 4. Unit letter
- 5. Quarter Section (feet from the North, South, East or West)
- 6. Section, Township and Range
- 7. Plugging Date
- 8. County

# SPECIAL CASES -----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION