

Submit 1 Copy To Appropriate District Office
District I - (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II - (575) 748-1283
811 S. First St., Artesia, NM 88210
District III - (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87410
District IV - (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised July 18, 2013

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO.
30-015-34222

5. Indicate Type of Lease

STATE ☒ FEE ☐

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name

Spud 16 State

8. Well Number

5

9. OGRID Number

6137

10. Pool name or Wildcat

Laguna Salado; Atoka (gas)

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☐ Gas Well ☒ **Oil**
NM OIL CONSERVATION
ARTESIA DISTRICT

2. Name of Operator
Devon Energy Production Company, LP

OCT 17 2018

3. Address of Operator
333 W. Sheridan Avenue, Oklahoma City, OK 73102

RECEIVED

4. Well Location

Unit Letter O:2320 feet from the South line and 660 feet from the East line

Section 16 Township 23S Range 29E NMPM Eddy County, NM

11. Elevation (Show whether DR, RKB, RT, GR, etc.)
2962' KB

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
DOWNHOLE COMMINGLE ☐
CLOSED-LOOP SYSTEM ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ P AND A ☐
CASING/CEMENT JOB ☐
OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Notify OCD 24 hrs. prior to any work done.

R-111-P

1. MIRU P&A Unit.
2. TOH 2-7/8" tubing.
3. Circ 10# Mud. Set CIBP @ 12100'.
4. Spot 20 sx CI C cmt 12000'-12100'. - WOC+T_{ny}
5. Spot 50 sx CI C cmt 9900'-10500'. WOC & Tag. (Liner top 10142', T. Wolfcamp 10070)
6. Spot 100 sx CI C 6500-7000. (T. Bone Spring 6687')
7. Spot 700 sx CI C 292-3600. WOC and Tag. (Shoes 342, 2948, T Bell Canyon 3035', B Salt 2775, T Salt 378, R-111P)
8. Spot 10 sx CI C 3'-33'.
9. Cut WH off 3' BGL, Set dry hole marker.

Spud Date:

10/24/2005

Rig Release Date:

12/13/2005

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Max Lubitz TITLE Production Engineer DATE 9/27/2018

Type or print name Max Lubitz E-mail address: max.lubitz@dv.com PHONE: 405-552-7825 or 580-302-4593

For State Use Only

APPROVED BY: [Signature] TITLE Staff Mgr. DATE 10-18-18
Conditions of Approval (if any):

*** See Attached COA's must be plugged by 10-18-19**

DEVON ENERGY PRODUCTION COMPANY LP

Well Name:	SPUD 16 ST 5			Field:	Potato Basin		
Location:	2320 FSL	660 FEL	SEC 16-T23S-R29E	County:	Eddy	State:	New Mexico
Elevation:	2962' GL			Spud Date:	10/24/2005	Compl Date:	3/1/2006
API#:	30-015-34222	Prepared by:	Max Lubitz	Date:	9/27/18	Rev:	

CURRENT WELLBORE

17-1/2" Hole
13-3/8", 48#, H-40 @ 353
 Cmt'd w/400 sx to surface

Base of Salt 2775
 Lamar Limestone 2993
 Bell Canyon 3035
 Cherry Canyon 3865
 Bone Spring 6687
 3rd Bone Spring Sand 9496
 Wolfcamp 10070
 Strawn 11535
 Atoka 11771

11" Hole
9-5/8", 40#, J55, @ 2948'
 Cmt'd w/1051 sx to surface

DV Tool @ 3500

2-7/8" tubing to 12024'

Perforations
12139-12165

8-3/4" Hole
7", 26#, P-110, @ 10500'
 Cmt'd w/1760 sx CI C cmt to SURF

6-1/8" hole
4-1/2" 13.5# P-110 Liner from 10142-12500
 Cmt'd with 330 sx CI H cmt

12500' TVD

DEVON ENERGY PRODUCTION COMPANY LP				
Well Name: SPUD 16 ST 5		Field: Potato Basin		
Location:	SEC 16-T23S-R29E	County: Eddy	State: New Mexico	
Elevation:		Spud Date: 10/24/2005	Compl Date: 3/1/2006	
API#: 30-015-34222	Prepared by:	Date:		Rev:

Field: Potato Basin

County: Eddy

State: New Mexico

Spud Date: 10/24/2005	Compl Date: 3/1/2006
-----------------------	----------------------

Date:

Rev:

PROPOSED WELLBORE

13-3/8", 48#, H-40 @ 353
Cmt'd w/400 sx to surface

1. Spot 10 sx Cl C 3'-33'.
2. Cut WH off 3' BGL, Set dry hole marker.

Spot 700 sx Cl C 292-3600. WOC and Tag.
(Shoes 342, 2948, T Bell Canyon 3035', B Salt
2775, T Salt 378, R-111P)

9-5/8", 40#, J55, @ 2948'
Cmt'd w/1051 sx to surface

Spot 100 sx Cl C 6500-7000.
(T. Bone Spring 6687')

1. Spot 50 sx Cl C cmt 9900'-10500'. WOC & Tag
(Liner top 10142', T. Wolfcamp 10070)

7", 26#, P-110, @ 10500'
Cmt'd w/1760 sx Cl (

4-1/2" 13.5# P-110 Liner from 10142-12500
Cmt'd with 330 sx Cl H cmt

1. Set CIBP @ 12100'.
2. Spot 20 sx Cl C cmt 12000'-12100'.

CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, **Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.**

1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs.
2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
3. Trucking companies being used to haul oilfield waste fluids to a disposal – commercial or private – shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
6. If the well is not plugged within 1
7. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
8. **Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.**
9. Produced water **will not** be used during any part of the plugging operation.
10. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
11. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
12. **Class 'C' cement will be used above 7500 feet.**
13. **Class 'H' cement will be used below 7500 feet.**
14. **A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged**
15. **All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing**

16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
17. **A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.**
18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, **(WOC 4 hrs and tag).**
19. **No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.**
20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) **Potash---** (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, **WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.**
21. **If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing**

DRY HOLE MARKER REQUIREMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

**1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter
Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date
8. County (SPECIAL CASES)-----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS**

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)