

Submit 3 Copies To Appropriate District Office

District I

1625 N. French Dr., Hobbs, NM 88240

District II

1301 W. Grand Ave., Artesia, NM 88210

District III

1000 Rio Brazos Rd., Aztec, NM 87410

District IV

1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

Form C-103
Revised June 10, 2003

WELL API NO.
30-015-33255

5. Indicate Type of Lease

STATE ☒ FEE ☐

6. State Oil & Gas Lease No.

K06527

7. Lease Name or Unit Agreement Name

Eaglette State

8. Well Number

001

9. OGRID Number

017985

10. Pool name or Wildcat

Seven Rivers

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

Oil Well ☒ Gas Well ☐ Other

RECEIVED

2. Name of Operator

MAR 14 2005

Premier Oil & Gas, Inc.

3. Address of Operator

P.O. Box 1246, Artesia, NM 88211-1246

4. Well Location

Unit Letter P : 330 feet from the South line and 330 feet from the East line

Section 25 Township 20S Range 27E NMPM Eddy County

11. Elevation (Show whether DR, RKB, RT, GR, etc.)

3297 GL

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

This C-103 is to correct the Plug and Abandon intention submitted 2/22/05.

The PBTD of this well is 1007'.

We propose to plug and abandon as follows:

1. Set CIBP @ 540' w/ ^{150'} 100' of cement. Pressure test plug to 1000 PSI for 30 minutes. ^{8 5/8" csg shoe was TAG.}
2. Set cement plug from 100' to surface.
3. Install dry hole marker.
4. Strip caliche pad & clean location.

If this work requires an earthen pit, a permit must be approved prior to construction of the pit(s).

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Rosalie Jones TITLE President DATE 03/14/05

Type or print name Rosalie Jones E-mail address: Telephone No. 505-748-2093

(This space for State use)

APPROVED BY Phil Hankin TITLE Field Inspector DATE 4/18/05

Conditions of approval, if any:

Eagle #1 Sec 25-20S-27E

