

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Budget Bureau No. 1004-C-1
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

NM 0560379

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

SW Henshaw Premier Uni

8. FARM OR LEASE NAME

9. WELL NO.

11

10. FIELD AND POOL OR WILDCAT

West Henshaw Grayburg

11. SEC., T., S., M., OR BLK. AND SURVEY OR AREA

Section 17-T16S-R30E

12. COUNTY OR PARISH 13. STATE

Eddy

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL GAS WELL OTHER **Water Injection**

2. NAME OF OPERATOR **Kay Jay Oil Co.**

3. ADDRESS OF OPERATOR **P.O. Box 3565 Midland, Texas 79702 O. C. D.**

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)
At surface **APTESA**

RECEIVED BY
JUL 24 1985

1980' FSL-660' FWL-Sec.17-T16S-R30E

14. PERMIT NO. 15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3773' GL

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREAT

MULTIPLE COMPLETE

FRACTURE TREATMENT

ALTERING CASING

SHOOT OR ACIDIZE

ABANDON*

SHOOTING OR ACIDIZING

ABANDONMENT*

REPAIR WELL

CHANGE PLANS

(Other)

(Other)

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose to P & A subject waterflood injection well due to termination of water injection as follows:

1. Set CIBP @ 2600' w/15 sx. cement of top of plug.
2. Spot 25 sx. cement plug 1950'-1800'.(Top of Queens)
3. Pressure test casing.
4. Perforate @ 1200' & spot 45 sx. cement plug. (100' inside & 100' outside) WOC & tag plug.
5. Perforate @ 600' & spot 45 sx. cement plug (100' inside & 100' outside) WOC & tag plug
6. Set 10 sx. surface plug.
7. Install dry hole marker and restore location.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Agent

DATE

7/19/85

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side