

NM OIL CONS. COMMISSION
Drawer DD
Artesia, NM 88210

RECEIVED BY
OCT 31 1984
Form Approved.
Budget Bureau No. 42-R1424
O. C. D.
ARTESIA, OFFICE

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil well gas well other Dry Hole

2. NAME OF OPERATOR
Champlin Petroleum Company

3. ADDRESS OF OPERATOR
P.O. Box 7946 Midland, TX 79708-0946

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 1980' FNL & 760" FEL Unit H
AT TOP PROD. INTERVAL: Same
AT TOTAL DEPTH: Same

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

5. LEASE
NM-5485

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
Crow Flats Federal Com

9. WELL NO.
1

10. FIELD OR WILDCAT NAME
Wildcat and Crow Flats

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
30-16S-28E

12. COUNTY OR PARISH
Eddy

13. STATE
N. Mexico

14. API NO.
NA

15. ELEVATIONS (SHOW DF, KDB, AND WD)
3596.7 DF, 3599.5 KDB, 3585.7 GL

REQUEST FOR APPROVAL TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF	<input type="checkbox"/>		<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>		<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>		<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>		<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>		<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>		<input type="checkbox"/>
CHANGE ZONES	<input type="checkbox"/>		<input type="checkbox"/>
ABANDON*	<input checked="" type="checkbox"/>		<input type="checkbox"/>
(other)			

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Set CIBP @ 9300' cap w/35' cement
 Set CIBP @ 9050' cap w/35' cement
 Set " " 7600' cap w/50' cement
 Set " " 25 sx plug @ top of Wolfcamp (6468')
 Determine free point, cut off & pull 5 1/2" casing. Est. free point @ 4000'.
 Set 100' plug in top of stub @ 4000'. Tag plug.
 Set 100' plug @ intermediate casing shoe @ 2000'. Tag plug.
 Set 60' plug @ surface. Install dry hole marker.

Rec. Verbal Approval 9/13/84
from BLM-Carlsbad

Note: 10# mud between plugs.

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED [Signature] TITLE Operations Supt. DATE 9/17/84

(This space for Federal or State office use)
APPROVED BY _____ TITLE _____ DATE 10 29 84
CONDITIONS OF APPROVAL, IF ANY:

Post ID-2
11-2-84
PWA